




**NCR 7198 Thermal Receipt
Printer
Release 1.0
Owner's Manual**



B005-0000-1736
Revision B
November, 2006

The product described in this book is a licensed product of NCR Corporation.

NCR is the registered trademark of NCR Corporation. Other trademarks and registered trademarks are the property of their respective holders.

It is the policy of NCR Corporation (NCR) to improve products as new technology, components, software, and firmware become available. NCR, therefore, reserves the right to change specifications without prior notice.

All features, functions, and operations described herein may not be marketed by NCR in all parts of the world. In some instances, photographs are of equipment prototypes. Therefore, before using this document, consult with your NCR representative or NCR office for information that is applicable and current.

To maintain the quality of our publications, we need your comments on the accuracy, clarity, organization, and value of this book.

Address correspondence to:

Retail Systems Group–Atlanta
NCR Corporation
2651 Satellite Blvd.
Duluth, GA 30136

Copyright © 2002
By NCR Corporation
Dayton, Ohio U.S.A.
All Rights Reserved

Important Information to the User

In order to ensure compliance with the Product Safety, FCC and CE marking requirements, you must use the power supply, power cord, and interface cable which was shipped with this product or which meet the following parameters:

Power Supply

Power supply should be certified according to UL/EN/IEC60950, Class 2 power supply with SELV (Secondary Extra Low Voltage), non-energy hazard output, limited power source, input rated 100-240 Vac, 1.5/0.8 A, 50/60 Hz, output rated 24 Vdc, 3.15A

Use of this product with a power supply other than the NCR power supply will require you to test this power supply and NCR printer for FCC and CE mark certification.

Interface Cable

A shielded (360 degree) interface cable must be used with this product. The shield must be connected to the frame or earth ground connection or earth ground reference at EACH end of the cable.

Use of a cable other than described here will require that you test this cable with the NCR printer and your system for FCC and CE mark certification.

Power Cord

A UL listed, detachable power cord must be used for this product. For applications where the power supply module may be mounted on the floor, a power cord with Type SJT marking must be used. For applications outside the US, power cords which meet the particular country's certification and application requirements should be used.

Use of a power cord other than described here may result in a violation of safety certifications which are in force in the country of use.

The socket-outlet shall be installed near the equipment and shall be easily accessible.

Wichtige Benutzerinformationen:

Um die Produktsicherheit und die FCC und CE-Markierungsanforderungen bei der Benutzung des Druckers sicherzustellen, müssen entweder das mitgesante Netzgerät, Netzanschlußkabel und Verbindungskabel verwendet werden oder folgende Anforderungen müssen erfüllt sein:

Netzgerät:

Das Netzgerät muß ein UL verzeichnetes (QGGQ) Netzgerät der Klasse 2 mit SELV (Sekundärextraniederspannung), Nichtenergie Gefahrenausgang, begrenzter Energiequelle, einer Aufnahmeleistung von 100-240 VAC, 1.5/0.8 A und 50/60 Hz, und einer Leistungsabgabe von 24 VDC, 3.15 A.c sein.

Die Benutzung des Produktes mit einem Netzgerät, daß nicht von NCR mitgeliefert wurde erfordert das Testen des Netzgerätes mit dem NCR Drucker auf FCC und CE-Markierungs Befolgung.

Verbindungskabel:

Bei der Benutzung dieses Produkts muß ein abgeschirmtes (360 Grad) Verbindungskabel benutzt werden. Die Abschirmleitung muß entweder mit dem Rahmens des Gerätes oder der Erde verbunden sein oder alternativ müssen alle Enden des Kabels geerdet werden.

Falls das Verbindungskabel nicht in der hier beschriebenen Art benutzt wird, muessen das Kabel und der NCR Drucker auf die FCC und CE-Markierungs Befolgung überprüft werden.

Netzanschlußkabel:

Für dieses Produkt muß ein in UL aufgelistete, abnehmbares Netzanschlußkabel benutzt werden. Falls das Netzgerät fest auf dem Boden montiert ist, muß ein Netzanschlußkabel mit der SJT Markierung benutzt werden. Für Anwendungen außerhalb der USA, sollte ein Netzanschlußkabel benutzt werden, daß der Zertifizierung und Bestimmung des jeweiligen Landes entspricht.

Das Abweichen der hier beschriebenen Benutzungsanleitung des Netzanschlußkabels kann gegen die gesetzlichen Sicherheitsbestimmungen des jeweiligen Landes verstoßen.

**Federal Communications Commission (FCC)
Radio Frequency Interference Statement**

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Communication Cables

Shielded communication cables must be used with this unit to ensure compliance with the Class A FCC limits.

Information to User

This equipment must be installed and used in strict accordance with the manufacturer's instructions. However, there is no guarantee that interference to radio communications will not occur in a particular commercial installation. If this equipment does cause interference, which can be determined by turning the equipment off and on, the user is encouraged to contact NCR immediately.

The NCR company is not responsible for any radio or television interference caused by unauthorized modification of this equipment or the substitution or attachment of connecting cables and equipment other than those specified by NCR. The correction of interferences caused by such unauthorized modification, substitution or attachment will be the responsibility of the user.

**Industry Canada (IC)
Radio Frequency Interference Statement**

This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe A respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

Bundeskommunikation Kommission (FCC)**Hochfrequenz-Störungs Richtlinie.**

Warnung: Änderungen oder Änderungen an der Maßeinheit, die nicht ausdrücklich von der Seite, die für die Befolgung verantwortlich ist, genehmigt ist, können zum Entzug der Benutzungsberechtigung dieses Gerätes führen.

Anmerkung: Dieses Gerät wurde getestet und entspricht der zulässigen Richtlinien eines digitalen Gerätes der Klasse A, gemäß Abschnitt 15 in den FCC Richtlinien. Diese Richtlinien sind dazu da, einen angemessenen Schutz gegen schädliche Störung bei der kommerziellen Nutzung dieses Gerätes zu gewährleisten. Dieses Gerät erzeugt und benutzt Hochfrequenzenergie und kann Hochfrequenzenergie ausstrahlen. Wenn die Installation und Benutzung dieses Gerätes nicht wie im Benutzer Handbuch beschrieben ist, durchgeführt wird, kann eine schädliche Störung von Funkverbindungen verursacht werden. Der Betrieb dieses Gerät in einem Wohngebiet kann schädliche Störung verursachen die auf Kosten des Benutzers behoben werden müssen.

Kommunikationskabel:

Dieses Gerät muß in Übereinstimmung mit Kategorie A FCC Richtlinien mit einem abgeschirmten Kabel betrieben werden.

Benutzerinformationen:

Dieses Gerät muß wie in der Hersteller Anweisungen beschrieben installiert und benutzt werden. Jedoch gibt es keine Garantie dafür, daß Funkstörung nicht in bestimmten kommerziellen Installation auftritt. Für den Fall, daß das Gerät Funkstörungen verursacht, was durch das An und Abschalten des Gerätes festgestellt werden kann, wird der Benutzer aufgefordert sofort mit NCR Kontakt aufzunehmen.

NCR ist nicht für Radio- oder Fernsehstörung verantwortlich, die durch unautorisierte Änderung der Ausrüstung oder den Ersatz der anschließenden Kabel oder durch Anschluß von Geräten hervorgerufen wird, die nicht ausdrücklich von NCR genehmigt wurden sind. Die Korrektur von Störungen, die durch solche unautorisierte Änderung, Ersatz oder Zubehör verursacht werden, liegt in der Verantwortlichkeit des Benutzers.

Industrie-Kanada (IS)**Hochfrequenz-Störungs Richtlinie:**

Dieses digitale Gerät der Klasse A entspricht allen Anforderungen der kanadischen Störung-Verursachende Geräte Richtlinie.

Quick Reference

This Quick Reference will direct you to key areas of the Owner's Manual. For a complete listing of topics, consult the Table of Contents or the Index.

***Setting Up the Printer* page 9**

Basic requirements for unpacking and installation, connecting the printer, turning it on, and running the print test.

***Running the Data Scope Mode* page 56**

Instructions for running the data scope mode.

***Troubleshooting* page 44**

Information on correcting problems with the printer.

How to Use this Book

Use this book as a general and technical reference manual and as a guide when replacing parts on the printer. The service guide is intended as a guide for service representatives, field engineers, and those who will be installing and learning about the 7198 printer. It can also be used as a reference for service courses.

See the Quick Reference page, the Contents, or the Index for detailed listings of what is contained in this book.

Who Should Use this Book?

You must be a trained service representative to service the 7198 Thermal Receipt printer.

How to Obtain More Information

For more information see the following documents:

- 7198 Receipt Printer: Service Manual (B005-0000-1737)
- 7198 Receipt Printer: Parts Identification Manual (B005-0000-1738)

For this and additional copies of the Owner's Manual, contact your sales representative.

Revision Record

Issue	Date	Remarks
A	August 06	Initial Issue
B	November 06	Revised formatting of document

Contents


Quick Reference	vii	
How to Use this Book.....	viii	
Who Should Use this Book?	viii	
How to Obtain More Information	viii	
Revision Record	viii	
Contents	ix	
Chapter 1: About the 7198 Printer		1
Features and Options	2	
Receipt Station.....	2	
General Features	3	
Options.....	3	
Thermal Print Head.....	3	
Ordering Paper and Supplies.....	4	
Ordering Thermal Receipt Paper.....	4	
Ordering Other Supplies	6	
Ordering Documentation	6	
Cleaning the Printer.....	7	
Cleaning the Cabinet.....	7	
Cleaning the Thermal Print Head	8	
Chapter 2: Setting Up and Using the Printer		9
What Is in the Box?	9	
Removing the Packing Material.....	10	
Repacking the Printer.....	11	
Choosing a Location	11	
Wall mounted.....	12	
Wall mounted Power Supply (Option).....	13	
Setting Switches	14	
Connecting the Cables.....	15	
About the Universal Serial Bus	18	
Advantages of USB connections.....	18	
Advantages of the NCR USB Solution.....	18	
Checking for USB Support on the Host Computer	19	
Host Configuration.....	19	
Configuring the Printer.....	20	
Installing the USB Printer Drivers	23	
Checking the Installation	33	
Configuring Serial Port Number Assignments.....	36	
Running the Edgeport Utility	36	
Serial Port Configuration Methods	37	
Uninstalling the Drivers	37	
Using the Printer	39	

Loading and Changing the Receipt Paper.....	40	
Removing the Paper Roll.....	40	
Loading the Paper Roll	41	
Advancing Paper	43	
Chapter 3: Solving Problems		44
Green LED Does Not Come On/Printer Will Not Print.....	45	
Green LED Blinking (Slow)	45	
Green LED Blinking (Fast).....	45	
Receipt Printing is Light or Spotty	46	
Other Serious Problems	47	
Contacting a Service Representative	47	
Chapter 4: Diagnostics		48
Level 0 Diagnostics	48	
Level 1 Diagnostics	49	
Printer Configuration.....	49	
Configuring the Printer.....	50	
Communication Interface Modes	53	
Diagnostic Modes	56	
Emulation/Software Options	57	
Hardware Options.....	61	
Default Code Page.....	64	
Double Side Printing Settings	66	
EEPROM to Default Settings.....	69	
Mfg. Adjustment	70	
Mfg Adjustment:.....	70	
Level 2 Diagnostics	76	
Level 3 Diagnostics	77	
Chapter 5: Communication		78
Communication Overview	78	
Interface.....	78	
Sending Commands	78	
RS-232C Interface.....	79	
Print Speed and Timing	79	
XON/XOFF Protocol.....	80	
DTR/DSR Protocol.....	80	
RS-232C Technical Specifications	81	
Setting Extra RS-232C Options	86	
Chapter 6: Commands		87
Command Conventions	87	
Introduction.....	87	
List of Commands and Location.....	87	
By Command Code	88	
By Function.....	92	
Printer Function Commands.....	92	

Vertical Positioning and Print.....	92
Horizontal Positioning Commands	93
Print Characteristic Commands.....	93
Graphics Commands.....	94
Status Commands.....	94
Real Time Commands.....	94
Unsolicited Status Update	95
Barcode Commands	95
Page Mode Commands.....	95
Macro Commands	96
User Data Storage Commands.....	96
Asian Character Commands	96
Flash Download Commands.....	96
Double Side Printing Commands.....	98
Comparison Chart	99
Command Descriptions	101
Printer Function Commands.....	102
Vertical Positioning and Print Commands	108
Horizontal Positioning Commands	114
Print Characteristic Commands.....	121
Graphics Commands.....	140
Status Commands.....	150
Real Time Commands.....	161
Unsolicited Status Update Validation.....	168
Bar Code Commands	173
Page Mode Commands.....	179
Macro Commands	186
User Data Storage Commands.....	188
Asian Character Commands	195
Flash Download Commands.....	198
Double Side Printing Commands.....	203
Chapter 7: Reflashing the Printer Firmware	219
Flash Utility Information	219
File Configurations	219
Printer Languages Cross Reference.....	220
Appendix A: Specifications	234
Printing Specifications.....	234
Power Requirements	235
Environmental Conditions	235
Reliability	236
Dimensions and Weight.....	236
Density of Receipt Print Lines.....	236
Duty Cycle Restrictions (Printing Solid Blocks)	236

Appendix B: Print Characteristics	238
Character Size.....	238
Receipt Station.....	238
Print Zones.....	239
Receipt Station.....	239
Character Sets.....	241
Appendix C: How to make printing pattern from single side to double side (Double side mode with single side command)	295
Index	300

Chapter 1: About the 7198 Printer



The 7198 printer is a fast, quiet, relatively small and very reliable multiple-function printer that provides the ability to print on the front and back of the receipt. It prints receipts and two color printing in single side mode.

The industry-standard RS-232C communication interface as well as USB which allows the 7198 to be connected to any host computer that uses RS-232C or USB communication interface.

Features and Options

The 7198 printer comes with several features and options.

Receipt Station

- Thermal printing with front and back printing
- Standard pitch (host selectable): 15.2 characters per inch, 44 columns
- Compressed pitch (host selectable): 19.0 characters per inch, 56 columns
- Resident bar codes
 - Code 39
 - Code 93
 - Code 128
 - UPC-A
 - UPC-E
 - JAN8 (EAN)
 - JAN13 (EAN)
 - Interleaved 2 of 5
 - Codabar
 - PDF417
- Drop-in paper loading requiring no spindle or threading paper
- Paper low indicator
- Paper exhaust indicator
- Variety of print modes: double high, double wide, upside down, and rotated
- 14 resident character language Code Pages:
 - PC Code Page 437 (US English)
 - PC Code Page 850 (Multilingual)
 - PC Code Page 852 (Slavic)
 - PC Code Page 858 (with Euro symbol)
 - PC Code Page 860 (Portuguese)
 - PC Code Page 862 (Hebrew)
 - PC Code Page 863 (French Canadian)
 - PC Code Page 864 (Arabic)
 - PC Code Page 865 (Nordic)
 - PC Code Page 866 (Cyrillic)
 - PC Code Page 1252 (Windows Latin #1)
 - PC Code Page Katakana
 - PC Code Page 874 (Thai)
- Space Page
- 16K RAM for downloaded character sets or bit-mapped graphics (such as logos)
- Two Color Printing

General Features

- Knife
- Cover open sensors
- One cash drawer connector (supports 2 cash drawers)
- Industry standard RS-232C and USB communication interface
- History EEROM for custom settings
- Audible tone (controlled by application)

Note: The 7198 does not have a paper journal. The journal is kept electronically by the host computer.

Options

- Remote power supply
- Communication cables
- Wall Mount

Thermal Print Head

The 7198 Receipt Station uses a thermal print head for printing on the front and back of receipts, and is extremely fast and quiet. Since it uses heat to print directly on paper, there is no cassette or ribbon to change, eliminating soiled fingers and paper dust.

There is no regularly scheduled maintenance for the print head and it does not need to be regularly cleaned. However, if it does appear dirty, wipe it with cotton swabs and rubbing alcohol. If spotty or light printing problems persist after the thermal print head has been cleaned, see “Chapter 3: Solving Problems” for more information.

Note: The thermal print head does not normally require cleaning if the recommended paper is used. If non-recommended paper has been used for an extended period of time, cleaning the print head with cotton swabs and rubbing alcohol will not be of much benefit. See “Ordering Receipt Paper” on the next page for the recommended paper.

The print head is designed for a very long life, but it may be replaced if needed. Only a trained service representative may replace the print head. See “Chapter 3: Solving Problems” to determine if the print head needs to be replaced.

Ordering Paper and Supplies

Thermal receipt paper, ribbon cassettes, and forms can be ordered. Documentation is also available.

Ordering Thermal Receipt Paper

The 7198 requires NCR qualified thermal paper to be used on the thermal receipt print station to insure proper operation of the printer. In addition the paper rolls must have the following dimension.

Diameter	Length	Width
80 mm max. (3.15 in.)	83 meters (273 ft.)	80 mm \pm .5 mm (3.15 \pm .008 in.)
80 mm max. (3.15 in.)	83 meters (273 ft.)	58 mm \pm .5 mm (2.28 \pm .008 in.)

The paper must not be attached at the core. Use paper with a colored stripe at the end to indicate that the paper is running low.

80 mm Paper Stock (Single Side)

Product ID	Paper Stock	Paper Grade Description
9078-0022	856911	Simplicity (for text printing)
9078-0029	856966	Enhanced Image (for text and simple graphics)
9078-0033	878559	High Resolution (for text, bar codes & detailed graphics)
Two Color		
9078-0052	856458	80 MM 2-color blue/black
9078-0053	856461	80 MM 2 color red/black

80mm Paper Stock (Two Side)

Product ID	Paper Grade Description
9079-0001	80 MM 2-color black/black Simplicity (for text printing)
9079-0002	80 MM 2-color black/blue Simplicity (for text printing)
9079-0003	80 MM 2 color black/red Simplicity (for text and simple graphics)
9079-0004	80 MM 2-color black/black High Resolution (for text, bar codes & detailed graphics)
9079-0005	80 MM 2-color black/blue High Resolution (for text, bar codes & detailed graphics)
9079-0006	80 MM 2 color black/red High Resolution (for text, bar codes & detailed graphics)

The paper must not be attached at the core. Otherwise the receipt station will be damaged when the paper is exhausted.

To order thermal receipt paper, contact your sales representative or order from NCR at the following address or toll free number:

NCR

Media Products Division

9995 Washington Church Road

Miamisburg, OH 45342

Voice: 1(800)543-8130 (toll free), or local listing of The NCR Systemedia

Products sales office

It is critical that only certified thermal paper be used with this printer, otherwise damage may result causing poor print quality or cause damage to the printer.

Ordering Other Supplies

Contact your sales representative to order the supplies listed in the table.

Item	Type	Number
Power supply with attached cable to printer and U.S. power supply cord	75 Watt Power Supply	7167-K311-V001
Power supply (w/o power cord)	75 Watt Power Supply	7167-K310-V003
Power supply cord (to outlet)	United States	1406-C325-0030
	International (no plug)	1416-C319-0030
	United Kingdom	1416-C321-0030
	S.E.V.	1416-C320-0030
	Australia	1416-C322-0030
	International (with plug)	1416-C323-0030
RS-232C Communication Cables		
9-pin to 9-pin (Black)	1.1 meters	1416-C879-0010
9-pin to 9-pin (Black)	4.0 meters (13.2 feet)	1416-C879-0040
USB Communication Cables		
USB Type A to Type B Connector (Black)	1.0 Meters	1432-C083-0010
USB Type A to Type B Connector (Black)	4.0 Meters	1432-C083-0040
USB Plus Power Cables		
USB/Plus Power to Type B Connector (Black)	1.0 Meters	1432-C092-0010
	4.0 Meters	1432-C092-0040
USB/Plus Power to Type B Connector (Black)		
Extended Slip Table (Standard)		7167-K352-V001
Cash Drawer	2189	2189-K002-V001 (Switchable for Drawer 1 or Drawer 2)
Cash Drawer Cable	Y Cable	1416-C372-0006

Ordering Documentation

Contact your sales representative to obtain the following documentation:

- 7198 Receipt Printer: Parts Identification Manual (B005-0000-1738)
- 7198 Receipt Printer: Service Manual (B005-0000-1737)
(includes Troubleshooting Guide)
- 7198 Receipt Printer: Owners Manual (B005-0000-1736)

Cleaning the Printer

Cleaning the Cabinet

The external cabinet materials and finish are durable and resistant to these items:

- Cleaning solutions
- Lubricants
- Fuels
- Cooking oils
- Ultraviolet light

There is no scheduled maintenance required for the 7198.

Clean the cabinet as needed to remove dust and finger marks. Use any household cleaner designed for plastics, but test it first on a small unseen area. If the receipt bucket is dirty, wipe it with a clean, damp cloth.

Cleaning the Thermal Print Head

Caution: Do not spray or try to clean the thermal print head or the inside of the printer with any kind of cleaner as this may damage the thermal print head and electronics.

If the thermal print head appears dirty, wipe it with cotton swabs and isopropyl alcohol.

If spotty or light printing problems persist after the thermal print head has been cleaned, see "Chapter 3: Solving Problems" for more information.

Note: The thermal print head does not normally require cleaning if the recommended paper grades are used. If non-recommended paper has been used for an extended period of time, cleaning the print head with cotton swabs and rubbing alcohol will not be of much benefit. See "Ordering Paper and Supplies" earlier in this manual for recommended paper.

Chapter 2: Setting Up and Using the Printer

What Is in the Box?


The following items are packed in the shipping box:

- Printer enclosed in a plastic bag and foam pack
- Thermal receipt paper roll

These items may be ordered as options from NCR and will be shipped separately:

- Communication cable (from host computer to printer)
- DC Power Cable
- Remote Power Supply
- Cash drawer with cables (may be ordered from other equipment suppliers: see “Ordering Other Supplies” in chapter 1)

Removing the Packing Material



1. Remove the printer from the foam pack and plastic bag.
2. Remove the receipt paper roll and cables from the foam packing material.
3. Save all packing materials for future storing, moving, or shipping the printer.

Note: If the printer is wall mounted, the paper low switch must be disable.

Repacking the Printer


Review the illustrations on the previous two pages to pack the printer.

1. Place receipt paper between the receipt cover and the print head for protection.
2. Place the printer in the plastic bag and foam pack, place the packed printer in the box, and secure the box with packing tape.
3. If you are sending the printer to NCR for repair, call your NCR-authorized service representative for instructions on where to send the printer.

Be prepared to answer questions concerning shipping and billing.


Choosing a Location

The 7198 printer takes up relatively little counter space and may be set on or near the host computer. Make sure there is enough room to open the receipt cover to change the paper. The illustration shows the actual dimensions of the printer, but leaves several inches around the printer for connecting and accessing the cables.



Wall mounted


The 7198 printer may be mounted on a vertical wall by using the keyhole slot at the bottom of the printer base. Make sure there is enough room to open the receipt cover to change the paper. Mount the screws on the wall using the following recommended mount dimensions. Use a M5x20 screw which is to be securely fastened to a wall stud or using a "Molly" fastener (not provided).



Note: Paper low must be disabled when printer is wall mounted

Wall mounted Power Supply (Option)

The 75 watt power supply may be mounted on a vertical wall by using the holes on the cover. Mount the screws on the wall using the following recommended mount dimensions. Use a #8 wood screw which is to be securely fastened to a wall stud or using "Molly" fasteners.




Setting Switches

The DIP switches, located at the back of the printer, are used for two purposes:

- To set variables for several printer functions (see the sections for the various printer functions in “Level 1 Diagnostics” in “Chapter 4: Diagnostics” for Setting Up the Printer)
- To perform diagnostic tests (see the sections for the various diagnostic tests in “Level 1 Diagnostics” in “Chapter 4: Diagnostics” for Setting Up the Printer)

Caution: The DIP switches are set at the factory to predetermined settings and should not be changed unless to change parameters or to reflash the firmware.



Note: Switch 1 is shown in the Off position for reference.

Use a paper clip or other pointed object to set the switches.

1. Set the switches to the desired settings shown in the table.
2. Reset the printer by disconnecting and reconnecting the power to the printer.

Resetting the Printer

The printer is reset by disconnecting/reconnecting the DC power.

Connecting the Cables

There are three different types of cables that connect to the printer:

- Power supply cable supplying power from the power supply
- Communication cable (RS-232 or USB) connecting the printer to the host computer
- Cash drawer cable connecting the printer to one or two cash drawers

Caution: Disconnect the power before connecting the cables. Always connect the communication cable and cash drawer cables before connecting power to the power supply. Always disconnect power to the power supply before disconnecting the communication and cash drawer cables.

Follow these steps to connect the cables. See the illustration on the next page.

1. Unplug the power supply from its power source.
2. Connect the power and communication cables to their respective connectors under the printer as shown in the illustration.

For the RS232 Cable, be sure to screw the communication cable to the communication connector.


3. Route the cables through the cable strain relief on the bottom of the printer, then through the two slots in the cable access cover as shown in the illustration.
4. Connect the communication cable to the appropriate host computer connector.
5. Connect the cash drawer cable to the printer and cash drawer.

The connector is a standard phone jack located at the rear of the printer.


6. Plug the power cord into the power supply for remote power supply installation, then plug the power supply into an outlet.

At this point, the printer receives power. If the On Line LED (green) is on, the printer is on-line. Otherwise, the printer is off-line.


7. For Host powered installation plug the DC cable into the POS terminal.



Bottom of the Printer



Bottom of the Printer



Bottom of the Printer

About the Universal Serial Bus

The Universal Serial Bus (USB) is a peripheral bus for personal computers that was first released in January 1996. Since that time, virtually all Intel Architecture personal computers have the hardware to support USB, and a large number of computers exist that have both the hardware and software support required to interface with USB peripherals.

Advantages of USB connections

USB has a number of advantages over legacy connection schemes (e.g., serial RS-232). These advantages include:

- **High Speed:** up to 12 MB/second for high-speed devices.
- **Plug and Play:** Devices are automatically recognized and configured at installation.
- **Hot plug:** Bus supports installation and removal of devices with the power applied.
- **Up to 127 devices:** One host can support up to 127 devices with the use of hubs.
- **“Free ports”:** Most PC architecture machines contain two USB ports in the base hardware.

These advantages have become attractive to the POS industry for a couple of reasons.

Additional POS devices. Some POS systems are required to host more peripherals than can be supported by two RS-232 ports typical in a platform. With the addition of one (or two) USB connectors, the platform can now support the additional devices that had previously required a serial port expander card.

Higher bandwidths. New devices coming into use have bandwidth requirements that are higher than the bandwidth that can be supported on legacy interfaces. These devices include image scanners and printers. As the speed and capability of POS printers increases, the performance of the printer in an application can become limited by the speed of the communications interface. USB provides ample bandwidth to support current and future POS printer requirements.

Advantages of the NCR USB Solution

NCR has eliminated any cost associated with porting applications to USB by implementing a USB solution that simulates standard serial communications in Windows 98 (SR2), Windows 98 USB Hot Patch, ID: Q236934, and NT 4.0 (Service Pack 3 or higher) and Windows 2000. Application developers need only redirect their software to the virtual serial ports created by the NCR USB solution to use the printer.

Checking for USB Support on the Host Computer

If USB interface communications is required, the host computer must be equipped and setup properly. If it is not, you need to install a USB interface card. With the required hardware in place, Windows 98 (SR2), Windows 98 USB Hot Patch, ID: Q236934, NT 4.0 (Service Pack 4.0 or higher) and Windows 2000 (Service Pack 2.0 or higher) natively support plug-and-play USB with a built-in driver; Windows NT does not, and the NCR windows NT USB driver needs to be installed.

IMPORTANT: You need to have internet access to download the USB drivers from the NCR Web site://www.NCR.com.

Host Configuration

Verify that the proper hardware has been installed in the host PC.

Windows 98:

1. Open the Control Panel.
2. Click on System (Windows 98).
3. Click the Device Manager tab.
4. In the Device Manager window, scroll down the list of installed hardware devices until you find an entry for "Universal serial bus controller."

If this entry exists, your host computer is set up for USB operation. If this entry does not appear:

- Consult your computer documentation to see if USB must be enabled in the BIOS setup.

Windows NT:

To see if your POS terminal is USB-compliant, look at the back.

- If it has a USB connector port, your hardware is all set.

Note: Even though the host may have a USB port, Windows NT does not natively support plug-and-play USB because it does not have a built-in driver. You will need to load the NCR Windows NT USB driver (see "Installing the USB Printer Drivers").

- If the connector port is missing, you need to install a third-party USB card, according to the manufacturer's instructions.

Note: For Windows NT units requiring the installation of a card, a Windows 98 USB card can be used with the NCR Windows NT driver.

Windows 2000:

1. Open the Control Panel.
2. Click on System.

3. Click the Device Manager tab.
4. In the Device Manager window, scroll down the list of installed hardware devices until you find an entry for "Universal serial bus controller."

If this entry exists, your host computer is set up for USB operation. If this entry does not appear:


- Consult your computer documentation to see if USB must be enabled in the BIOS setup.


Configuring the Printer

USB is a plug-and-play environment. As such, neither the printer nor the host requires user configuration to work. However, since the NCR solution simulates a serial communication interface, you must configure "handshaking" on the printer for proper operation. The printer can be configured to use hardware flow control (using DTR/DSR) or software flow control (using XON/XOFF). All other serial communication parameters (i.e., baud rate, parity, stop bits, and data bits) are ignored.

To define software or hardware handshaking:

1. Open the Receipt Cover and check whether there is paper in the printer. If there isn't, insert the paper roll, as described in the *Owner's Manual*.
2. Turn over the printer so the bottom side is facing you.
3. Set DIP switch 1 to the On position (up).






4. Reset the printer. See below for information on resetting the printer.

The printer beeps, prints the current configuration, then waits for you to make a selection from the Main Menu on the printout.

DIP Switch Settings Information

Switch 1 Settings	Switch 2 Settings	Printer State
OFF (0)	OFF (0)	On-line Mode (default)
ON (1)	OFF (0)	Diagnostic Mode
OFF (0)	ON (1)	Flash Download Mode
ON (1)	ON (1)	Vendor Adjustment Mode



Configuration Menu and Print Test samples (show approximately 60% of size).

Follow the instructions on the scrolling menu, pressing the Paper Feed button to make selections. Indicate Yes with a long click, and No with a short click.

- Press and hold the Paper Feed button for at least one second for a long click.
 - Press the Paper Feed button quickly for a short click.
5. Select Set Communication Interface from the Main Menu.
The printer scrolls to the first question.
 6. Select RS232/USB.
 7. Skip through the parameters with short clicks until Set Flow Control Method is displayed.
 8. Follow the instructions to select either XON/OFF or DTR/DSR, then skip the remaining communications parameters.
 9. When you have finished, set DIP switch 1 to Off (down).
 10. Reset the printer.

The printer resets with the new selection. You can verify the new setting by pressing the Paper Feed button to print out a diagnostics form or by holding the Paper Feed button while closing the Top Cover.

Installing the USB Printer Drivers


Windows NT users need to run Service Pak 3 or higher for a successful installation and should exit all Windows programs before starting.

1. Verify that the printer is plugged in and the power is on.
2. The installation varies depending on the operating system.

Windows 98

Follow the on-screen instructions. The printer beeps when the USB device is recognized. Go to the location where you downloaded the drivers and double click the file.








Note: Location of the IONetworks files on the CD-ROM may vary depending on the version of the CD that is being used.

Windows NT

The printer beeps when it is plugged in to show the USB device is recognized. Click on the file you downloaded and follow the on-screen instructions.







Windows 2000

Follow the on-screen instructions. The printer beeps when the USB device is recognized. Go to the location where you downloaded the drivers and double click the file.









Note: Location of the IONetworks files on the CD-ROM may vary depending on the version of the CD that is being used.







Checking the Installation


You need to verify that the device drivers were installed correctly:

Windows 98:

1. Open the Device Manager window, as you did in “Checking for USB Support.”
2. Scroll down to “Universal serial bus controllers.”

The following devices should be displayed:

- NCR 7198 Printer
- NCR 7198 Serial Ports [Port#] (where the # is the location of the printer)



3. Scroll back up to “Ports.”


You should see a COM number and port description for the **NCR** printer.

If the devices are missing or are not listed correctly, the installation wasn't successful. You will need to reinstall the drivers.


Windows NT:

Go the Windows Start button and select Programs > InsideOut Networks Utilities > Edgeport Configuration Utility. A window opens that contains the name of the printer, and the port assignment.

If this information is not listed, then the installation was not successful. You will need to reinstall the drivers.

**Windows 2000:**


1. Open the Device Manager window, as you did in "Checking for USB Support."
2. Scroll down to "Universal serial bus controllers."



3. Scroll back up to “Ports.”

If the devices are missing or are not listed correctly, the installation wasn't successful. You will need to reinstall the drivers.

If this information is not listed, then the installation was not successful. You will need to reinstall the drivers.



Configuring Serial Port Number Assignments

This section describes how the NCR USB solution assigns serial port numbers (e.g., COMx) to the printer. The information that determines the assigned port number is stored in the host computer and not in the printer. This assignment is made in one of three ways. The first method is the default method that automatically assigns a serial port number to the printer. The other two methods require the user to specify a port number. These methods are described more fully in “Serial Port Configuration Methods” on the following page.

Running the Edgeport Utility

You’ll need to run the Edgeport utility to check which serial port has been assigned to the printer. This utility queries and configures the operating system and driver for the information regarding the virtual serial port.

Windows 98

1. Open the Device Manager and make sure “View Devices by Type” is selected.
2. Scroll down to Universal serial bus controller, and expand the list by pressing the “+” symbol. You’ll see two entries for your NCR printer.
3. Select the printer name and click Properties.
4. Select the Details tab, then press the Details button to start the Edgeport utility.

Windows NT 4.0

From the Windows Start menu, select Programs > Inside Out Networks Utilities > Edgeport Configuration Utility.

Serial Port Configuration Methods

Automatic (Default). When the printer is plugged into the USB port of the host and the drivers are loaded, the printer will default to the next available serial port number. In many cases this is exactly what is desired. You can check the assigned serial port by clicking the General tab in the Edgeport utility. You'll see an entry for the NCR printer. Expand the list to see which serial port has been assigned to the printer.


Assigning a serial port to the printer. If the default assignment does not meet the requirements of the installation, you can assign a different serial port to the printer. From the General tab of the Edgeport utility, select the printer and press Configure. Follow the directions on the resulting form to assign a new port to the printer.

Associating a serial port with a specific USB port. (Windows 98 and NT) In certain installations it is desirable to associate a serial port number with a specific USB port. This is particularly important if multiple identical printers are installed on one host. Select the Advanced tab in the Edgeport utility, and follow the instructions for configuring the serial port number based on the physical USB port.

Uninstalling the Drivers

Windows 98:

1. Open the Device Manager and make sure "View Devices by Type" is selected.
2. Scroll down to Universal serial bus controller, and expand the list by pressing the "+" symbol. You'll see two entries for your NCR printer.
3. Select the printer name and click Properties.
4. Select the Details tab, then press the Details button to start the Edgeport utility.
5. Click the Advanced tab.
6. Click the Uninstall button and follow the on-screen instructions.

**Windows NT:**


Windows NT users will need to run the Edgeport Configuration Utility to uninstall the drivers.

1. Press Windows Start Menu button.
2. Choose Programs, then Inside Out Networks Utilities.
3. Choose Edgeport Configuration Utility.
4. Click the Advanced tab.
5. Click the Uninstall button and follow the on-screen instructions.

Windows 2000:

1. Open the Device Manager and make sure "View Devices by Type" is selected.
2. Scroll down to Universal serial bus controller, and expand the list by pressing the "+" symbol. You'll see two entries for your NCR printer.
3. Select the printer name and click Properties.
4. Select the Details tab, then press the Details button to start the Edgeport utility.
5. Click the Advanced tab.
6. Click the Uninstall button and follow the on-screen instructions.

Using the Printer



Note: See “Setting Switches” earlier in this book for instructions on setting the DIP switches.

1. Connect the power supply to the printer and turn on the power source.

The printer goes through a self-test routine to ensure everything is working properly then “beeps.” After the printer has completed its “startup” cycle, it is ready to receive data.

If the LED blinks, or the host computer indicates that there is a problem, see “Chapter 3: Solving Problems” for more information.

2. To perform a Configuration check (optional), reset the printer while holding the Paper Feed Button, or open the receipt door and while pressing the paper feed button close the receipt door, let go of the Paper Feed Button once the printing begins.

Note: The printer receives power when the power supply is on even if the printer is off-line. To completely remove power, unplug the power supply from the outlet, or turn the POS terminal off.

Loading and Changing the Receipt Paper

Although the illustrations show a used roll being removed, the instructions apply to loading paper for the first time.

Change the paper when either of the following two conditions occurs:

- LED blinks (slow): the paper is low

There are approximately 1 ½ to 7 ½ meters (5-25 feet) of paper remaining on the roll. Change the paper as soon as possible to avoid running out part way through a transaction.

Depending on the application program, the host computer may alert you when the paper is low.



- LED blinks (fast): the paper is out

Change the paper immediately or data may be lost.

Caution: Do not operate the printer or host computer if the printer runs out of paper. The printer will not operate without paper, but it may continue to accept data from the host computer. Because the printer cannot print any transactions, the data may be lost.

Removing the Paper Roll

1. Open the receipt cover by pressing receipt cover button
2. Remove the used roll.





Loading the Paper Roll

Note: Tear off the end of the new roll so that the edge is loose.

1. Place the new roll in the bin with a little extra paper extending over the front of the printer.

Be sure the paper unrolls from the bottom of the roll. Otherwise the paper will not be printed on the correct side of the paper roll.

Be sure the paper is routed above the paper damper.



2. Align the paper in the center of the receipt printer.



3. Close the receipt cover.



4. Remove the excess paper by tearing it against Top Cover tear-off bar.

Note: Refer to the illustrations imprinted on the back of the receipt cover.



Advancing Paper

1. Press the Paper Feed button on the operator panel to advance the paper.

The cover must be closed. To ensure print quality and the proper alignment of the paper, advance about 30 cm (12 inches) of paper.

2. Tear off the excess paper against Top Cover tear-off bar.

Chapter 3: Solving Problems

The 7198 printer is a simple, generally trouble-free printer, but from time to time minor problems may occur. For example, the power supply may be interrupted or the thermal print head may overheat.

A green LED on the operator panel signals that something may be wrong.

For some problems, the printer communicates the information to the host computer and relies on the application to indicate what the problem is.

The information on the following pages describes some problems that you may encounter: problems that you can easily fix, and others that you will need to contact a service representative for.

You may be able to correct many of the conditions or problems without calling for service. However, if a problem persists, contact a service representative. See “Contacting a Service Representative” at the end of this chapter.

Green LED Does Not Come On/Printer Will Not Print

Problem	What to Do	Where to Go
Cables may not be connected properly	Check all cable connections. Check that the host computer and power supply are both on (the power supply is turned on by plugging it into an outlet).	See "Connecting the Cables" in chapter 2.
Power supply may be defective	If the power supply is plugged in, but does not come on, you will need to order a new power supply.	See "Ordering Other Supplies" in chapter 1.

Green LED Blinking (Slow)

Problem	What to Do	Where to Go
Receipt paper is low*	There are about 4 ½ meters, ± 3 meters, (15 feet, ± 10 feet) of paper left. Change the paper soon to avoid running out of paper part way through a transaction.	See "Loading and Changing the Receipt Paper" in chapter 2.

Green LED Blinking (Fast)

Problem	What to Do	Where to Go
Receipt paper is out	Change the paper now. Do not run a transaction without paper as the data may be lost.	See "Loading and Changing the Receipt Paper" in chapter 2.
Receipt cover is open	Close the cover. The printer will not operate with the cover open.	
Knife failure	Open the receipt cover and check the knife. Clear any jammed paper you can see. Tear off any excess paper against the tear-off blade.	
	Contact a service representative if this does not resolve the problem.	See "Contacting a Service Representative" later in this chapter.
AC supply voltage is out of range	If paper is not low and no conditions indicate that the thermal print head is too hot, then it is likely that the power supply voltage is out of range.	
	Contact a service representative if this does not resolve the problem.	See "Contacting a Service Representative" later in this chapter.

Thermal print head temperature is out of range	<p>The print head may overheat when printing in a room where the temperature is above the recommended operating temperature or when printing high-density graphics continuously, regardless of the room temperature. In either case, the printer will shut off.</p> <p>If the temperature of the print head is too hot, adjust the room temperature or move the printer to a cooler location.</p> <p>If the print head is overheating because of printing high density graphics continuously, reduce the demand on the printer.</p> <p>If the printer continues to overheat, contact a service representative.</p>	<p>See "Environmental Conditions" in Appendix A for the recommended temperature range for operating the printer.</p> <p>See "Contacting a Service Representative" later in this chapter.</p>
Power supply voltage is out of range	<p>If paper is not low and no conditions indicate that the print head is too hot, the power supply voltage is out of range. Contact a service representative.</p>	<p>See "Contacting a Service Representative" later in this chapter.</p>

Receipt Printing is Light or Spotty

Problem	What to Do	Where to Go
Thermal print head may be dirty	<p>Open the receipt cover and clean the thermal print head with cotton swabs and isopropyl alcohol.</p> <p>Caution: Do not use the alcohol to clean other parts of the printer. Damage will occur.</p> <p>Contact a service representative if this does not resolve the problem.</p>	<p>See "Cleaning the Printer" in chapter 2.</p> <p>See "Contacting a Service Representative" later in this chapter.</p>
<p>Note: The thermal print head does not normally require cleaning if the recommended paper grades are used. If non-recommended paper has been used for an extended period of time, cleaning the print head with the alcohol and cotton swabs will not be of much benefit. See "Ordering Thermal Paper" in chapter 1 for recommended paper.</p>		

Other Serious Problems

The following problems all need to be corrected by a qualified service representative. See the next section, "Contacting a Service Representative."

- Printer will not cycle or stop when required
- Illegible characters
- Paper will not feed
- Knife will not cycle or cut
- Printer will not communicate with Host

Contacting a Service Representative

For serious problems, such as the printer not printing, not communicating with the host computer, or not turning on, contact your NCR-authorized service organization to arrange for a service call. In addition to the service guide listed below, other service-related materials may be available. Contact your NCR-authorized service representative to obtain the service guide.

- 7198 Thermal Receipt Printer: Service Manual (B005-0000-1737)
(includes the Troubleshooting Guide and the Preventative Maintenance Guide)
- 7198 Thermal Receipt Printer: Parts Identification Manual (B005-0000-1738)
- 7198 Thermal Receipt Printer: Owners Manual (B005-0000-1736)

Chapter 4: Diagnostics

The following diagnostic tests are available for the 7198:

- **Level 0 Diagnostics (Startup)**
Performed during the startup cycle.
- **Level 1 Diagnostics (Printer Configuration)**
Allows configuration of the printer using a Configuration Menu that is printed on a receipt.
- **Level 2 Diagnostics (Runtime)**
The printer checks the status of these conditions during normal operation.
- **Level 3 Diagnostics (Remote)**
The printer keeps track of counters during normal operation.
- **Vendor Adjustment**
Performed in off-line mode. Allows to change settings for mechanical and perform printer test. Modifications of these settings are to be made by service personnel only.

Level 0 Diagnostics

The printer automatically performs level 0 diagnostics when it is put on-line. Level 0 diagnostics comprise the following actions:

- Motors are turned off.
- Microprocessor timing is checked, CRC check of the firmware ROM is performed, external RAM is read.
- The green LED flashes once if this action succeeds.
- Level 0 diagnostics stop if this action fails. Failure is indicated by the printer going dead: knife and print head do not home, LEDs are not lit, the printer is unable to communicate with the host computer.
- Knife is homed. A fault condition is caused if this action fails.
- The status of all sensors is checked, and the status bytes are updated.

If the printer has not been turned on before the default values for the printer functions will be loaded into the non volatile memory during level 0 diagnostics. These values can be changed in level 1 diagnostics. See "Level 1 Diagnostics" for the functions and their settings.

When the last step is complete, the Paper Feed button is enabled and the printer is ready for normal operation. Information about the tests is available to the communication interface through the commands.

Level 1 Diagnostics

Level 1 diagnostics (setup mode) allow you to change the settings for various printer functions and run certain tests.

Keep the following information in mind when changing the settings:

- The settings can only be changed when the printer is in level 1 diagnostics (setup mode): Switch 1 must be set to On and Switch 2 must be set to Off.
- The default options are set at the factory and are stored in the history non volatile memory.
- Once the settings have been changed and stored in the non volatile memory, the diagnostic setup is exited which saves the settings.

Caution: If you are changing the printer settings, be sure they are the correct settings for that particular function or test to avoid accidentally changing the settings for another function or test. If the settings are accidentally changed you must reenter the setup mode and reenter the correct settings. If you need assistance, contact a service representative. See "Contacting a Service Representative" in chapter 3.

Printer Configuration

Printers are generally shipped with all appropriate configuration settings pre-set at the factory. The only time the user should need to change the printer configuration is if a new option is installed, communication baud rate or the firmware is changed. It is also possible the user may need to run certain tests using the Configuration Menu.

The user configures the printer using a convenient Configuration Menu that is printed on receipt paper. The Configuration Menu prints instructions and setting options interactively as the user goes through the configuration process. The following functions and parameters can be changed with the scrolling Configuration Menu:


- Configuring the Printer
- Communication Interface
- Interface Type
- Baud Rate
- Number of Data Bits
- Number of Stop Bits
- Parity
- Flow Control
- Reception Errors
- Receive Buffer
- USB Interface type
- Setting Diagnostic Modes
- Off, Normal Mode
- Datascope Mode
- Receipt Test Mode
- Setting Emulation/Software Options
- Emulation
- Printer ID
- Default Lines Per Inch

- Carriage Return Usage
- Asian Mode
- Receipt Synchronization
- PDF417 Max Print Column
- Setting Hardware Options
- Print Density
- Maximum Power Option
- Paper Low Sensor
- Paper Width
- Set Knife Option
- Color Paper Option
- Power LED Control
- Setting Default Code Page
- Setting Double Side Printing
- Thermal Print Mode
- Upside Down
- Swap Front & Back Side
- Top/Bottom Message
- Reprint Message
- Minimum Receipt Length
- Reprint Error Page
- Setting EEPROM to default settings

Configuring the Printer

Use the Configuration Menu to select functions or change various settings as indicated in the preceding sections. The Configuration Menu prints instructions and setting options interactively as the user goes through the configuration process.

Caution: Be extremely careful in changing any of the printer settings to avoid changing settings that might affect the performance of the printer.



1. Set DIP Switch 1 to On, Switch 2 to Off.
2. Reset the printer while holding the Paper Feed Button, the printer will print the current configuration, then cuts the paper to print the Configuration Menu.
3. Press the Paper Feed Button to make the selections.

The instructions indicate whether to select something with a short click, a long click, or a series of short clicks. Indicate Yes with a long click, No with a short click.

Press and hold the Paper Feed Button for at least one second for a long click. Press the Paper Feed Button quickly for a short click.

4. When finished, set DIP Switch 1 to Off and reset printer.

Press the paper feed for the configuration you want.

Defaults are marked with asterisk (*).

***** **Main Menu** *****

Select a sub-menu:

EXIT	> 1 Click
Print Current Configuration	> 2 Clicks
Set Communication Interface	> 3 Clicks
Set Diagnostics Modes	> 4 Clicks
Set Emulation/Software	> 5 Clicks
Set Hardware Options	> 6 Clicks
Set Default Code page	> 7 Clicks
Set Double Side Modes	> 8 Clicks
Set EEPROM To Default Settings	> 9 Clicks

Enter code, then hold Button DOWN
 At least 1 second to validate

***** Diagnostics Form *****

Model number : 7198-1002-9001
 Serial number : 1234567890

Boot Firmware
 Revision : V11.00
 CRC : D3CE
 P/N : 497-0446068

Flash Firmware
 Revision : V35.00
 CRC : AC12
 P/N : 497-0446069

Hardware
 Flash Memory Size : 3 Mbytes
 Flash Logo Size : 256 Kbytes
 Flash Fonts Size : 64 Kbytes
 Flash User Storage : 64 Kbytes

Communication Interface
 Interface Type : RS232/USB
 Parameters
 Baud Rate : 19200
 Data Bits : 8
 Stop Bits : 1
 Parity : None
 Flow Control : DTR/DSR
 Reception Errors : Print '?'
 Receive Buffer : 4K Bytes
 DSR Signal : Enabled

Diagnostics Mode : OFF, Normal Mode

Emulation/Software
 Printer Emulation : 7194 Mode
 Printer ID Mode : 7194 Native ID
 Default LPI : 7.52
 Carriage Return : Use Print Cmd
 Asian Mode : On
 Receipt Sync. : Enabled
 PDF417 Max Columns : 14 Columns

Hardware
 Print Density : 100 %
 Max Power : 75W
 Paper Low Sensor : Enabled
 Paper Width : 80 mm
 Knife : Enabled
 Color Paper : Monochrome
 Power LED Control : Disabled
Paper Detection Sensor : Enabled

Code Pages
 Default Code Page : 437
 Resident code Pages : 437, 850, 852, 858, 860, 863, 862, 864, 865, 866, 874, 1252, Katakana + 932

Double Side Mode : Single Side
 Thermal Print Mode : Single Side
 Upside Down : Single Side
 Front Side : Normal
 Back Side : Up Down
 Swap Side : Disable
 Top/Bottom Msg : Disable
 Btm of Front : Disable
 Top of Back : Enable
 Reprint Msg : Disable
 Min Rcpt Length : Disable
 Reprint Error Page : Off

Top/Btm Msg Defined : No
 Reprint Msg defined : No
 PreDfn Back Defined : No
 Logo(s) defined : No
 User Char(s) defined : No

Sensor Level (On, Off, TH)
Paper Detect Sensor : 2.9V, 0.2V, 1.5V

User Tallies
 Receipt Lines Front : 389482
 Receipt Lines Back : 188470
 Knife Cuts : 12768
 Hours ON : 959
 Flash cycles : 5
 Knife Jams : 2
 Cover Openings : 71
 Max Temp Reached : 363

Permanent Tallies
 Receipt Lines Front : 389482
 Receipt Lines Back : 188470
 Knife Cuts : 12768
 Hours ON : 959
 Flash cycles : 5
 Knife Jams : 2
 Cover Openings : 71
 Max Temp Reached : 363

To enter Diagnostics Mode:
 1) Flip DIP switch #1 on.
 2) Reset the printer by pressing and holding Receipt Feed switch down while disconnecting and reconnecting the power.

Important: Ensure that the configuration settings match your host computer, if not, enter the Configuration Menu to make changes.

Configuration Menu and Print Test samples (show approximately 60% of size).

Communication Interface Modes

The Configuration Menu gives the user the option of setting the printer to use an RS-232C serial port. (See "Configuring the Printer" for instructions on how to enter the Configuration Menu.)

Interface Settings

If the user sets the printer to use an RS-232C serial interface, the Configuration Menu can be used to set the following RS-232C specific settings:

- Set a baud rate 115200, 57600, 38400, 19200, 9600 baud
- Set the number of data bits to seven or eight
- Set the number of stop bits to one or two
- Enable or disable parity
- Set flow control to software (XON/XOFF) or Hardware (DTR/DSR)
- Set the printer to ignore data errors or print a "?" upon encountering an error
- Set receive buffer size to 4K byte or one line
- Set USB Interface type to NHPI or PRTR

The settings used will depend on the software the operator is using and the capabilities of the host computer.

Press the paper feed button for the communications settings you want.

Defaults are marked with asterisks (*).

** SET INTERFACE TYPE ?

YES > Long Click
NO > Short Click

RS232/USB* > 1 Click
RS232 > 2 Clicks
USB > 3 Clicks

Enter code, then hold Button Down

At least 1 second to validate

** SET BAUD RATE ?

YES > Long Click
NO > Short Click

115200 Baud > 1 Click
57600 Baud > 2 Clicks
38400 Baud > 3 Clicks
19200 Baud > 4 Clicks
9600 Baud* > 5 Clicks

Enter code, then hold Button DOWN

At least 1 second to validate

**** SET NUMBER OF DATA BITS ?**

YES > Long Click
 NO > Short Click

8 Data Bits* > Long Click
 7 Data Bits > Short Click

**** SET NUMBER OF STOP BITS ?**

YES > Long Click
 NO > Short Click

1 Stop Bits* > Long Click
 2 Stop Bits > Short Click

**** SET PARITY ?**

YES > Long Click
 NO > Short Click

No Parity* > 1 Click
 Even Parity > 2 Clicks
 Odd Parity > 3 Clicks
 Enter code, then hold Button DOWN
 At least 1 second to validate

**** SET FLOW CONTROL METHOD ?**

YES > Long Click
 NO > Short Click

Software (XON/XOFF) > Long Click
 Hardware (DTR/DSR)* > Short Click

**** SET DATA RECEPTION ERRORS OPTION ?**

YES > Long Click
 NO > Short Click

Ignore Errors > Long Click
 Print '?'* > Short Click

Note: Press the Paper Feed Button for at least one second to validate the selection.

Receive Buffer Size Option

This function allows the user to set the buffer size to a single line or a 4 K buffer.
 Press the Paper Feed Button for the option you want.

**** SET RECEIVE BUFFER SIZE ?**

YES > Long Click
 NO > Short Click

4K Buffer* > Long Click
 One Line > Short Click

Note: Press the Paper Feed Button for at least one second to validate the selection.

**** SET DSR IGNORE FUNCTION ?**

YES > Long Click
 NO > Short Click

Enabled* > Long Click
 Disabled > Short Click

Note: Press the Paper Feed Button for at least one second to validate the selection.

**** SET USB INTERFACE TYPE ?**

YES > Long Click
 NO > Short Click

NHPI* > 1 Click
 PRTR > 2 Click

Note: Press the Paper Feed Button for at least one second to validate the selection.

USB Interface Type is shown on Non ION USB version only.

ION USB version doesn't show this setting.

If Non ION USB version firmware is downloaded to ION USB version printer, EEPROM value doesn't match the version. In this case, firmware should change the value as follows.

Previous EEPROM Value	New EEPROM value for ION USB version	New EEPROM value for Non ION USB version
00 (EPiC)	00 (EPiC)	01 (NHPI)
01 (NHPI)	00 (EPiC)	01 (NHPI)
02 (PRTR)	00 (EPiC)	02 (PRTR)

The default value of EEPROM is

ION USB version : 0x00 (EPiC)

Non ION USB version : 0x01 (NHPI)

Save Parameters

This function allows to save the selected communication settings or return to the communication settings to select additional options.

Press the Paper Feed Button for the option you want.

Save new parameters ?

YES > Long Click

NO, MODIFY > Short Click

Diagnostic Modes

This function allows the user to put the printer into the following diagnostic modes:

- OFF, Normal Mode: this is the normal operating mode of the printer.
- Datascope Mode: the receipt printer prints incoming commands and data in hexadecimal format.
- Receipt Test Mode: the receipt printer prints two code pages.

The diagnostic modes are enabled or disabled by using the Configuration Menu. See "Configuration the Printer," for instructions on how to enter the Configuration Menu.

Press the Paper Feed Button for the diagnostic mode you want.

**** SET DIAGNOSTICS MODE ?**

YES > Long Click

NO > Short Click

OFF, Normal Mode* > 1 Click

Data Scope Mode > 2 Clicks

Receipt Test Mode > 3 Clicks

Enter code, then hold Button DOWN

At least 1 second to validate

Enter code, then hold Button DOWN

At least 1 second to validate

Datascope Mode

Datascope Mode allows the user to test the printer's communications. When in Datascope Mode the printer receives all communications, but instead of executing the commands it prints them out on receipt paper as hexadecimal numbers in the order received. For example, the ASCII character "A" is printed as the hexadecimal number 41 and so on.

To run the Datascope Mode:

1. After you have enabled the Datascope Mode through the Configuration Menu, exit the Configuration Menu.
2. Run a transaction from the host computer.

All commands and data sent from the host computer will be printed as hexadecimal numbers as shown in the illustration.

```
30 31 32 33 34 35 36 37 38 39 40 41      :      0 1 2 3 4 5 6 7 8 9 @ A
41 42 43 44 45 46 47 48 49 50 51 52      :      A B C D E F G H I J K L
```

To exit the Datascope Mode:

1. Enter the Configuration Menu again
2. Disable the Datascope Mode
3. Exit the Configuration Menu

The printer is in Normal Mode and can communicate with the host computer.

Receipt Test Mode

To run the Receipt Test Mode:

1. Enable the Receipt Test Mode through the Configuration Menu. See "Configuring the Printer," for instructions on how to enter the Configuration Menu.
2. Push Paper Feed Button and the receipt station will print all code pages.
3. The test ends with a cut.
4. Go to step 2 again to repeat this test.

To exit the Receipt Test Mode:

1. Enter the Configuration Menu again.
2. Disable the Receipt Test Mode
3. Exit the Configuration Menu

The printer is in Normal Mode and can communicate with the host computer.

Save Parameters

This function allows to save the selected diagnostics modes or return to the diagnostics mode to select additional options.

Press the Paper Feed Button for the option you want.

Save Parameters

This function allows to save the selected communication settings or return to the communication settings to select additional options.

Press the Paper Feed Button for the option you want.

Save new parameters ?

YES > Long Click

NO, MODIFY > Short Click

Emulation/Software Options

Printer Emulations

Printer emulations determine the commands that are available to the printer. They are set by using the Configuration Menu. (See "Configuring the Printer," for instructions on how to enter the Configuration Menu.). The available options are:

- 7194 Mode

- 7193 Mode
- 7197 Native Mode

Press the Paper Feed Button for the emulation you want.

**** SET EMULATION ?**

YES > Long Click
NO > Short Click

7194 Mode* > 1 Click
7193 Mode > 2 Click
7197 Native Mode > 3 Click
Enter code, then hold Button DOWN
At least 1 second to validate

Note: Press the Paper Feed Button for at least one second to validate the selection.

Printer ID Selections

Printer ID Selections determines the print ID that is returned from the printer. This is set by using the Configuration Menu. (See "Configuring the Printer," for instructions on how to enter the Configuration Menu.). The available options are:

- 7197 Native ID
- Emulated Print ID
- 7197 Native ID

Press the Paper Feed Button for the emulation you want.

**** SET PRINTER ID MODE ?**

YES > Long Click
NO > Short Click

7194 Native ID* > 1 Click
Emulated Printer ID > 2 Clicks
7197 Native ID > 3 Clicks
Enter code, then hold Button DOWN
At least 1 second to validate

Note: Press the Paper Feed Button for at least one second to validate the selection

Default Lines per Inch

This function allows the user to set the default lines per inch printed by the thermal printer to 6, 7.52 or 8.13. (See "Configuring the Printer" for instructions on how to enter the Configuration Menu to change this setting.)

Press the Paper Feed Button for the lines per inch you want.

** SET DEFAULT LINES PER INCH ?

YES > Long Click
NO > Short Click

8.13 Lines per Inch > 1 Click
7.52 Lines per Inch* > 2 Clicks
6 Lines per Inch > 3 Clicks

Enter code, then hold Button DOWN
At least 1 second to validate

Note: Press the Paper Feed Button for at least one second to validate the selection.

Carriage Return Usage

This function allows the printer to ignore or use the Carriage Return (hexadecimal 0D) command depending on the application. Some applications expect the command to be ignored while others use the command as a print command. (See "Configuring the Printer" for instructions on how to enter the Configuration Menu to change this setting.)

Press the Paper Feed Button for the carriage return usage you want.

** SET CARRIAGE RETURN USAGE ?

YES > Long Click
NO > Short Click

Ignore CR > Long Click
Use CR as Print Cmd* > Short Click

Note: Press the Paper Feed Button for at least one second to validate the selection.

Asian Mode

This function makes it possible for the user to select an Asian character for the printer. (See "Configuring the Printer" for instructions on how to enter the Configuration Menu to change this setting.)

Note: For Asian code pages, only one (either 932, 936, 949 or 950) will exist in the firmware.

Press the Paper Feed Button for the Asian mode you want.

** SET ASIAN MODE ?

YES > Long Click

NO > Short Click

Asian Mode On > Long Click

Asian Mode Off* > Short Click

Note: Press the Paper Feed Button for at least one second to validate the selection.

Receipt Synchronization Mode

The standard mode for synchronization allows for verification of each line printed to the host. When the receipt synchronization is disabled the printer will allow for maximum print speed and ignore the verification of each line printed.

Press the Paper Feed Button for the receipt synchronization mode option you want.

** SET RECEIPT SYNCHRONIZATION MODE ?

YES > Long Click

NO > Short Click

Enable Receipt Sync.* > Long Click

Disable Receipt Sync. > Short Click

Note: Press the Paper Feed Button for at least one second to validate the selection.

SET PDF417 MAX PRINT COLUMN

This function makes it possible for the user to select the print columns for the PDF417 bar code printing. The selections are 9 or 14 columns. The end result is the height of the bar code printing. The default setting is 9 columns. (See Configuring the Printer for instructions on how to enter the Configuration Menu to change this setting.)

** SET PDF417 COLUMN PRINT ?

YES > Long Click

NO > Short Click

9 Columns* > 1 Click

14 Columns > 2 Clicks

Enter code, then hold Button DOWN at least 1 second to validate.

Save Parameters

This function allows to save the selected emulations/software settings or return to the emulations/software settings to select additional options.

Press the Paper Feed Button for the option you want.

Save new parameters ?

YES > Long Click

NO, MODIFY > Short Click

Hardware Options

Print Density

This function makes it possible to adjust the energy level of the print head to darken the printout. An adjustment should only be made when necessary. The factory setting is 100%.

Warning: Choose an energy level no higher than necessary to achieve a dark printout.

Failure to observe this rule may result in a printer service call or voiding of the printer warranty. Consult your NCR technical support specialist if you have any questions.

Press the Paper Feed Button for the print density you want.

** SET PRINT DENSITY ?

YES > Long Click
NO > Short Click

100 %* > 1 Click
110 % > 2 Clicks
120 % > 3 Clicks

Enter code, then hold Button DOWN
At least 1 second to validate

Note: Press the Paper Feed Button for at least one second to validate the selection.

Maximum Power Option

This function allows the user to set the maximum power for the printer to 75W or 55W.

Press the Paper Feed Button for the option you want.

** SET MAX POWER OPTION ?

YES > Long Click
NO > Short Click

55W Power Supply* > Long Click
75W Power Supply > Short Click

Note: Press the Paper Feed Button for at least one second to validate the selection.

Paper Low Sensor

Paper Low Sensor makes it possible to enable or disable the paper low sensor for particular printer configurations.

Press the Paper Feed Button for the option you want.

** SET PAPER LOW SENSOR OPTION ?

YES > Long Click
NO > Short Click

Enable Paper Low Sensor* > Long Click
Disable Paper Low Sensor > Short Clicks

Note: Press the Paper Feed Button for at least one second to validate the selection.

Paper Width

This function allows the user to set the default paper width for the receipt thermal printer to 58mm or 80mm wide.

Press the Paper Feed Button for the paper width option you want.

** SET PAPER WIDTH ?

YES > Long Click
NO > Short Click

Paper Width = 80 mm* > 1 Click
Paper Width = 58 mm > 2 Clicks

Enter code, then hold Button DOWN
At least 1 second to validate

Note: Press the Paper Feed Button for at least one second to validate the selection.

Set Knife Option

Set the Knife option using the configuration menu. Answer No to the questions printed on the receipt until you come to the instructions for knife option.

Caution: Be extremely careful changing any of the printer settings to avoid inadvertently changing other settings that might affect the performance of the printer.

Press the Paper Feed Button for the option you want.

** SET KNIFE OPTION ?

YES > Long Click
NO > Short Click

Enable Knife* > Long
 Disable Knife > Short

Color Paper Option

This function allows the user to set the color paper option to Monochrome or Color Paper.

Press the Paper Feed Button for the option you want.

** SET COLOR PAPER OPTION ?

YES > Long Click
 NO > Short Click

Monochrome* > Long Click
 Color Paper > Short Click

Note: Press the Paper Feed Button for at least one second to validate the selection.

Set Power LED Control

This function allows the user to set the power LED control.

- When Enable is selected, printer checks DSR line for LED control. If DSR is BUSY, printer turns off LED even if printer is in error condition.
- When Disable is selected, printer doesn't check DSR line for LED control.

Press the Paper Feed Button for the option you want.

** SET POWER LED CONTROL OPTION ?

YES > Long Click
 NO > Short Click

Disable Control* > Long Click
 Enable Control > Short Click

Note: Press the Paper Feed Button for at least one second to validate the selection

Save Parameters

This function allows to save the selected hardware settings or return to the hardware options to select additional options.

Press the Paper Feed Button for the option you want.

Save new parameters ?

YES > Long Click
 NO, MODIFY > Short Click

Default Code Page

This function makes it possible to select the default code page.

These are the code pages available for printing:

- Code page 437 (US English)
- Code page 850 (Multilingual)
- Code page 852 (Slavic)
- Code page 858 (with Euro symbol)
- Code page 860 (Portuguese)
- Code page 862 (Hebrew)
- Code page 863 (French Canadian)
- Code page 864 (Arabic)
- Code page 865 (Nordic)
- Code page 866 (Cyrillic)
- Code page 874 (Thai)
- Code page 1252 (Windows Latin #1)
- Code page Katakana
- Code page 932 (MS Japan)
- Space page

Note: For Asian code pages, code page 936, 949, or 950 replaces code page 932. Only one Asian code page (either 932, 936, 949, 950) will exist in firmware.

Press the Paper Feed Button for the Default Code Page you want.

** SET CODE PAGE ?

YES > Long Click
NO > Short Click

Code Page 437* > 1 Click
Code Page 850 > 2 Clicks
Code Page 852 > 3 Clicks
Code Page 858 > 4 Clicks
More Options > 5 Clicks

Enter code, then hold Button DOWN
At least 1 second to validate

Code Page 860 > 1 Click
Code Page 862 > 2 Clicks
Code Page 863 > 3 Clicks
Code Page 864 > 4 Clicks
More Options > 5 Clicks

Enter code, then hold Button DOWN
At least 1 second to validate

Code Page 865 > 1 Click

Code Page 866	> 2 Clicks
Code Page 874	> 3 Clicks
Code Page 1252	> 4 Clicks
More Options	> 5 Clicks

Enter code, then hold Button DOWN
At least 1 second to validate

Code Page Katakana	> 1 Click
Code Page 932	> 2 Clicks

Enter code, then hold Button DOWN
At least 1 second to validate

Note: Press the Paper Feed Button for at least one second to validate the selection. For Asian code pages, code page 936, 949 or 950 replaces code page 932 in the above shown menu. Only one Asian code page (Either 932, 936, 949 or 950) will exist in firmware.

Save Parameters

This function allows to save the selected default code page selection or return to the default code page selection to select additional options. Press the Paper Feed Button for the option you want.

Save new parameters ?

YES	> Long Click
NO, MODIFY	> Short Click

Double Side Printing Settings

Set the double side printing settings using the Configuration Menu.

Caution: Be extremely careful changing any of the printer settings to avoid inadvertently changing other settings that might affect the performance of the printer.

Press the Paper Feed Button for the double side printing settings you want.

Defaults are marked with an asterisk (*).

Set Thermal Print Mode

This setting allows the user to select double side printing mode.

Press the Paper Feed Button for the option you want.

** SET THERMAL PRINT MODE ?

YES > Long Click

NO > Short Click

Single Side* > 1 Click

Double Side w/Single Cmd > 2 Clicks

Double Side w/Double Cmd > 3 Clicks

Double Side w/ Predfn Back > 4 Clicks

Enter code, then hold Button Down at least 1 second to validate.

Set Upside Down

This setting allows the user to select upside-down character printing for each side in double side printing.

Press the Paper Feed Button for the option you want.

** SET UPSIDE DOWN ?

YES > Long Click

NO > Short Click

F:Normal, B:Normal* > 1 Click

F:Up Down, B:Normal > 2 Clicks

F:Normal, B:Up Down > 3 Clicks

F:Up Down, B:Up Down > 4 Clicks

Enter code, then hold Button DOWN at least 1 second to validate.

Set Swap Front & Back Side

This setting allows the user to exchange front side data and back side data.

Press the Paper Feed Button for the option you want.

**** SET SWAP FRONT&BACK SIDE ?**

YES > Long Click

NO > Short Click

Disable* > 1 Click

Enable > 2 Clicks

Enter code, then hold Button DOWN at least 1 second to validate.

Set Top/Bottom Message

This setting allows the user select whether Top/Bottom messages are disabled or enabled.

Press the Paper Feed Button for the option you want.

**** SET TOP/BOTTOM MSG ?**

YES > Long Click

NO > Short Click

Top:Disable,Btm:Disable* > 1 Click

Top:Disable,Btm:Enable > 2 Clicks

Top:Enable, Btm:Disable > 3 Clicks

Top:Enable, Btm:Enable > 4 Clicks

Enter code, then hold Button DOWN at least 1 second to validate.

Set Reprint Message

This setting allows the user to select whether Reprint message is disabled or enabled. The printer allows for predefining of a message on the front side of the receipt. The printing of the lines are enabled as shown in the chart below.

Press the Paper Feed Button for the option you want.

** SET REPRINT MSG?

YES > Long Click

NO > Short Click

Disable* > 1 Click

Enable > 2 Clicks

Enter code, then hold Button DOWN

At least 1 second to validate

Set Minimum Receipt Length

This setting allows the user to select minimum receipt length.

Press the Paper Feed Button for the option you want.

** SET MIN RECEIPT LENGTH ?

YES > Long Click

NO > Short Click

Disable* > 1 Click

5 inch > 2 Clicks

10 inch > 3 Clicks

15 inch > 4 Clicks

Enter code, then hold Button DOWN at least 1 second to validate.

Set Reprint Error Page

This setting allows the user to execute reprint error page data.

Press the Paper Feed Button for the option you want.

** SET REPRINT ERROR PAGE ?

YES > Long Click

NO > Short Click

Resume Print from Error > 1 Click

Reprint Error Page > 2 Clicks

Enter code, then hold Button DOWN at least 1 second to validate.

Save Parameters

This function allows to save the selected communication settings or return to the communication settings to select additional options.

Press the Paper Feed Button for the option you want.

Save new parameters ?

YES > Long Click

NO > Short Click

EEPROM to Default Settings

This selection resets the configuration to the Default Settings.

Caution: Be extremely careful changing any of the printer settings to avoid inadvertently changing other settings that might affect the performance of the printer.

**** RESET EEPROM TO DEFAULT VALUES ?**

YES > Long Click

NO > Short Click

Note: Press the Paper Feed Button for at least one second to validate the selection.

Save Parameters

This function allows to save the selected default code page selection or return to the default code page selection to select additional options.

Press the Paper Feed Button for the option you want.

Save new parameters ?

YES > Long Click

NO, MODIFY > Short Click

Mfg. Adjustment

This selection provides Receipt Printing Test only since adjustments are not necessary. To perform the printer test, use the Mfg Adjustment menu feature. This feature prints instructions on the receipt for selecting any type of print pattern needed.

Mfg Adjustment:

Caution:

Be extremely careful when changing any of the printer settings to avoid changing other settings that might affect the performance of the printer.

1. Set DIP switch 1 to ON, DIP switch 2 to ON.
2. Power on the printer while holding the Paper Feed Button. The printer will print the Current Setting Form, then cuts the paper to print the Mfg Adjustment Menu.
3. If you do not hold the Paper Feed Button while power up the printer, it will go to Online Mode.

This menu allows you to print different test patterns

Selections are made using the Paper Feed Button.

===== Mfg Adjustment Menu =====

Select a sub-menu:

EXIT	> 1 Click
Rolling ASCII Print Test	> 2 Clicks
H Print Test	> 3 Clicks
Duty Check Print Test	> 4 Clicks
Print Current Setting	> 5 Clicks
Sensor Calibration (Rcpt)	> 6 Clicks
Reset all EEPROM to Default	> 7 Clicks

Enter code then hold Button DOWN
At least 1 second to validate.

Rolling ASCII print test (Receipt)

This option let you run rolling ASCII printing test. The printer prints the resident character set in standard pitch continuously. When Rolling ASCII Print (Rcpt) is selected, printer prints the following menu. After selection of the printing side, test print will start.

**** SELECT PRINTING SIDE?**


- Front Side Only > 1 Click
- Back Side Only > 2 Click
- Double Side > 3 Click

Enter code, then hold Button DOWN at least 1 second to validate

Press the Paper Feed Button to stop the test.

Rolling ASCII

- Stop and exit test > Long Click



H print test (Receipt)

This option let you run H printing test. The printer prints the 'H' character in standard pitch continuously. When H Print Test (Rcpt) is selected, printer prints the following menu. After selection of the printing side, test print will start.

Press the Paper Feed Button to start or stop the test.

** SELECT PRINTING SIDE?

Front Side Only > 1 Click

Back Side Only > 2 Click


Double Side > 3 Click

Enter code, then hold Button DOWN at least 1 second to validate.

Press the Paper Feed Button to stop the test.

H Print test

Stop and exit test -> Long Click



Duty check print test (Receipt)

This option let you run duty check printing test. The printer prints the 12.5%, 25%, 50% and 100% duty original pattern. When Duty Check Print (Rcpt) is selected, printer prints the following menu. After selection of the printing side, test print will start.

Press the Paper Feed Button to start or stop the test.

** SELECT PRINTING SIDE?

Front Side Only > 1 Click


Back Side Only > 2 Click

Double Side > 3 Click

Enter code, then hold Button DOWN at least 1 second to validate.

Press the Paper Feed Button to continue or stop the test.

Duty Check Print
 Stop and exit test > Short Click
 Continue test > Long Click



Print current setting


This option let you print current setting on receipt.

Press the Paper Feed Button to start the test.

** START CURRENT SETTING PRINTING?

Return Main Menu > Short Click
 Start Printing > Long Click

Note: Press the Paper Feed Button for at least one second to validate the selection.



Sensor Calibration (Rcpt)

This option calibrates Double side paper detection sensor.

** START SENSOR CALIBRATION?

Return Main Menu > Short Click

Start Printing > Long Click

If error occurs during sensor calibration, the value in the Printer Configuration will become 0000.

EEPROM to Default Setting

This selection resets the configuration & clears all input data to the Default Settings.

Caution: Don't perform this selection unless you want to clear all details in EEPROM to default value. Be extremely careful changing any of the printer settings to avoid inadvertently changing other settings that might affect the performance of the printer.

** RESET EEPROM TO DEFAULT VALUES ?

YES > Long Click

NO > Short Click

Procedure:

1. Enable the EEPROM to Default Setting option through the Configuration Menu; enter a short click to return to the Mfg Adjustment Menu.
2. Enter a Long Click to reset the EEPROM to the Default Values.
3. Enter a Short Click to return to the Mfg Adjustment Menu without resetting to the default values.

Note: Press the Paper Feed Button for at least one second to validate the selection.

Where to save the setting of Double Side Mode

Parameter	Size	Where	Remark
Thermal Printing Mode	2 bits	EEPROM	
Upside Down Mode	2 bits	EEPROM	
Swap Front & Back	1 bit	EEPROM	
Bottom and Top Message	2 bits	EEPROM	
Reprint when Error Occur	1 bit	EEPROM	
Minimum Receipt Length	1 bytes	EEPROM	
Pre-defined Top and Bottom message	1024 bytes	Flash ROM	
Pre-defined Back Side printing	4096 bytes	Flash ROM	
Macro	50 Kbytes	Flash ROM	50 Kbytes is shared by 25 Macros
Serial Number	10 bytes	Flash ROM	Change from EEPROM to Flash
Model Name	15 bytes	Flash ROM	Change from EEPROM to Flash

Level 2 Diagnostics

Level 2 diagnostics run during normal printer operation. When the following conditions occur, the printer automatically turns off the appropriate motor, disables printing to prevent damage, and turns on the green LED (flashes the green LED if the receipt print head is too hot or the voltages are out of range):

- Paper out
- Cover open
- Knife unable to go back to home position
- Print head too hot
- Power supply voltage out of range

See “Chapter 3: Solving Problems” for more information about other conditions that may occur and how to correct them.

Status	LED Behavior
Power Off	Off
Firmware Download	Very Fast Blink
Level 0 Diagnostics	No Blink
Receipt Paper Low	Slow Blink
Temperature Error	No Blink
Voltage Error	No Blink
Cover Open	Fast Blink
Receipt Paper Out	Fast Blink
Knife Jam	Fast Blink, then Slow Blink
All other states	On

Level 3 Diagnostics

Level 3 diagnostics keeps track of the following tallies and prints them on the receipt during the receipt test.

- Serial number
- Model number
- CRC number
- Number of receipt lines printed
- Number of knife cuts
- Number of hours printer is on
- Number of flash cycles
- Maximum temperature reached
- Number of cutter jams
- Number of times the door is open

Chapter 5: Communication

Communication Overview

In order for a receipt to be printed, a program must be in place that translates the data from the host computer into a language that the printer can understand. This program must tell the printer exactly how to print each character. This chapter describes how to create such a program or modify an existing one.

Interface

In order for the printer to communicate with the host, a communication link must be set up. The 7198 supports the industry standard RS-232C communication interface. This interface has a protocol associated with it that the host computer must understand and adhere. The printer also supports USB communications.

Only when the interface parameters are matched and the proper protocol is used will the host and the printer be able to communicate. See the section, "RS-232C Interface" on the next page for a description of the protocol associated with the RS-232C interface.

Sending Commands

Once the communication link is established, commands can be sent to the printer. This section describes how to send commands to the printer using DOS and BASIC. This section does not take into account the necessary protocol, but is meant as a general introduction to how the printer functions.

Using DOS to Send Commands

One way of getting commands to the printer is to send them directly from DOS. For example, the command

```
COPY CON: COM1:
```

This sets the computer up such that the Hex code corresponding to any key that was pressed would be sent to the RS-232C communication port COM1 when the COPY mode is exited. If the printer is connected to COM1, then the data will go to the printer.

Exit the COPY mode by typing

```
CTRL Z
```

and then pressing the ENTER key. This directs the data from any print command to the proper port, commands can be sent from any software program.

Using BASIC to Send Commands

In BASIC, printer commands are sent as a string of characters preceded by the LPRINT command. For example,

```
LPRINT CHR$( &H0A)
```

sends the hexadecimal number 0A to the printer, which causes the printer to print the contents of its print buffer. Previously sent commands tell the printer exactly how this data should appear on the paper. For example,

```
LPRINT CHR$( &H12); "ABC"; CHR$( &H0A)
```

sends the Hex numbers 12 41 42 43 0A to the printer. This causes the printer to set itself to double wide mode (12), load the print buffer with "ABC" (41 42 43), and finally, print (0A). Again, the communication link that the BASIC program outputs to must be matched to that of the printer.

RS-232C Interface

The RS-232C interface uses either XON/XOFF or DTR/DSR protocol. For XON/XOFF, a particular character is sent back and forth between the host and the printer to regulate the communication. For DTR/DSR, changes in the DTR/DSR signal coordinate the data flow.

The RS-232C version of the 7198 offers the standard options which are selectable in the Diagnostic mode. See "Diagnostics: Communications Interface Settings" later in this book.

Print Speed and Timing

The fast speed of the printer requires the application to send data to the printer at least as fast as it is printed. This application must also allow receipt lines to be buffered ahead at the printer, so the printer can print each line immediately after the preceding line, without stopping to wait for more data. Ideally, the application will send all the data for an entire receipt without pausing between characters or lines transmitted.

If the application sends data at 9600 baud and pauses between lines for as little as 50 milliseconds, the printer will never be able to print at full speed. But, if the application sends data at 19.2 K baud and does not pause between lines, the printer will be able to print at its full speed of 1020 lines/minute.

The table shows that with a pause of 50 milliseconds after each line, the transmit time equals or exceeds the print time, slowing down the printer, regardless of the baud rate.

Char. /Line	Lines/Receipt	Transmit Time: (9600 Baud)	Print Time (9600 Baud)	Transmit Time: (19.2 K Baud)	Print Time (19200 Baud)
20	20	0.84 Seconds	1.76 Seconds	0.70 Seconds	1.51 Seconds
20	40	1.69 Seconds	3.51 Seconds	1.34 Seconds	3.01 Seconds
44	20	1.86 Seconds	1.76 Seconds	1.53 Seconds	1.51 Seconds
44	40	3.71 Seconds	3.51 Seconds	3.07 Seconds	3.01 Seconds

The next table shows that with no delay between lines, the transmit time is much less than the print time, allowing the printer to print at full speed.

Char. /Line	Lines/Receipt	Transmit Time: (9600 Baud)	Print Time (9600 Baud)	Transmit Time: (19.2 K Baud)	Print Time (19200 Baud)
20	20	0.43 Seconds	0.98 Seconds	0.21 Seconds	0.72 Seconds
20	40	0.86 Seconds	1.95 Seconds	0.43 Seconds	1.43 Seconds
44	20	0.95 Seconds	0.98 Seconds	0.47 Seconds	0.72 Seconds
44	40	1.89 Seconds	1.95 Seconds	0.93 Seconds	1.43 Seconds

XON/XOFF Protocol

The XON/XOFF characters coordinate the information transfer between the printer and the host computer. The printer sends an XON character when it is ready to receive data and it sends an XOFF character when it cannot accept any more data. The software on the host computer must monitor the communication link as shown in the following flowchart in order to send data at the appropriate times.

If XON/XOFF has been selected, the printer also toggles the DTR signal, as described in the next section, but it does not look at the DSR signal to transmit data.

XON character = Hex 11.

XOFF character = Hex 13.

DTR/DSR Protocol

The DTR signal is used to control data transmission to the printer. It is driven low when the printer is ready to receive data and driven high when it cannot accept any more data. Data is transmitted from the printer after it confirms that the DSR signal is low.

RS-232C Technical Specifications

This section describes the pin settings for the connectors and the RS-232C interface parameters. The RS-232C parameters are selectable in the Diagnostic mode. See "Diagnostics: Communications Interface Settings" in chapter 4 for the position of the DIP switches. The RS-232C parameters must match those of the host.

RS 232 Connector

The illustration shows the RS-232C communication connector and pin assignments. The connector is a 9-pin male D-shell connector and is located in the hollow cavity under the printer at the rear.

DC Power Connector

The illustration shows the power cable connector and pin assignments. The power cable connector is a 3-pin DIN plug and is located in the hollow cavity under the printer at the rear.


Cash Drawer Connector

The following illustration shows the pin out designation for the cash drawer connectors. The following table provides the pinout assignments for cash drawers one and two. The cash drawer connectors are located at the rear of the printer.

Pin Number	Cash Drawer 1 Connector
1	Frame Ground
2	Drawer 1 Solenoid
3	Drawer 1 Status Switch
4	+24 Volts (to Solenoid +)
5	Drawer 2 Solenoid
6	Ground (Status Switch Return)

USB Connector

The following illustration is for the USB Type B communication connector and pin assignment.



Pin No	Signal
1	+5 V – USB
2	Data -
3	Data +


4 **Ground**

Switch Settings

The DIP switches are located on the PC board at the bottom of the printer as shown in the illustration in “Level 1 Diagnostics” in chapter 4.

The switches are used to put the printer into various modes for printer configuration set up.

Printer Bottom View



Use a paper clip or other pointed object to set the switches.

1. Set the switches to the desired settings shown in the table.

Caution: Do not set switch 1 to On. Setting switch 1 to On puts the printer in level 1 diagnostics (setup mode) where other functions and tests can be changed.

DIP Switch Settings

Switch 1 Setting	Switch 2 Setting	Printer State
OFF (0)	OFF (0)	On-line Mode (default)
ON (1)	OFF (0)	Diagnostic Mode
OFF (0)	ON (1)*	Flash Download Mode
ON (1)	ON (1)	Vendor Adjustment Mode

* It is optional to set this switch to ON when reflashing the IPL firmware.

Setting Extra RS-232C Options

The following extra options are available for the RS-232C Interface:

- Data errors
- Print “?” for data errors (default)
- Ignore data errors

Chapter 6: Commands

Command Conventions

Introduction

The different features and functions provided by the printer are controlled by sending commands from the host computer to the printer. This section describes the commands that are supported by the printer. The printer commands are made up of one or more bytes of data starting with a command control code followed by its supporting parameters.

Commands control all operations and functions of the printer. This includes selecting the size and placement of characters and graphics on the receipt or the slip and feeding and cutting the paper. Unless otherwise noted, any of the commands may be used in any combination to communicate with the printer from a program in a host computer.

In order to allow the graceful handling of commands that may be available in other printers but are not available in this printer, some commands will be listed and described but identified as "not implemented." If the printer receives one of these "not implemented" commands, the command and its supporting operands will be discarded. Any other data bytes, including unrecognized commands, are sent to the print buffer as data, and the printer will attempt to print the data when it is instructed to print the buffer.

List of Commands and Location

This section presents groups of lists of the hexadecimal command codes, parameters, and the command names. A page reference is provided for the page on which the command is more fully described. If this document is being viewed online, the page reference will be linked to the actual page and may click to go to that page.

The first section lists all of the commands. The following lists are separated into functional category groupings.

All commands **listed in bold** are new or have additional functionality when compared to the NCR 7193.

By Command Code

Code (Hexadecimal)	Command	Page
09 (HT)	Horizontal Tab	114
0A (LF)	Print and Feed Paper One Line	108
0C (FF)	Print and Return to Standard Mode	179
0D (CR)	Print and Carriage Return	108
10	Clear Printer	102
10 04 n	Real Time Status Transmission (DLE Sequence)	163
10 05 n	Real Time Request to Printer (GS Sequence)	166
11 <i>n1... nk</i>	Print Raster Graphics	140
12	Select Double-Wide Characters	121
13	Select Single-Wide Characters	121
14 <i>n</i>	Feed <i>n</i> Print Lines	109
15 <i>n</i>	Feed <i>n</i> Dot Rows	109
16 <i>n</i>	Add <i>n</i> Extra Dot Rows	110
17	Print	111
18	Cancel Print Data in Page Mode	179
19	Perform Full Knife Cut	103
1A	Perform Partial Knife Cut	103
1B (+ *.bmp)	Download BMP Logo	140
1B 07	Generate Tone	104
1B 0C	Print Data in Page Mode	180
1B 12	Select 90 Degree Counter-Clockwise Rotated Print	121
1B 14 <i>n</i>	Set Column	114
1B 16 <i>n</i>	Select Pitch (Column Width)	123
1B 20 <i>n</i>	Set Character Right-Side Spacing	124
1B 21 <i>n</i>	Select Print Modes	125
1B 24 <i>n1 n2</i>	Set Absolute Starting Position	115
1B 25 <i>n</i>	Select or Cancel User-Defined Character Set	127
1B 26 3 <i>c1 c2...dn</i>	Define User-Defined Characters	127
1B 27 <i>m a0 a1 a2 d1 ... dm</i>	Write to User Data Storage	188
1B 2A <i>m n1 n2 d1 ... dn</i>	Select Bit Image Mode	140

Code (Hexadecimal)	Command	Page
1B 2D <i>n</i>	Select or Cancel Underline Mode	128
1B 2E <i>m n rl rh d1...dn</i>	Print Advanced Raster Graphics	143
1B 32	Set Line Spacing to 1/6 Inch	111
1B 33 <i>n</i>	Set Line Spacing	111
1B 34 <i>m a0 a1 a2</i>	Read from User Data Storage	188
1B 3A 30 30 30	Copy Character Set from ROM to RAM	129
1B 3F <i>n</i>	Cancel User-defined Characters	129
1B 40	Initialize Printer	104
1B 44 [<i>n</i>] <i>k 00</i>	Set Horizontal Tabs	116
1B 45 <i>n</i>	Select or Cancel Emphasized Mode	130
1B 47	Select Double Strike (7193 Emulation)	130
1B 48	Cancel Double Strike	131
1B 49 <i>n</i>	Set or Cancel Italic Print	131
1B 4A <i>n</i>	Print and Feed Paper	112
1B 4B	Select Single-Density Graphics	144
1B 4C	Select Page Mode	180
1B 4C	Select Double Density Graphics (7193 Emulation Mode)	145
1B 52 <i>n</i>	Select International Character Set	133
1B 53	Select Standard Mode	181
1B 54 <i>n</i>	Select Print Direction in Page Mode	182
1B 56 <i>n</i>	Select or Cancel 90 Degrees Clockwise Rotated	134
1B 57 <i>n1, n2,...n8</i>	Set Printing Area in Page Mode	183
1B 59 <i>n1 n2 d1...dn</i>	Select Double Density Graphics	144
1B 5B 7D	Switch to Flash Download Mode	198
1B 5C <i>n1 n2</i>	Set Relative Print Position	117
1B 61 <i>n</i>	Select Justification	118
1B 63 34 <i>n</i>	Select Sensors to Stop Printing	105
1B 63 35 <i>n</i>	Enable or Disable Panel Buttons	105
1B 64 <i>n</i>	Print and Feed <i>n</i> Lines	113
1B 69	Perform Full Knife Cut	103
1B 6A <i>k</i>	Read from Non-Volatile Memory	188
1B 6D	Perform Partial Cut	103
1B 70 <i>n p1 p2</i>	Generate Pulse to Open Cash Drawer	106
1B 72 <i>n</i>	Select Print Color	134
1B 73 <i>n1 n2 k</i>	Write to Non-Volatile Memory (NVRAM)	189
1B 74 <i>n</i>	Select International Character Set	133
1B 75 0	Transmit Peripheral Device Status	151
1B 76	Transmit Paper Sensor Status	151

Code (Hexadecimal)	Command	Page
1B 7B <i>n</i>	Select or Cancel Upside Down Printing Mode	135
1C 21 <i>n</i>	Select print modes for Kanji characters	195
1C 2D <i>n</i>	Turn underline mode ON/OFF for Kanji	196
1C 32 <i>c1 c2 d1...dn</i>	Define user-defined Kanji characters	196
1C 53 <i>n1 n2</i>	Set Kanji character spacing	197
1c 57 <i>n</i>	Set quadruple mode ON/OFF for Kanji	197
1D 00	Request Printer ID	198
1D 01	Return Segment Number Status of Flash Memory	199
1D 02 <i>n</i>	Select Flash Memory Sector to Download	199
1D 03 <i>n</i>	Real Time Request to Printer (DLE Sequence)	166
1D 04 <i>n</i>	Real Time Status Transmission (GS Sequence)	163
1D 05	Real Time Printer Status Transmission	167
1D 06	Get Firmware CRC	199
1D 07	Return Microprocessor CRC	200
1D 0E	Erase the Flash Memory	200
1D 0F	Return Main Program Flash CRC	200
1D 10 <i>n</i>	Erase Selected Flash Sector	201
1D 11 <i>al ah cl ch d1...dn</i>	Download to Active Flash Sector	201
1D 1E	Baseline Status Request	169
1D 1F	Enable/Disable Unsolicited Status Update	168
1D 21 <i>n</i>	Select Character Size	135
1D 22 <i>n</i>	Select Memory Type (SRAM/Flash) Where to Save Logos or User-Defined Fonts	189
1D 22 55 <i>n1 n2</i>	Flash Allocation	190
1D 23 <i>n</i>	Select the Current Logo (Downloaded Bit Image)	145
1D 24 <i>nL nH</i>	Set Absolute Vertical Print Position in Page Mode	184
1D 2A <i>n1 n2 d1...dn]</i>	Define Downloaded Bit Image	146
1D 2F <i>m</i>	Print Downloaded Bit Image	148
1D 3A	Start or End Macro Definition	186
1D 40 <i>n</i>	Erase User Flash Sector	191
1D 42 <i>n</i>	Select or Cancel White/Black Reverse Print Mode	137
1D 48 <i>n</i>	Select Printing Position for HRI Characters	173
1D 49 <i>n</i>	Transmit Printer ID	153
1D 49 40 <i>n</i>	Transmit Printer ID, Remote Diagnostics Extension	154
1D 4C <i>nL nH</i>	Set Left Margin	118
1D 50 <i>x y</i>	Set Horizontal and Vertical Minimum Motion	113

Code (Hexadecimal)	Command	Page
	Units	
1D 56 <i>m</i>	Select Cut Mode and Cut Paper	107
1D 56 <i>m n</i>	Select Cut Mode and Cut Paper	107
1D 57 <i>nL nH</i>	Set Printing Area Width	119
1D 5C <i>nL nH</i>	Set Relative Vertical Print Position in Page Mode	185
1D 5E <i>r t m</i>	Execute Macro	187
1D 61 <i>n</i>	Select or Cancel Unsolicited Status Update	168
1D 66 <i>n</i>	Select Pitch for HRI Characters	174
1D 68 <i>n</i>	Select Bar Code Height	174
1D 6B <i>m d1...</i>	Print Bar Code	175
1D 6B <i>m n d1...dn</i>	Print Bar Code	175
1D 72 <i>n</i>	Transmit Status	157
1D 77 <i>n</i>	Select Bar Code Width	178
1D FF	Reboot the Printer	202
1F 04 <i>n</i>	Convert 6 Dots/mm Bitmap to 8 Dots/mm Bitmap	149
1F 05 <i>n</i>	Select Superscript or Subscript Modes	138
1F 11 [<i>m n</i>],[<i>m n</i>]...[<i>m n</i>] OFFH	Printer Setting Change	192
1F 56	Send Printer Software Version	159
1F 60 <i>n</i>	Select Thermal Printing Modes	203
1F 61 <i>n</i>	Select Thermal Printing Side	205
1F 62	Start Double Sided Printing	206
1F 63 <i>n</i>	Select or Cancel Upside Down Printing for Double Sided Printing	206
1F 64 <i>n</i>	Swap Front Side and Back Side	207
1F 65 <i>n k1 d1 d2 ... di 0</i>	Download 1-Line Top/Bottom Message	208
1F 66 <i>n</i>	Enable Pre-Defined Top/Bottom Message	211
1F 67 <i>n</i>	Select nth Macro	212
1F 68	Start/End Pre-Defined Back Side Printing	213
1F 69 <i>n1 n2</i>	Define Minimum Receipt Length	213
1F 6A n [m, o]	Print Variable	215
1F 6B <i>n d1 d2...di 0</i>	Define Variable	215
1F 6C <i>n</i>	Return Thermal Printing Mode (Batch mode command)	217
1F 6D <i>n</i>	Return Thermal Printing Mode (Real time command)	218
1F 74	Print Test Form	108

By Function

Printer Function Commands

Code (Hexadecimal)	Command	Page
10	Clear Printer	102
19 or 1B 69	Perform Full Knife Cut	103
1A or 1B 6D	Perform Partial Knife Cut	103
1B 07	Generate Tone	104
1B 40	Initialize Printer	104
1B 63 34 n	Select Sensors to Stop Printing	105
1B 63 35 n	Enable or Disable Panel Buttons	105
1B 70 n p1 p2	Generate Pulse to Open Cash Drawer	106
1D 56 m	Select Cut Mode and Cut Paper	107
1D 56 m n	Select Cut Mode and Cut Paper	107
1F 74	Print Test Form	108

Vertical Positioning and Print

Code (Hexadecimal)	Command	Page
0A	Print and Feed Paper One Line	108
0D	Print and Carriage Return	108
14 n	Feed <i>n</i> Print Lines	109
15 n	Feed <i>n</i> Dot Rows	109
16 n	Add <i>n</i> Extra Dot Rows	110
17	Print	111
1B 32	Set Line Spacing to 1/6 Inch	111
1B 33 n	Set Line Spacing	111
1B 4A n	Print and Feed Paper	112
1B 64 n	Print and Feed <i>n</i> Lines	113
1D 50 x y	Set Horizontal and Vertical Minimum Motion Units	113

Horizontal Positioning Commands

Code (Hexadecimal)	Command	Page
09	Horizontal Tab	114
1B 14 n	Set Column	114
1B 24 n1 n2	Set Absolute Starting Position	115
1B 44 [n] k 00	Set Horizontal Tabs	116
1B 5C n1 n2	Set Relative Print Position	117
1B 61 n	Select Justification	118
1D 4C nL nH	Set Left Margin	118
1D 57 nL nH	Set Printing Area Width	119

Print Characteristic Commands

Code (Hexadecimal)	Command	Page
12	Select Double-Wide Characters	121
13	Select Single-Wide Characters	121
1B 12	Select 90 Degree Counter-Clockwise Rotated Print	121
1B 16 n	Select Pitch (Column Width)	123
1B 20 n	Set Character Right-Side Spacing	124
1B 21 n	Select Print Modes	125
1B 25 n	Select or Cancel User-Defined Character Set	127
1B 26 s c1 c2 d1...dn	Define User-Defined Characters	127
1B 2D n	Select or Cancel Underline Mode	128
1B 3A 30 30 30	Copy Character Set from ROM to RAM	129
1B 3F n	Cancel User-Defined Characters	129
1B 45 n	Select or Cancel Emphasized Mode	130
1B 47 n	Select Double Strike	130
1B 48	Cancel Double Strike	131
1B 49 n	Select or Cancel Italic Print	131
1B 52 n	Select International Character Set	133
1B 56 n	Select or Cancel 90 Degrees Clockwise Rotated Print	134
1B 72 n	Select Print Color	134
1B 74 n	Select International Character Set	133

Code (Hexadecimal)	Command	Page
1B 7B n	Select or Cancel Upside Down Printing Mode	135
1D 21 n	Select Character Size	135
1D 42 n	Select or Cancel White/Black Reverse Print Mode	137
1F 05 n	Select Superscript or Subscript Modes	138

Graphics Commands

Code (Hexadecimal)	Command	Page
11 n1 ... nk	Print Raster Graphics	140
1B (+*.bmp)	Download BMP Logo	140
1B 2A m n1 n2 d1...dn	Select Bit Image Mode	141
1B 2E m n rl rh d1...dn	Advanced Raster Graphics	143
1B 4B n1 n2 d1...dn	Select Single-Density Graphics	144
1B 4C	Select Double Density Graphics (7193 Emulation Mode)	145
1B 59 n1 n2 d1...dn	Select Double-Density Graphics	144
1D 23 n	Select Current Logo (Downloaded Bit Image)	145
1D 2A n1 n2 d1...dn]	Define Downloaded Bit Image	146
1D 2F m	Print Downloaded Bit Image	148
1F 04 n	Convert 6 Dots/mm Bitmap to 8 Dots/mm Bitmap	149

Status Commands

Batch Mode

Code (Hexadecimal)	Command	Page
1B 75 0	Transmit Peripheral Device Status	151
1B 76	Transmit Paper Sensor Status	151
1D 49 n	Transmit Printer ID	153
1D 49 40 n	Transmit Printer ID, Remote Diagnostics Extension	154
1D 72 n	Transmit Status	157
1F 56 n	Send Printer Software Version	159

Real Time Commands

Code (Hexadecimal)	Command	Page
--------------------	---------	------

10 04 n	Real Time Status Transmission (DLE Sequence)	163
10 05 n	Real Time Request to Printer (GS Sequence)	166
1D 03 n	Real Time Request to Printer (DLE Sequence)	166
1D 04 n	Real Time Status Transmission (GS Sequence)	163
1D 05	Real Time Printer Status Transmission	167

Unsolicited Status Update

Code (Hexadecimal)	Command	Page
1D 61 n	Select or Cancel Unsolicited Status Update	168
1D 1F	Enable/Disable Unsolicited Status Update	168
1D 1E	Baseline State Request	169

Barcode Commands

Code (Hexadecimal)	Command	Page
1D 48 n	Select Printing Position for HRI Characters	173
1D 66 n	Select Pitch for HRI Characters	174
1D 68 n	Select Bar Code Height	174
1D 6B m d1...dk 00 or 1D 6B m n d1...dn	Print Bar Code	175
1D 77 n	Select Bar Code Width	178

Page Mode Commands

Code (Hexadecimal)	Command	Page
0C	Print and Return to Standard Mode	179
18	Cancel Print Data in Page Mode	179
1B 0C	Print Data in Page Mode	180
1B 4C	Select Page Mode	180
1B 53	Select Standard Mode	181
1B 54 n	Select Print Direction in Page Mode	182
1B 57 n1, n2...n8]	Set printing Area in Page Mode	183
1D 24 nL nH	Set Absolute Vertical Print Position in Page Mode	184
1D 5C nL nH	Set Relative Vertical Print Position in Page Mode	185

Macro Commands

Code (Hexadecimal)	Command	Page
1D 3A	Start or End Macro Definition	186
1D 5E r t m	Execute Macro	187

User Data Storage Commands

Code (Hexadecimal)	Command	Page
1B 27 m addr d1...dm	Write to User Data Storage	188
1B 34 m addr	Read from User Data Storage	188
1B 6A k	Read from Non-Volatile Memory	188
1B 73 n1 n2 k	Write to Non-Volatile Memory (NVRAM)	189
1D 22 n	Select Memory Type (SRAM/Flash) Where to Save Logos or User-Defined Fonts	189
1D 22 55 n1 n2	Flash Allocation	190
1D 40 n	Erase User Flash Sector	191
IF 11 [m n],[m n]...[m n] 0FFH	Printer Setting Change	192

Asian Character Commands

Code (Hexadecimal)	Command	Page
1C 21 n	Select print modes for Kanji characters	195
1C 2D n	Turn underline mode ON/OFF for Kanji	196
1C 32 c1 c2 d1...dn	Define user-defined Kanji characters	196
1C 53 n1 n2	Set Kanji character spacing	197
1c 57 n	Set quadruple mode ON/OFF for Kanji	197

Flash Download Commands

Code (Hexadecimal)	Command	Page
1B 5B 7D	Switch to Flash Download Mode	198
1D 00	Request Printer ID	198
1D 01	Return Segment Number Status of Flash Memory	199
1D 02 n	Select Flash Memory Sector to Download	199
1D 06	Get Firmware CRC	199
1D 07	Return Microprocessor CRC	200
1D 0E	Erase the Flash Memory	200
1D 0F	Return Main Program Flash CRC	200
1D 10 n	Erase Selected Flash Sector	201

1D 11 aL aH cL cH d1...dn	Download to Active Flash Sector	201
1D FF	Reboot the Printer	202

Double Side Printing Commands

Hexadecimal Command Code and Operands	Command	Page
1F 60 <i>n</i>	Select Thermal Printing Modes	203
1F 61 <i>n</i>	Select Thermal Printing Side	205
1F 62	Start Double Sided Printing	206
1F 63 <i>n</i>	Select or Cancel Upside Down Printing for Double Side Mode	206
1F 64 <i>n</i>	Swap Front Side and Back Side	207
1F 65 <i>n k₁ d₁ d₂ ... d_i 0</i>	Download 1-line Top/Bottom/Reprint Message into ROM	208
1F 66 <i>n</i>	Enable Top/Bottom Message	211
1F 67 <i>n</i>	Select <i>n</i> th Macro	212
1F 68	Start or End Pre-Defined Back Side Printing Data Definition	213
1F 69 <i>n1n2</i>	Define Minimum Receipt Length	213
1F 6A n [m, o]	Print a Variable	215
1F 6B <i>n d₁ d₂ ... d_i 0</i>	Define a Variable	215
1F 6C <i>n</i>	Return Thermal Printing Mode (Batch mode command)	217
1F 6D <i>n</i>	Return Thermal Printing Mode (Real time command)	218

Comparison Chart

The following table details the list of commands whose behavior differs from the 7193 and the 7198 because of the physical differences of a 6 dots/mm head (7193) versus an 8 dots/mm head (7198).

Command	Description	Difference between 7193 and 7198 configured in 7193 Emulation Mode.
15 <i>n</i>	Feed <i>n</i> Dot Rows	This command will move the paper on the receipt in $n/203$ inch steps instead of $n/152$ inch steps.
16 <i>n</i>	Add <i>n</i> Extra Dot Rows	The dot rows will be measured in $n/203$ inches versus $n/152$ inches.
1B 20 <i>n</i>	Set Right-Side Character Spacing	This command sets the right side spacing to “ <i>n</i> ” horizontal motion units. By default, these units are in terms of $1/203$ inches versus $1/152$ inches.
1B 24 <i>n1 n2</i>	Set Absolute Starting Position	For graphics commands, the position is scaled to best 7193. In text mode, the equivalent character position is calculated.
1B 26 <i>s c1 c2 n1 d1...nn dn]</i>	Define User-Defined Character Set	Since the dots on the 7198 print head are smaller, user-defined characters that were used on the previous printer will appear smaller on the 7198 printer.
1B 2A <i>m n1 n2 d1...dn</i>	Select Bit Image Mode	In 7193 Emulation Mode, graphics are scaled to best match the size of the graphic in the 7193 printer.
1B 33 <i>n</i>	Set Line Spacing	This command uses <i>n</i> in terms of $n/360$ inches. Since the 7193 had a fundamental step of $1/152$ inch and the 7198 has a fundamental step of $1/203$ inch, the actual line spacing will not exactly match the requested spacing.
1B 4A <i>n</i>	Print and Feed Paper	(Same as above)
1B 59 <i>n1 n2 d1...dn</i>	Select Double-Density Graphics	In 7193 Emulation Mode, the printer scales the graphics to

Command	Description	Difference between 7193 and 7198 configured in 7193 Emulation Mode.
		provide the best match.
1B 5C <i>n1 n2</i>	Set Relative Print Position	The parameter to this command is in units of dots. However, the command moves and aligns to character positions. In 7193 Emulation Mode, this command calculates how many character positions to move based on the 7193 character width in dots (10) versus the 7198 (13).
1B 61 <i>n</i>	Select Justification	This command does true dot resolution alignment for centering versus character-aligned centering.
1D 2A <i>n1 n2 d1...dn]</i>	Define Downloaded Bit Image	In 7193 Emulation Mode, this command scales the incoming data to provide a best match to the size of the image as it printed on 7193.
1D 2F <i>m</i>	Print Downloaded Bit Image	(Same as above)

Command Descriptions

This section provides the detailed description of the commands. These commands are separated into groups according to their function or use. The previous sections can be used as an index for the following sections.

The following lists and describes the headings used to present the elements of the commands in the descriptions in this section. Each command code is presented in three formats: ASCII, hexadecimal, and decimal. Choose the format that best suits the programming implementation. The printer interprets the 8-bit bytes it gets through its communication interface; it does not care what format the program lists them in.

Name: Name of Command

ASCII: The ASCII representation of the command control code followed by its operands.

Hexadecimal: The hexadecimal representation of the command control code followed by its operands.

Decimal: The decimal representation of the command control code followed by its operands.

Operand *n*: A description of the command operand. Other command operands may be *m*, *p1*, *p2*, *x*, or *y*.

Range of *n*: The upper and lower limits or list of possible values of the command operand. The values are listed as decimal values unless specified otherwise.

Default of *n*: The command operand default value after printer reset or startup.

Description: A brief description of the use of the command.

Formulas: Any formulas used for this command.

Example: Coding example of how to send the command in Visual Basic. This code assumes we are doing output to an opened and ready device called "MSCOMM1." The examples use the hexadecimal command code formats; the ASCII or decimal formats could also be used in VB. In commands that use an operand, a specific value is used, and the result of using the selected value for the operand is described.

Exceptions: Describes any exceptions to this command, e.g., incompatible

commands.

Related Information: Describes related information for this command, e.g., bit information.

Printer Function Commands

The printer function commands control the following basic printer functions and are described in order of their hexadecimal codes:

1. Resetting the printer
2. Cutting the paper
3. Opening the cash drawers

Clear Printer

ASCII: DLE

Hexadecimal: 10

Decimal: 16

Clears the print line buffer without printing and sets the printer to the following condition:

1. Double-Wide command (0x12) is cancelled
2. Line Spacing, Pitch, and User-Defined Character Sets are maintained at current selections (RAM is not affected)
3. Single-Wide, Single-High, Non-Rotated, and Left-Aligned characters are set
4. Printer is restarted and error status is cleared if a fault condition existed
5. Printing position is set to column one
6. Knife is homed

- Exceptions:
-
- A DLE command followed by an 04 or 05 is interpreted as a "real time command".
(See Real Time commands)
-

Perform Partial Knife Cut (Previously command was full knife cut)**ASCII:** EM or ESC i**Hexadecimal:** 19 or 1B 69**Decimal:** 25 or 27 105

Cuts the receipt, leaving .20 inch (5 mm) of paper. This command is implemented the same as Partial Knife Cut (1A, 1B 6D). There are two codes for this command. Both codes perform the same function.

A Line Feed is executed first if print buffer is not empty.

Perform Partial Knife Cut**ASCII:** SUB or ESC m**Hexadecimal:** 1A or 1B 6D**Decimal:** 26 or 27 109

Cuts the receipt, leaving 5 mm (.20 inch) of paper. This command is implemented the same as Full Knife Cut (19, 1B 6D) which results in a partial knife cut. There are two codes for this command and both perform the same function.

Exceptions:

Line Feed is executed first if the buffer is not empty.

Generate Tone**ASCII:** ESC BEL**Hexadecimal:** 1B 07**Decimal:** 27 7

Generates an audible tone. This allows the application to provide an audible tone to the operator.

Initialize Printer**ASCII:** ESC @**Hexadecimal:** 1B 40**Decimal:** 27 64**Default:****Character Pitch** 15.6 CPI**Column Width** 44 characters (80mm)
32 characters (58mm)**Extra Dot Rows** 2**Character Set** Code Page 437**Printing Position** Column One

Clears the print line buffer and resets the printer to the default settings for the startup configuration (refer to Default settings above.)

Single-Wide, Single-High, Non-Rotated, and Left-Aligned characters are set and User-defined characters or logo graphics are cleared (Flash Memory is not affected). Tabs reset to default.

Select Sensors to Stop Printing**ASCII:** ESC c 4 *n***Hexadecimal:** 1B 63 34 *n***Decimal:** 27 99 52 *n***Value of *n* :**

Bit	Function
0, 1	Stop Receipt on Receipt Low
2 - 7	Undefined

Default: 0

Determines which sensor stops printing on the receipt station. The command does not affect the paper out sensor on the receipt station, which will automatically stop the printer when the paper is depleted.

Enable or Disable Panel Buttons**ASCII:** ESC c 5 *n***Hexadecimal:** 1B 63 35 *n***Decimal:** 27 99 53 *n***Value of *n* :** 0 = Enable

1 = Disable

Default: 0 (Enable)

Enables or disables the Paper Feed Button. If the last bit is 0, the Paper Feed Button is enabled. If the last bit is 1, the Paper Feed Button is disabled so pressing the paper feed button will result in no response.

Related Information:

Functions that require using the Paper Feed Button (except for the Execute Macro [1D 5E] command) cannot be used when it is disabled with this command.

Generate Pulse to Open Cash Drawer**ASCII:** ESC p *n* *p1* *p2***Hexadecimal:** 1B 70 *n* *p1* *p2***Decimal:** 27 112 *n* *p1* *p2***Value of *n* :** 0, 48 = Drawer 1

1, 49 = Drawer 2

Value of *p1*: 0 - 255**Value of *p2*:** 0 - 255

Sends a pulse to open the cash drawer.

Formulas:

The value for either *p1* or *p2* is the hexadecimal number multiplied by 2 msec to equal the total time.

1. On time = $p1 \times 2$ msec
2. Off time = $p2 \times 2$ msec

Related Information:

The off-time is the delay before the printer performs the next operation.

Refer to cash drawer specifications for required on and off times.

Select Cut Mode and Cut Paper

ASCII: GS V *m* or GS V *m n*

Hexadecimal: 1D 56 *m* or 1D 56 *m n*

Decimal: 29 86 *m* or 29 86 *m n*

Value of *m*: Selects the mode as shown in the table

Value of *n*: Determines cutting position only if *m* is 65 or 66.

<i>m</i>	Feed and Cut Mode
0, 48	Full cut (no extra feed). Partial cut on the 7198.
1, 49	Partial cut (no extra feed).
65	Feeds paper to cutting position + (<i>n</i> times vertical motion unit), and cuts the paper completely.
66	Feeds paper to cutting position + (<i>n</i> times vertical motion unit), and performs a partial cut.

Range of *m*: 0, 48; 1, 49

65, 66 (when used with *n*)

Range of *n*: 0 - 255

Default of *n*: 0

Default of *m*: 0

Selects a mode for cutting paper and cuts the paper. There are two formats for this command, one requiring one parameter *m*, the other requiring two parameters, *m* and *n*. The format is indicated by the parameter *m*.

Formulas: *n* times the vertical motion unit is used to determine the cutting position to the distance that the paper is fed.

Exceptions:

If *m* is out of the specified range, the command is ignored.

Print Test Form**ASCII:** US t**Hexadecimal:** 1F 74**Decimal:** 31 116

Prints the current printer configuration settings on the receipt.

Disabled in page mode.

Exception:

This command is available in 7194 Mode only.

Vertical Positioning and Print Commands

The vertical positioning and print commands control the vertical print positions of characters on the receipt.

Print and Feed Paper One Line**ASCII:** LF**Hexadecimal:** 0A**Decimal:** 10

Prints one line from the buffer and feeds paper one line.

Related Information:

Carriage Return + Line Feed, prints and feeds only one line.

Print and Carriage Return**ASCII:** CR**Hexadecimal:** 0D**Decimal:** 13

Prints one line from the buffer and feeds paper one line. The printer can be set through the configuration menu to ignore or use this command. Some applications expect the command to be ignored while others use it as print command.

Related Information:

See Ignoring/Using the Carriage Return in *Diagnostics* for more information.

Carriage Return + Line Feed, prints and feeds only one line.

Feed n Print Lines

ASCII: DC4 n

Hexadecimal: 14 n

Decimal: 20 n

Value of n : The number of lines to feed at current line height setting.

Range of n : 0 - 127 7193 Emulation Mode

0 - 255 7194 Emulation Mode

Feeds paper n lines at the current line height without printing.

Ignored if the current line is not empty.

Feed n Dot Rows

ASCII: NAK n

Hexadecimal: 15 n

Decimal: 21 n

Value of n : $n/203$ inch

Range of n : 0 - 127 7193 Emulation Mode

0 - 255 7194 Emulation Mode

Feeds paper n dot rows without printing. Receipt moves n rows if the print buffer is empty.

Add n Extra Dot Rows**ASCII:** SYN n **Hexadecimal:** 16 n **Decimal:** 22 n **Value of n :** $n/203$ inch**Range of n :** 0 - 12**Default:** 3

Adds n extra dot rows to the character height to increase space between print lines or decrease number of lines per inch.

Formulas:

The following table shows the relationship between the number of lines per inch and each extra dot row(s) added:

Receipt Station		
Extra Rows	Lines Per Inch	Dot Rows
0	8.47	24
1	8.13	25
2	7.81	26
3	7.52	27
4	7.25	28
5	7.00	29
6	6.77	30
7	6.55	31
8	6.35	32
9	6.16	33
10	5.98	34
11	5.81	35
12	5.64	36

Print**ASCII:** ETB**Hexadecimal:** 17**Decimal:** 23

Prints one line from the buffer and feeds paper one line. Executes LF on receipt.

•

Set Line Spacing to 1/6 Inch**ASCII:** ESC 2**Hexadecimal:** 1B 32**Decimal:** 27 50**Default:** 0.13 Inch (3.33 mm)

Sets the default line spacing to 1/6 of an inch (4.25 mm).

•

Set Line Spacing**ASCII:** ESC 3 *n***Hexadecimal:** 1B 33 *n***Decimal:** 27 51 *n***Value of *n*:** *n*/406 inches in 7194 Emulation Mode*n*/360 inches in 7193 Emulation Mode**Range of *n*:** 0 – 255**Default:** .13 inch (3.37 mm or 7.52 lines per inch, 3 extra dot rows.).

Sets the line spacing to *n*/406 inches. The minimum line spacing is 8.5 lines per inch. The line spacing equals the character height when *n* is too small.

If the Set Horizontal and Vertical Minimum Motion Units command (1D 50) is used to change the horizontal and vertical minimum motion unit, the parameters of this command (Set Line Spacing) will be interpreted accordingly.

Related Information:

For more information, see the description of the Set Horizontal and Vertical Minimum Motion Units command in this document.

Print and Feed Paper

ASCII: ESC J *n*

Hexadecimal: 1B 4A *n*

Decimal: 27 74 *n*

Value of *n*: *n*/203 inches in 7194 Emulation Mode
n/360 inches in 7193 Emulation Mode

Range of *n*: 0 - 255

Prints one line from the buffer and feeds the paper.

The line height equals the character height when *n* is too small.

•

If the Set Horizontal and Vertical Minimum Motion Units command (1D 50) is used to change the horizontal and vertical minimum motions units, the parameters of this command (Print and Feed paper) will be interpreted accordingly.

•

Related Information:

For more information, see the description of the Set Horizontal and Vertical Minimum Motion Units command in this document.

Print and Feed n Lines

ASCII:	ESC d n
Hexadecimal:	1B 64 n
Decimal:	27 100 n
Value of n:	Number of lines to be printed and fed.
Range of n:	1 - 255 (0 is interpreted as 1 on the receipt station)

Prints one line from the buffer and feeds paper n lines at the current line height.

•
•

Set Horizontal and Vertical Minimum Motion Units

ASCII:	GS P $x y$
Hexadecimal:	1D 50 $x y$
Decimal:	29 80 $x y$
Value of x:	Horizontal
Value of y:	Vertical
Range of x:	0 - 255
Range of y:	0 - 255
Default: of x:	203
Default: of y:	203

Sets the horizontal and vertical motion units to $1/x$ inch and $1/y$ inch respectively.

When x or y is set to 0, the default setting for that motion unit is used.

The default horizontal motion is $x = 203$.

Horizontal Positioning Commands

The horizontal positioning commands control the horizontal print positions of characters on the receipt.

Horizontal Tab

ASCII: HT

Hexadecimal: 09

Decimal: 9

Moves the print position to the next tab position set by the Set Horizontal Tab Positions (1B 44 *n1 n2 ... 00*) command. The print position is reset to column one after each line.

Tab treats the left margin as column one, therefore changes to the left margin will move the tab positions.

When there are no tabs defined to the right of the current position, or if the next tab is past the right margin, line feed is executed. HT has no effect in page mode. Printer initialization sets 32 tabs at column 9, 17, 25, ... (Every 8 characters)

•

Set Column

ASCII: ESC DC4 *n*

Hexadecimal: 1B 14 *n*

Decimal: 27 20 *n*

Value of *n*: 1-44 (Standard, 80 mm) 1-32 (Standard, 58 mm)

1-56 (Compressed, 80 mm) 1-42 (Compressed, 58 mm)

Default of *n*: 1

Prints the first character of the next print line in column *n*. It must be sent for each line not printed at column one. The value of *n* is set to one after each line.

Exceptions:

The command cannot be used with Single- or Double-Density graphics.

Set Absolute Starting Position**ASCII:** ESC \$ *n1 n2***Hexadecimal:** 1B 24 *n1 n2***Decimal:** 27 36 *n1 n2***Value of *n*:** Number of dots to be moved from the beginning of the line.**Value of *n1*:** Remainder after dividing *n* by 256.**Value of *n2*:** Integer after dividing *n* by 256.

The values for *n1* and *n2* are two bytes in low byte, high byte word orientation.

Sets the print starting position to the specified number of dots (up to the right margin) from the beginning of the line. The print starting position is reset to the first column after each line.

Formulas:

Determine the value of *n* by multiplying the column for the absolute starting position by 10 (standard pitch) or 8 (compressed pitch). The example shows how to calculate column 29 (10 dots per column) as the absolute starting position.

$$28 \times 10 = 280 \text{ dots (beginning of column 29)}$$

$$280 / 256 = 1, \text{ remainder of } 24$$

$$n1 = 24 \quad n2 = 1$$
Related Information:

This command is also used in the graphics mode. See Graphics Commands in this chapter for more information.

If the Set Horizontal and Vertical Minimum Motion Units command (1D 50) is used to change the horizontal and vertical minimum motion unit, the parameters of this command (Set Absolute Print Position) will be interpreted accordingly. For more information, see the description of the Set Horizontal and Vertical Minimum Motion Units command (1D 50) in this document.

Set Horizontal Tabs**ASCII:** ESC D [*n*] *k* NUL**Hexadecimal:** 1B 44 [*n*] *k* 00**Decimal:** 27 68 [*n*] *k* 0**Value of *n*:** Column for tab minus one.*n* is always less than or equal to the current selected column width.**Value of *k*:** 0 - 32**Default:** Every 8 characters from column. 1 (9, 17, 25, etc.) for normal print.

Sets up to 32 horizontal tab positions *n* columns from column one, but does not move the print position. See the Horizontal Tab (09) command.

The tab positions remain unchanged if the character widths are changed after the tabs are set. This command ends with hexadecimal 00; hexadecimal 1B 44 00 clears all tabs. Tabs assumed to be in strictly ascending order. A tab out of order terminates the command string as if it were 00, and remaining tab values are taken as normal data.

Formulas:

Set the tab positions in ascending order and put Hex 00 at the end.

Hex 1B 44 00 (number of tabs not specified) clears all tab positions.

Exceptions:

The tabs cannot be set higher than the column width of the current pitch.

Set Relative Print Position**ASCII:** ESC \ *n1 n2***Hexadecimal:** 1B 5C *n1 n2***Decimal:** 27 92 *n1 n2***Value of *n*:**To Move the Relative Starting Position Right of the Current Position by *n* dots:*n1* = Remainder after dividing *n* by 256.*n2* = Integer after dividing *n* by 256.The values for *n1* and *n2* are two bytes in low byte, high byte word orientation.To Move the Relative Starting Position Left of the Current Position by *n* dots:*n1* = Remainder after dividing (65,536-*n*) by 256*n2* = Integer after dividing (65,536-*n*) by 256The values for *n1* and *n2* are two bytes in low byte, high byte word orientation.

Moves the print starting position the specified number of dots either right (up to the right margin) or left (up to the left margin) of the current position. The print starting position is reset to the first column after each line.

Formulas:

To move to the left:

Determine the value of *n* by multiplying the number of columns to move left of the current position by 13 (standard pitch) or 10 (compressed pitch). The example shows how to set the relative position two columns in standard pitch (10 dots per column) to the left of the current position. $2 \times 10 = 20$ dots (two columns to be moved left of the current position) $65,536 - 20 = 65516$ $65,516 / 256 = 255$, remainder of 236 $n1 = 236$ $n2 = 255$

To move to the right:

Determine the value of *n* by multiplying the number of columns to move right of the current position by 10 (standard pitch) or 8 (compressed pitch). The example shows how to set the relative position two columns in standard pitch (10 dots per column) to the right of the current position. $2 \times 10 = 20$ dots (two columns to be moved right of the current position) $20 / 256 = 0$, remainder of 20 $n1 = 20$ $n2 = 0$ **Related Information:**

If the Set Horizontal and Vertical Minimum Motion Units command (1D 50) is used to change the horizontal and vertical minimum motion unit, the parameters of this

command (Set Relative Print Position) will be interpreted accordingly. For more information, see the description of the Set Horizontal and Vertical Minimum Motion Units command (1D 50) in this document.

Compatibility Information (7194 receipt mode vs. 7193 receipt mode)

There is a difference in the normal behavior of this command in 7194 Emulation Mode as compared to the original 7193. The difference exists when the command is used to move to the left. The 7193 processes the whole print string prior to putting it in the buffer for the print head. This method of processing allows the 7193 to backup in the print string and replace characters and their associated attributes when a "Set Relative Print Position" command instructs the printer to move the print position to the left.

In order to improve the speed of printing, the 7194 moves the data into a buffer for the print head when it receives it. When the "Set Relative Print Position" command contains a move to the left, this causes the new data to overstrike the previous data. This behavior can be used to an application's advantage to provide the ability to create compound characters on the receipt station.

Select Justification

ASCII:	ESC a <i>n</i>
Hexadecimal:	1B 61 <i>n</i>
Decimal:	27 97 <i>n</i>
Value of <i>n</i>:	0, 48 = Left Aligned 1, 49 = Center Aligned 2, 50 = Right Aligned
Range of <i>n</i>:	0 - 2, 48-50
Default:	0 (Left aligned)

Specifies the alignment of the characters, graphics, logos, and bar codes on the receipt station.

Exceptions:

The command is valid only when input at the beginning of a line.

Set Left Margin

ASCII: GS L *nL nH*

Hexadecimal:	1D 4C <i>nL nH</i>
Decimal:	29 76 <i>nL nH</i>
Range of <i>nL</i>:	0 - 255
Range of <i>nH</i>:	0 - 255
Default:	80 mm width 576 dots (the maximum printable area) 58 mm width 424 dots (the maximum printable area)

Sets the left margin of the printing area. The left margin is set to $((nH \times 256) + nL)$ times horizontal motion unit) inches. The horizontal motion units are set by the Set Horizontal and Vertical Minimum Motion Units command (1D 50), described in this manual.

The width of the printing area is set by the Set Printing Area Width command (1D 57), which follows this command. See the Set Printing Area Width command (1D 57) in this document for a description of that command.

If the setting exceeds the printable area, the maximum value of the printable area is used. The maximum printable area is 576 dots. See the illustration.

Formulas:


To set the left margin to one inch at the default horizontal motion unit of 1/203 inches, send the four-byte string:

```
GS L 203 0
```

Or, to set the left margin to two inches at the default horizontal motion unit of 1/203 units per inch, send the four-byte string:

```
GS L 150 1
```

Where 2 inches = $406/203$, and $406 = (1 \times 256) + 150$.



Exceptions:

The command is effective only at the beginning of a line.

This command is ignored if the line buffer is not empty.

Set Printing Area Width

ASCII: GS W *nL nH*

Hexadecimal:	1D 57 <i>nL nH</i>
Decimal:	29 87 <i>nL nH</i>
Range of <i>nL</i>:	0 - 255
Range of <i>nH</i>:	0 - 255
Default:	80 mm width 576 dots (the maximum printable area)
	58 mm width 424 dots (the maximum printable area)

Sets the width of the printing area. If the setting exceeds the printable area, the maximum value of the printable area is used.

The width of the printing area is set to $((nH \times 256) + nL)$ times horizontal motion unit) inches. The horizontal motion units are set by the Set Horizontal and Vertical Minimum Motion Units command (1D 50).

The width of the printing area follows the Set Left Margin command (1D 4C). See the Set Left Margin command (1D 4C...) earlier in this document for a description.

Formulas:


To set the width of the printing area to one inch at the default horizontal motion unit of 1/203 inches, send the four-byte string:

```
GS W 203 0
```

Or, to set the width of the printing area to two inches at the default horizontal motion unit of 1/203 units per inch, send the four-byte string:

```
GS W 150 1
```

Where 2 inches = 406/203, and 406 = (1 X 256) + 150.



Exceptions:

This command is effective only at the beginning of a line.

This command is ignored if the line buffer is not empty, and only effects the Receipt interface.

If the setting exceeds the printable area, the maximum value of the printable area is used. The maximum printable area is 576 dots for 80 mm paper width and 424 dots for 58 mm paper width. See the illustration in the Set Left Margin command (1D 4C).

Print Characteristic Commands

These commands control what the printed information looks like: selection of character sets, definition of custom-defined characters, and setting of margins. The commands are described in order of their hexadecimal codes

Select Double-Wide Characters

ASCII: DC2

Hexadecimal: 12

Decimal: 18

Prints double-wide characters. The printer is reset to single-wide mode after a line has been printed or the Clear Printer (0x10) command is received. Double-wide characters may be used in the same line with single-wide characters.

Select Single-Wide Characters

ASCII: DC3

Hexadecimal: 13

Decimal: 19

Prints single-wide characters. Single-wide characters may be used in the same line with double-wide characters.

Select 90 Degree Counter-Clockwise Rotated Print

ASCII:	ESC DC2
Hexadecimal:	1B 12
Decimal:	27 18

Rotates characters 90 degrees counter-clockwise. The command remains in effect until the printer is reset or until a Clear Printer (0x10), Select or Cancel Upside-Down Print (1B 7B), or Select or Cancel Rotated Print (1B 56) command is received.

- Example:
- `MSComm1.Output = Chr$(&H1B) & Chr$(&H12)`

Exceptions:

This command is valid only at the beginning of a line.

Rotated print and non-rotated print characters cannot be used together in the same line.

Related Information:

See Summary of Rotated Printing in this chapter.

Select Pitch (Column Width)

ASCII:	ESC SYN <i>n</i>
Hexadecimal:	1B 16 <i>n</i>
Decimal:	27 22 <i>n</i>
Value of <i>n</i>:	0 = Standard Pitch 1 = Compressed Pitch
Default:	0 (Standard pitch)

Selects the character pitch for a print line.

Formulas:

The following table provides the print characteristics for both pitches.

Pitch	Columns	CPI
Standard	44 for 80 mm paper	15.6
	32 for 58 mm paper	
Compressed	56 for 80 mm paper	20.3
	42 for 58 mm paper	

Related Information:

See "Technical Specifications" for descriptions of character pitches (print modes).

Set Character Right-Side Spacing**ASCII:** ESC SP *n***Hexadecimal:** 1B 20 *n***Decimal:** 27 32 *n***Range of *n*:** 0 - 32**Default:** 0

Sets the right side character spacing to [*n* × horizontal or vertical motion units]. Values for this command are set independently in Standard and Page Mode.

The units of horizontal and vertical motion are specified by the Set Horizontal and Vertical Minimum Motion Units (1D 50...) command. Changes in the horizontal or vertical units do not affect the current right side character spacing. When the horizontal or vertical motion unit is changed by the Set Horizontal and Vertical Minimum Motion Units (1D 50...) command the value must be in even units and not less than the minimum amount of horizontal movement.

In Standard Mode the horizontal motion unit is used.

In Page Mode the horizontal or vertical motion unit differs and depends on the starting position of the printable area. When the starting printing position is the upper left or lower right of the printable area (set by Select Print Direction in Page Mode, 1B 54 *n*) the horizontal motion unit (*x*) is used. When the starting printing position is the upper right or lower left of the printable area (set by Select Print Direction in Page Mode, 1B 54 *n*) the vertical motion unit (*y*) is used.

Exception:

This command is ignored in 7193 Emulation Mode.

Select Print Modes**ASCII:** ESC ! *n***Hexadecimal:** 1B 21 *n***Decimal:** 27 33 *n***Value of *n*:** Pitch selection (standard, compressed, double high, or double wide.)

Bit	Function	0	1
Bit 0	Pitch	Standard Pitch ¹ 15.6 CPI 44 Col/Line, (80 mm) 32 Col/Line, (58 mm)	Compressed Pitch 20.3 CPI 56 Col/Line, (80 mm) 42 Col/Line, (58 mm)
Bit 3	Emphasized Mode	Canceled	Set
Bit 4	Double-high ²	Canceled	Set
Bit 5	Double-wide	Canceled	Set
Bit 7	Underlined Mode	Canceled	Set

Bits 1, 2, 6 are not used.

¹Standard and compressed pitch cannot be used together in the same line.**Default:** 0 (for bits 0, 3, 4, 5, 7)

Selects the print mode: standard, compressed, double high, or double wide.

Related Information:

The bits in this command perform the same function as the standalone functions:

1B 16 <i>n</i>	Select Pitch
1B 45 <i>n</i>	Emphasized
12	Double-wide
13	Single-wide
1B 2D <i>n</i>	Underline

Select or Cancel User-Defined Character Set

ASCII:	ESC % <i>n</i>
Hexadecimal:	1B 25 <i>n</i>
Decimal:	27 37 <i>n</i>
Value of <i>n</i>:	0= Code Page 437 1= User-defined (RAM character set) 2= Code Page 850
Range:	0 - 2
Default:	0 (Code Page 437)

Selects the character set. When an undefined RAM character is selected, the Code Page 437 character is used. See the *Printing Specification Guide* for the character sets.

Define User-Defined Characters**Receipt**

ASCII:	ESC & 3 <i>c1 c2 n1 d1 ... nm dn</i>
Hexadecimal:	1B 26 3 <i>c1 c2 n1 d1 ... nm dn</i>
Decimal:	27 38 3 <i>c1 c2 n1 d1 ... nm dn</i>


Defines and enters downloaded characters into RAM or Flash. The command may be used to overwrite single characters. User-defined characters are available until power is turned off or the Initialize Printer command (1B 40) is received.

Any invalid byte (*s, c1, c2, n1*) aborts the command.

The command clears bit image logo data from RAM. The illustration below provides a sample of a character cell.

Defining User-Defined Characters

Defines and enters downloaded characters into RAM.



Values and Ranges:

c = the ASCII codes of the first ($c1$) and last ($c2$) characters respectively

$c1$ = Hex 20-FF (Hex 20 is always printed as a space)

$c2$ = Hex 20-FF (Hex 20 is always printed as a space)

To define only one character, use the same code for both $c1$ and $c2$.

n = the number of dot columns for the n th character as specified by $n1 \dots n_n$

$n = 1-10$ (standard pitch), 12 and less accepted but ignored

$n = 1-8$ (compressed pitch), 12 and less accepted but ignored

d = the column data for the n th character as specified by $d1 \dots d_n$

The number of bytes for a particular character cell is $3 \times n1$.

The bytes are printed down and across each cell.

Related Information:

See 1D 22 n (Select Memory Type Where to Save User-Defined Fonts.)

Select or Cancel Underline Mode

ASCII: ESC - n

Hexadecimal: 1B 2D n

Decimal: 27 45 n

Value of n : 0, 48 = Cancel underline mode

1, 49 = Select underline mode

Default of *n*: 0 (Cancels underline mode)

Turns underline mode on or off. Underlines cannot be printed for spaces set by the Horizontal Tab, Set Absolute Start Position, or Set Relative Print Position commands. This command and the Select Print Mode(s) command (1B 21) turn underline on and off in the same way.

Exceptions:

This command is ignored if *n* is out of the specified range.

This command is only available in 7194 Mode.

Copy Character Set from ROM to RAM

ASCII: ESC : 0 0 0

Hexadecimal: 1B 3A 30 30 30

Decimal: 27 58 48 48 48

Default: Code Page 437

Copies characters in the active ROM set to RAM. Use this command to re-initialize the User-Defined Character Set. Code Page 437 is copied by default at initialization.

The command is ignored if current font is the user font.

Related Information:

To modify characters in one of the character set variations, such as Rotated Print, select one of the Rotated Print commands, copy to RAM, then use the Define User-Defined Character Set command (1B 26).

Cancel User-Defined Characters

ASCII: ESC ? *n*

Hexadecimal: 1B 3F *n*

Decimal: 27 63 *n*

Value of *n*: Specified character code

Range of *n*: 32 - 255

Cancels the pattern defined for the character code specified by *n*. After the user-defined character is canceled, the corresponding pattern from Code Page 437 is printed.

Exceptions:

This command is ignored if *n* is out of range or if the user-defined character is not defined.

Select or Cancel Emphasized Mode

ASCII:	ESC E <i>n</i>
Hexadecimal:	1B 45 <i>n</i>
Decimal:	27 69
Value of <i>n</i>:	0 (bit 0), not selected 1 (bit 0), selected
Range of <i>n</i>:	0 - 255
Default:	0 (bit 0)

Starts or stops emphasized printing. The printer is reset to the standard Print Mode after Clear Printer (0x10) command is received.

Exceptions:

Only the lowest bit of *n* is effective.

Emphasized printing cannot be used with bit-images or downloaded bit-images.

Related Information:

This command and the Select Print Mode(s) command (1B 21) function identically.

Select Double Strike

	7193 Emulation	7194 Emulation
ASCII:	ESC G	ESC G <i>n</i>
Hexadecimal:	1B 47	1B 47 <i>n</i>
Decimal:	27 71	27 71 <i>n</i>
Value of <i>n</i>:		0 = Off 1 = On

Turns double strike mode on or off. Identical to Emphasized mode command. The printer is reset to the standard print mode after a line has been printed or after a Clear Printer (0x10) command is received.

Exceptions:

These settings do not apply in Page Mode. However they can be set or cleared in Page Mode.

Double-strike printing cannot be used with bit-images or downloaded bit-images.

This command functions the same as the **7193** when the printer is in **7193 Emulation Mode**. In Emulation Mode, the command takes a parameter to enable and disable it.

Related Information:

Printer output is the same as in Emphasized Mode.

•

Cancel Double Strike

ASCII: ESC H

Hexadecimal: 1B 48

Decimal: 27 72

Turns off double strike mode in **7193 Emulation Mode**.

This command is ignored in the **7194 Emulation Mode**.

Select or Cancel Italic Print

ASCII: ESC I *n*

Hexadecimal: 1B 49 *n*

Decimal: 27 73 *n*

Value of *n*: 0 = Off

1 = On

(When 0 and 1 are the Least Significant Bit, LSB)

Default: 0 (Off)

Turns Italic print mode on or off. This command is only available in **7194** Mode. Italic print mode is available for built-in, user-defined characters.

Exceptions:

Only the lowest bit of n is valid. This command is only valid for the receipt station in 7194 Mode.

Select International Character Set

ASCII:	ESC R <i>n</i>	or	ESC t <i>n</i>	
Hexadecimal:	1B 52 <i>n</i>	or	1B 74 <i>n</i>	
Decimal:	27 82 <i>n</i>	or	27 116 <i>n</i>	
Value of <i>n</i>:	7194 Emulation			7196 Emulation
	0 = Code Page 437	US English		0 = Code Page 437
	1 = Code Page 850 Multilingual			1 = Code Page 850
	2 = Code Page 852 Slavic			
	3 = Code Page 860 Portuguese			
	4 = Code Page 863 French Canadian			
	5 = Code Page 865 Nordic			
	6 = Code Page 858 Multilingual with Euro Symbol			
	7 = Code Page 866 Cyrillic			
	8 = Code Page 1252 Windows Latin I			
	9 = Code Page 862 Hebrew			
	20 = Code Page Katakana			
	21 = Code Page 874 Thailand			
	22 = Code Page 864 Arabic			
	128 = Code Page 932			
	129 = Code Page 936			
	130 = Code Page 949			
	131 = Code Page 950			
Default:	0 (Code Page 437)			

Selects the character set to be used. See *Print Specifications* for the character sets.

There are two codes for this command. Both codes perform the same function.

Related Information:

This command may also be known as Select Character Code Table.

Select Character Code Table

See the previous command, Select International Character Set.

Select or Cancel 90 Degrees Clockwise Rotated Print

ASCII: ESC V *n*

Hexadecimal: 1B 56 *n*

Decimal: 27 86 *n*

Value of *n*: 0 = Cancel

1 = Set

Default: 0 (Cancel)

Rotates characters 90 degrees clockwise. The command remains in effect until the printer is reset or the Clear Printer (0x10) command is received. See Summary of Rotated Printing in this chapter.

Select Print Color

ASCII: ESC r *n*

Hexadecimal: 1B 72 *n*

Decimal: 27 114 *n*

Value of *n*: 0 = Monochrome

1 = 2nd Color

Default: 0 (Monochrome)

Selects color printing. Color printing is valid for character, graphics, logo and barcode.

- Example:
- MScComm1.Output = Chr\$(&H1B) & Chr\$(&H72) & Chr\$(n)

Select or Cancel Upside Down Printing Mode

ASCII:	ESC { <i>n</i>
Hexadecimal:	1B 7B <i>n</i>
Decimal:	27 123 <i>n</i>
Value of <i>n</i>:	0 = Cancel 1 = Set
Default:	0 (Cancel)

Prints upside-down characters. The character order is inverted in the buffer so text is readable. The command remains in effect until the Rotated Print (1B 12) command is received. Only bit 0 is used. Bits 1-7 are not used. See Summary of Rotated Printing in this document for more information.

Exceptions:

The command is valid only at the beginning of a line.
The Rotated Print command (1B 12) cancels this command.

Select Character Size

ASCII:	GS ! <i>n</i>
Hexadecimal:	1D 21 <i>n</i>
Decimal:	29 33 <i>n</i>
Value of <i>n</i>:	1 - 8 = vertical number of times normal font 1 - 8 = horizontal number of times normal font
Range of <i>n</i>:	00 - 07, 10 - 17, ... 70 - 77
Default of <i>n</i>:	0

Selects the character height using bits 0 to 2 and selects the character width using bits 4 to 7, as follows:

Character Width Selection

Hex	Decimal	Width
00	0	1 (normal)
10	16	2 (two times width)
20	32	3 (three times width)
30	48	4 (four times width)
40	64	5 (five times width)
50	80	6 (six times width)
60	96	7 (seven times width)
70	112	8 (eight times width)

Character Height Selection

Hex	Decimal	Height
00	0	1 (normal)
01	1	2 (two times height)
02	2	3 (three times height)
03	3	4 (four times height)
04	4	5 (five times height)
05	5	6 (six times height)
06	6	7 (seven times height)
07	7	8 (eight times height)

This command is effective for all characters (except for HRI characters).

In Standard Mode, the vertical direction is the paper feed direction, and the horizontal direction is perpendicular to the paper feed direction. However, when character orientation changes in 90 degree clockwise-rotation mode, the relationship between vertical and horizontal directions is reversed.

In Page Mode, vertical and horizontal directions are based on the character orientation. When characters are enlarged with different sizes on one line, all the characters on the line are aligned at the baseline.

The Select Print Mode (1B 21 n) command can also select or cancel double-width and double-height modes. However, the setting of the last received command is effective.

Exceptions:

If *n* is out of the defined range, this command is ignored.

This is only available in 7194 Mode.

Select or Cancel White/Black Reverse Print Mode

ASCII:	GS B <i>n</i>
Hexadecimal:	1D 42 <i>n</i>
Decimal:	29 66 <i>n</i>
Value of <i>n</i>:	0 = Off
Range of <i>n</i>:	1 = On(Only the lowest bit is used.)
Default of <i>n</i>:	0 - 255
	0 (Off)

Turns on White/Black reverse printing mode. This command is only available in 7194 Mode. In White/Black reverse printing mode, print dots and non-print dots are reversed, which means that white characters are formed by printing a black background. When the White/Black reverse printing mode is selected it is also applied to character spacing which is set by Right-Side Character Spacing (1B 20).

This command can be used with built-in characters and user-defined characters, but does not affect the space between lines.

White/Black Reverse Print Mode does not affect bit image, downloaded bit image, bar code, HRI characters, and spacing skipped by Horizontal Tab (09), Set Absolute Starting Position (1B 24...), and Set Relative Print Position (1B 5C).

White/Black reverse mode has a higher priority than Underline Mode. When Underline Mode is on and White/Black Reverse Print Mode is selected, Underline Mode is disabled, but not canceled.

Exceptions:

This is only available in 7194 Mode.

Select or Cancel Smoothing Mode

ASCII:	GS b <i>n</i>
Hexadecimal:	1D 62 <i>n</i>
Decimal:	29 98 <i>n</i>

This command is ignored.

Select Superscript or Subscript Modes

ASCII:	US ENQ <i>n</i>
Hexadecimal:	1F 05 <i>n</i>
Decimal:	31 05 <i>n</i>
Value of <i>n</i>:	0 = Normal character size 1 = Select subscript size 2 = Select superscript size
Default:	0 (normal size)

Turns superscript or subscript modes on or off. This attribute may be combined with other characters size settings commands (12, 13, 1B 21 *n*, 1D 21 *n*, ...)

This command is only available on the receipt station in 7194 Native Mode and 7197 Native Mode.

Exceptions:

This command is ignored if *n* is out of the specified range.

This is only available in 7194 Mode.

Summary of Rotated Printing

The table shows the combinations of Set/Cancel Upside-Down Print, Set/Cancel Rotated Print (clockwise), and Rotated Print (counterclockwise). Rotated CCW is mutually exclusive with the other two commands. Unintended consequences may result when rotated CCW is mixed with other commands.

The samples of the print show only the normal size characters. Double-wide and double-high characters are printed in the same orientation. They may also be mixed on the same line.

Upside Down (1B 7B <i>n</i>)	Rotated CW (1B 56 <i>n</i>)	Rotated CCW (1B 12)	Resulting Output
Canceled	Canceled	Cleared	A B C
Canceled	Set	X	
Set	Canceled	X	
Set	Set	X	
X	X	Set	

Note: The following print modes cannot be mixed on the same line:

1. Standard and compressed pitch
2. Vertical (normal) and rotated
3. Right-side up and upside down
4. Single high (normal) and double high

Graphics Commands

These commands are used to enter and print graphics data and are described in order of their hexadecimal codes.

Print Raster Graphics

ASCII: DC1 $n1 \dots nk$

Hexadecimal: 11 $n1 \dots nk$

Decimal: 17 $n1 \dots n72$

Value of n : $n1 \dots nk =$ Data bytes

Range of n : 0 - 255

Value of k : $k = 72 : 80\text{mm}$, $k = 53 : 58\text{mm}$

Prints one row of data. $N1 \dots nk$: bytes describing the line to print.

Exceptions:

Raster graphics is not available in Page Mode

This is only available in 7194 Mode.

Download BMP Logo

ASCII: ESC (+*.BMP file data)

Hexadecimal: 1B (+*.BMP file data)

Decimal: 27 (+*.BMP file data)

Value: Maximum width = 576

Maximum height = 512

Enters a BMP file data into RAM or Flash.

This command is used by sending the file data of a monochrome BMP file preceded by a $0 \times 1B$. The bit map is stored in the printer in the same manner as a down loaded bit image.

The downloaded BMP file can be printed by using the Print Downloaded Bit Image (1D 2F m) command.

Exceptions:

BMP file images that are not monochrome are ignored. This command is only valid for the receipt station.

This is only available in 7194 Mode.

Related Information:

See 1D 22 n (Select Memory Type to save logos.)

Select Bit Image Mode

ASCII: ESC * *m n1 n2 d1 ... dn*

Hexadecimal: 1B 2A *m n1 n2 d1 ... dn*

Decimal: 27 42 *m n1 n2 d1 ... dn*

Sets the print resolution and enters one line of graphics data into the print buffer. Excess data is accepted but ignored. Any print command is required to print the data, after which the printer returns to normal processing mode.



See the illustration graphic representation of the bit image.

Values:

Value of <i>m</i>	Mode	No. of Dots (Vertical)	No. of Dots (Horizontal)	Number of Dots/Line
0	8 Dot Single Density	8 (68 DPI)	0-288 (101DPI, 80mm) 0-212 (101DPI, 58mm)	8x288 (80mm) 8x212 (58mm)
1	8 Dot Double Density	8 (68 DPI)	0-576 (101DPI, 80mm) 0-424 (101DPI, 58mm)	8x576 (80mm) 8x424 (58mm)
32	24 Dot Single Density	24 (203 DPI)	0-288 (101DPI, 80mm) 0-212 (101DPI, 58mm)	24x288 (80mm) 24x212 (58mm)
33	24 Dot Double Density	24 (203 DPI)	0-576 (101DPI, 80mm) 0-424 (101DPI, 58mm)	24x576 (80mm) 24x424 (58mm)

Formulas:

$$\begin{aligned} \text{8 Dot Single Density} & n1 + (256 \times n2) \\ \text{24 Dot Single Density} & 3 \times [n1 + (256 \times n2)] \end{aligned}$$



Print Advanced Raster Graphics**ASCII:** ESC . *m n rl rh d1 ... dn***Hexadecimal:** 1B 2E *m n rl rh d1 ... dn***Decimal:** 27 46 *m n rl rh d1 ... dn***Value of *m*:** Horizontal offset from left margin = 8 x *n* dots**Value of *n*:** Number of data bytes that compose the raster**Value of *r*:** Number of times the raster has to be printed = 256 x *rh* + *rl***Value of *d*:** *d1 ... dn* = Data bytes**Range:** $0 \leq m, n \leq 72$ (80mm), $0 \leq m, n \leq 53$ (58mm) $0 \leq r \leq 65536$ $0 \leq d1 \dots dn \leq 255$

Prints a horizontal raster of graphics data one or multiple times.

Horizontal offset and number of data bytes are variable and specified by parameters.

Exceptions:

Advanced Raster graphics is not available in Page Mode.

Select Single-Density Graphics

ASCII: ESC K $n1\ n2\ d1\ \dots\ dn$

Hexadecimal: 1B 4B $n1\ n2\ d1\ \dots\ dn$

Decimal: 27 75 $n1\ n2\ d1\ \dots\ dn$

Value of n :

Value of n (8-Dot Single Density Mode)	Value of n (24-Dot Single Density Mode)	Value of d
$n1 + (256 \times n2)$	$3 \times [n1 + (256 \times n2)]$	Number of Bytes of Data (Printed Down, Then Across)

Enters one line of 8-dot single-density graphics into the print buffer. Any print command is required to print the line, after which the printer returns to normal processing mode. The number of bytes sent is represented by the formulas in the table.

Each bit corresponds to one horizontal dot. Compare to Set Bit Image Mode (1B 2A, m=1) earlier in this document.

- Example:
- `MSCComm1.Output = Chr$(&H1B) & Chr$(&H4B) & Chr$(10) & Chr$(100) Chr$(&HFF) . . . & Chr$(&HFF)`

Select Double-Density Graphics

ASCII: ESC Y $n1\ n2\ d1\ \dots\ dn$

Hexadecimal: 1B 59 $n1\ n2\ d1\ \dots\ dn$

Decimal: 27 89 $n1\ n2\ d1\ \dots\ dn$

Value of n :

Value of n (8-Dot Single Density Mode)	Value of n (24-Dot Single Density Mode)	Value of d
$n1 + (256 \times n2)$	$3 \times [n1 + (256 \times n2)]$	Number of Bytes of Data (Printed Down, Then Across)

Enters one line of 8-dot double-density graphics into the print buffer. Any print command is required to print the line, after which the printer returns to normal processing mode. The number of bytes sent is represented by the formulas in the table.

Each bit corresponds to one horizontal dot. Compare to Set Bit Image Mode (1B 2A, m=1) earlier in this document.

Exception:

1B 4C $n_1 n_2 d_1 \dots d_n$ is only valid in 7193 Emulation Mode.

Select the Current Logo (Downloaded Bit Image)

ASCII: GS # n

Hexadecimal: 1D 23 n

Decimal: 29 35 n

Range of n : 0 – 255

Selects a logo to be defined or printed. The active logo n remains in use until this command is sent again with a different logo n .

When this command precedes a logo definition, that definition is stored in Flash Memory as logo n . If there is already a different definition in Flash Memory for logo n , the first is inactivated and the new definition is used. The inactive definition is not erased from Flash and continues to take up space in Flash Memory.

When this command precedes a logo print command and n is different from the previously active logo selected, the printer retrieves the logo definition for n from Flash Memory and prints it. If there is no definition for logo n , then no logo is printed.

In the case of a previously existing application that expects only one possible logo, the printer will not receive the Select Current Logo (1D 23 n) command. In this case, the printer assigns 0 as the active logo identifier. It automatically stores any new logo definition in Flash Memory as logo 0, inactivating any previous logo 0 definition. If the Flash Memory space available for logos fills up with inactive logo 0 definitions, the firmware erases the old definitions at the next power cycle. This is the only case in which the printer erases Flash Memory without an application command.

In the case of a new application using multiple logos, the Select Current Logo (1D 23 n) command is used. After that, the printer no longer automatically erases the logo definition Flash Memory page when it fills with multiple definitions. A new application using multiple logos, writing a user-defined character set into Flash Memory, or both, is responsible for erasing the logo and user-defined character set Flash Memory page when the logo area is full or before a new character set is defined.

By default, 7193 Emulation loads downloaded bit image to SRAM, while 7194 Native Mode and 7197 Native Mode loads them to Flash.

Define Downloaded Bit Image**ASCII:** GS * $n1$ $n2$ $d1$... dn]**Hexadecimal:** 1D 2A $n1$ $n2$ $d1$... dn]**Decimal:** 29 42 $n1$ $n2$ $d1$... dn **Value of $n1$:** See the following table.**Value of $n2$:** See the following table.**Value of d :** See the following table.

Value of $n1$	Value of $n2$	Value of d
1-72 (8 x $n1$ = Number of Horizontal Dot Columns)	1-64 (Number of Vertical Bytes)*	Bytes of Data (Printed Down Then Across)

*The number of bytes sent is represented by the following formula:

$$n = 8 \times n1 \times n2 \text{ (} n1 \times n2 \text{ must be less than or equal to 4608).}$$

Enters a downloaded bit image (such as a logo) into RAM or Flash with the number of dots specified by $n1$ and $n2$ in 7193 Emulation, unless loaded into Flash. The downloaded bit image is available until power is turned off, another bit image is defined, or either Initialize Printer (1B 40), or Define User-Defined Character Set (1B 26), command is received.

By default, 7193 Emulation loads downloaded bit image to SRAM, while 7194 Mode loads them to Flash.

See the illustration on the following page for a graphic representation of the downloaded bit image.

Exceptions:

See the illustration for the Print Downloaded Bit Image command (1D 2F) for a representation of the bit image.

Related Information:

See 1D 22 n (Select Memory Type to store logos) and 1D 23 n (Select the Current Logo.)

Print Downloaded Bit Image


ASCII:	<i>GS / m</i>
Hexadecimal:	<i>1D 2F m</i>
Decimal:	<i>29 47 m</i>
Value and Range of <i>m</i>:	

Value of <i>m</i>	Print Mode	Vertical DPI ¹	Horizontal DPI*
0	Normal	203	203
1	Double Wide	203	101
2	Double High	101	203
3	Quadruple	101	101

¹Dot density measured in dots per inch

Prints a downloaded bit image in RAM or Flash on the receipt station at a density specified by *m*. It is ignored if any data is in the print buffer, if the downloaded bit image is undefined, or if the data defined exceeds one line.

See the illustration for a representation of the bit image.



Related Information:

See 1D 22 n (Select Memory Type to store logos) and 1D 23 n (Select the Current Logo.)

Convert 6 Dots/mm Bitmap to 8 Dots/mm Bitmap**ASCII:** US EOT *n***Hexadecimal:** 1F 04 *n***Decimal:** 31 04 *n***Value:** 0 = Off

1 = On

Default: 0 (Off)

Selects or cancels 6 dot/mm in 7193 Emulation Mode.

When the 6 dot/mm emulation is selected, logos and graphics are expanded horizontally and vertically to emulate their size on a 6 dot/mm printer. The horizontal positioning commands also emulate positioning on a 6 dot/mm printer.

Exception:

This command is available in 7194 Mode only.

Status Commands

Status Command Introduction

The 7198 has three methods of providing status to the application. These methods are through Batch Status Commands, Real Time Status Commands, and Unsolicited Status Update messages. An application may use one or more of these methods to understand the current status of the printer. A brief description of each of these methods follows.

Batch Status Commands – These commands are sent to the printer and stored in the printer's buffer. Once the printer has processed all the previous commands these commands are processed and the proper status is returned to the application. In the event a condition causes the printer to go BUSY, it stops processing commands from the printer buffer. If a Batch Status Command remained in the buffer during this busy condition, it would not be processed. In fact, no Batch Commands are processed while the printer is in this state.

Real-Time Commands – These commands are sent to the printer and are NOT stored in the printer's buffer. Instead, they are acted on immediately (regardless of the printer's BUSY status) and their response (if any) is returned to the application. This gives the application the ability to query the printer when it is in a busy state in order to correct whatever fault has occurred.

Unsolicited Status Update messages

The host can determine if any unsolicited 3-byte sequence from the printer is a USU message by checking the upper 4 bits of the three bytes received. If the upper 4 bits match those of the USU message, then the remaining lower 4 bits are to be interpreted as the information bits of a USU message.

Batch Mode

For RS-232C printers, these commands enable the printer to communicate with the host computer following the selected handshaking protocol, either DTR/DSR or XON/XOFF. They are stored in the printer's data buffer as they are received, and are handled by the firmware in the order in which they are received.

When a fault occurs, the printer will go busy at the RS-232C interface and not respond to any of the Batch Mode Printer Status commands. If the fault causing the busy condition can be cleared, such as by loading paper, or letting the thermal print head cool down, the printer will resume processing the data in its receive buffer.

Transmit Peripheral Device Status**ASCII:** ESC u 0**Hexadecimal:** 1B 75 0**Decimal:** 27 117 0

	<u>Bit 0</u>	<u>Bit 1</u>
Return Value:	1 = Drawer 1 closed	1 = Drawer 2 closed
	0 = Drawer 1 open	0 = Drawer 2 open
	(Bits 2-7 are not used)	

Transmits current status of the cash drawers. One byte is sent to the host computer. In DTR/DSR protocol the printer waits for DSR = SPACE. If a drawer is not connected, the status will indicate it is closed.

Transmit Printer Status**ASCII:** ESC v**Hexadecimal:** 1B 76**Decimal:** 27 118

Sends status data to the host computer. The printer sends one byte to the host computer when it is not busy or in a fault condition. In DTR/DSR protocol, the printer waits for DSR = SPACE.

Status Byte (RS-232C)			
Bit	Function	0 Signifies	1 Signifies
0	Receipt Paper	Ok	Low
1	Receipt Cover or Front Cover	Closed	Open
2	Receipt Paper	Ok	Out
3	Knife Position	Ok	Jam
4	Not Used	Fixed to Zero	Fixed to Zero
5	Temperature	In valid range	Too hot or too cold
6	Voltage	In valid range	Too high or too low
7	Not Used	Fixed to Zero	Fixed to Zero

- Example:
- `MSCComm1.Output = Chr$(&H1B) & Chr$(&H76)`

Related Information:

See Real Time Commands, in this document for details about fault condition reporting.

Transmit Printer ID**ASCII** GS I *n***Hexadecimal** 1D 49 *n***Decimal** 29 73 *n***Value of *n*** 1, 49 = Printer model ID

2, 50 = Type ID

3, 51 = ROM version ID

4, 52 = Logo definition

Transmits the printer ID specified by *n*. This command is a batch mode command; that is, the response is transmitted after all prior data in the receive buffer has been processed. There may be a time lag between the printer receiving this command and transmitting the response.

Transmits the printer ID specified by *n* as follows:

N	Printer ID	Specification	ID (hexadecimal)
1, 49	Printer model ID	NCR 7194	0x24 (7194 Emulation)
1, 49	Printer model ID	NCR 7193	0x03 (7193 Emulation)
1, 49	Printer model ID	NCR 7197	0xA2 (7197 Emulation)
2, 50	Type ID	Installed options	Refer to the table below
3, 51	ROM version ID	ROM version	0x00
4, 52	Logo Definition	Logo Definition	Refer to table below

Type ID (n=2)

Bit	Off/On	Hex	Decimal	Function
0	Off	00	0	No two-byte character code installed.
	On	01	1	Two-byte character code installed.
1	Off	00	0	No knife installed.
	On	02	2	Knife installed.
2	-	-	-	Undefined
3	-	-	-	Undefined
4	Off	00	0	Not used. Fixed to Off.
5	-	-	-	Undefined
6	-	-	-	Undefined
7	Off	00	0	Not used. Fixed to Off.

Type ID (n=4)

Bit	Off/On	Hex	Decimal	Function
0	Off	00	0	No logo definition loaded by application.
	On	01	1	Logo loaded by application.
1	-	-	-	Undefined
2	-	-	-	Undefined
3	-	-	-	Undefined
4	Off	00	0	Not used. Fixed to Off.
5	-	-	-	Undefined
6	-	-	-	Undefined
7	Off	00	0	Not used. Fixed to Off.

Transmit Printer ID, Remote Diagnostics Extension

ASCII: GS I @ *n*

Hexadecimal: 1D 49 40 *n*

Decimal: 29 73 64 *n*

Values of *n*: Refer to table

Range of *n*: 32 - 255

(not all defined but reserved)

Performs the remote diagnostic function specified by *n*.

Eighteen remote diagnostic items are defined: eight printer ID items and ten printer tally items. A group of four remote diagnostic functions is assigned to each diagnostic item. Most of the diagnostic items are maintained in non-volatile memory (NVRAM), but some are maintained in read-only memory (ROM).

The table that follows describes the variables.

The first item group in the table includes an example of data to send and to receive. Data sent from the host to write to NVRAM must contain all digits required by the remote diagnostic item. All data must be ASCII. The printer returns all ASCII data. It is preceded by the parameter *n* to identify the diagnostic item and is followed by a Carriage Return (0D) to signify the end of the data.

The command performs the remote diagnostic function specified by *n* as described in the following table.

n (hex)	Remote diagnostic item	Function
20	Serial number, 10 digit ASCII	Write to flash Rom
21	Serial number, 10 digit ASCII	Write to flash ROM and print on receipt to verify
22	Serial number	Not available
23	Serial number	Return serial number, a total of 12 bytes

n (hex)	Remote diagnostic item	Function
24	Class/model number 15 digit ASCII	Write to NVRAM
25	Class/model number	Write to NVRAM and print on receipt to verify
27	Class/model number	Return Class/model number, a total of 17 bytes

n (hex)	Remote diagnostic item	Function
2B	Boot firmware part number 12 digit ASCII	Return boot firmware part number, a total of 14 bytes.

n (hex)	Remote diagnostic item	Function
2F	Boot firmware CRC 4 digit ASCII	Return boot firmware CRC, a total of 6 bytes.

n (hex)	Remote diagnostic item	Function
33	Flash firmware part number 12 digit ASCII	Return flash firmware part number, a total of 14 bytes.

n (hex)	Remote diagnostic item	Function
37	Flash firmware CRC 4 digit ASCII	Return flash firmware CRC, a total of 6 bytes.

n (hex)	Remote diagnostic item	Function
80	Receipt lines tally (Front side), 8 digit ASCII numeric	Write to NVRAM max 99,999,999
81	Receipt lines tally (Front side)	Write to NVRAM and print on receipt to verify
82	Receipt lines tally (Front side)	Clear receipt lines tally to 0.
83	Receipt lines tally (Front side)	Return receipt lines tally, preceded by n (83H) to identify

n (hex)	Remote diagnostic item	Function
84	Knife cut tally, 8 digit ASCII numeric	Write to NVRAM max 99,999,999
85	Knife cut tally	Write to NVRAM and print on receipt to verify
86	Knife cut tally	Clear Knife cut tally to 0.
87	Knife cut tally	Return Knife cut tally, returns 10 bytes

n (hex)	Remote diagnostic item	Function
88	Slip character tally, 8 digit ASCII numeric	Write to NVRAM
89	Slip character tally	Write to NVRAM and print on receipt to verify
8A	Slip character tally	Clear Slip character tally to 0.
8B	Slip character tally	Return Slip character tally, returns 10 bytes

n (hex)	Remote diagnostic item	Function
8C	MICR read tally, 8 digit ASCII numeric	Write to NVRAM max 99,999,999
8D	MICR read tally	Write to NVRAM and print on receipt to verify
8E	MICR read tally	Clear MICR read tally to 0.
8F	MICR read tally	Return MICR read tally, returns 10 bytes

n (hex)	Remote diagnostic item	Function
90	Hours on tally, 8 digit ASCII numeric	Write to NVRAM max 99,999,999
91	Hours on tally	Write to NVRAM and print on receipt to verify
92	Hours on tally	Clear Hours on tally to 0.
93	Hours on tally	Return Hours on tally, returns 10 bytes

n (hex)	Remote diagnostic item	Function
94	Boot firmware version	Not available
95	Boot firmware version	Not available
96	Boot firmware version	Not available
97	Boot firmware version	Return boot firmware version, returns 6 bytes

n (hex)	Remote diagnostic item	Function
A0	Flash firmware version	Not available
A1	Flash firmware version	Not available
A2	Flash firmware version	Not available
A3	Flash firmware version	Return flash firmware version, returns 6 bytes

n (hex)	Remote diagnostic item	Function
A4	Flash cycles tally, 8 digit ASCII numeric	Write to NVRAM max 99,999,999
A5	Flash cycles tally	Write to NVRAM and print on receipt to verify
A6	Flash cycles tally	Clear Flash cycles tally to 0.
A7	Flash cycles tally	Return Flash cycles tally, returns 10 bytes

n (hex)	Remote diagnostic item	Function
A8	Knife jams tally, 8 digit ASCII numeric	Write to NVRAM max 99,999,999
A9	Knife jams tally	Write to NVRAM and print on receipt to verify
AA	Knife jams tally	Clear Knife jams tally to 0.
AB	Knife jams tally	Return Knife jams tally, returns 10 bytes

n (hex)	Remote diagnostic item	Function
AC	Cover openings tally, 8 digit ASCII numeric	Write to NVRAM max 99,999,999
AD	Cover openings tally	Write to NVRAM and print on receipt to verify
AE	Cover openings tally	Clear Cover opening tally to 0.
AF	Cover openings tally	Return Cover opening tally, returns 10 bytes

n (hex)	Remote diagnostic item	Function
B0	Max temperature tally, 8 digit ASCII numeric	Not available
B1	Max temperature tally	Not available
B2	Max temperature tally	Clear Max temperature tally
B3	Max temperature tally	Return Max temperature tally, returns 10 bytes

n (hex)	Remote diagnostic item	Function
B4	Slip lines tally, 8 digit ASCII numeric	Write to NVRAM max 99,999,999
B5	Slip lines tally	Write to NVRAM and print on receipt to verify
B6	Slip lines tally	Clear Slip lines tally to 0.
B7	Slip lines tally	Return Slip lines tally, returns 10 bytes

n (hex)	Remote diagnostic item	Function
BC	Receipt lines tally (Back side), 8 digit ASCII numeric	Write to NVRAM max 99,999,999
BD	Receipt lines tally (Back side)	Write to NVRAM and print on receipt to verify
BE	Receipt lines tally (Back side)	Clear receipt lines tally to 0.
BF	Receipt lines tally (Back side)	Return receipt lines tally, preceded by n (BFH) to identify

Transmit Status

ASCII: GS r n

Hexadecimal: 1D 72 n

Decimal: 29 114 n

Value of n: 1, 49 = printer status

2, 50 = cash drawer status

4, 52 = Flash Memory status

Transmits the status specified by *n*. This is a batch mode command which transmits the response after all prior data in the receive buffer has been processed. There may be a time lag between the printer receiving this command and transmitting the response, depending on the receive buffer status.

When DTR/DSR RS232C communications handshaking control is selected, the printer transmits the one byte response only when the host signal DSR indicates it is ready to receive data.

When XON/XOFF RS232C communications handshaking control is selected, the printer transmits the one byte response regardless of the host signal DSR.

The status bytes to be transmitted are described in the following four tables.

Printer Status ($n = 1$ or $n = 49$)

Bit	Off/On	Hex	Decimal	Status for Transmit Status
0	Off	00	0	Paper present
	On	01	1	Paper exhausted.
1	Off	00	0	Cover closed
	On	02	2	Cover open
2	Off	00	0	Paper present
	On	04	4	Paper exhausted.
3	-	-	-	Undefined
4	Off	00	0	Not used. Fixed to off.
5	-	-	-	Undefined
6	-	-	-	Undefined
7	Off	00	0	Not used. Fixed to off.

Cash Drawer Status ($n = 2$ or $n = 50$)

Bit	Off/On	Hex	Decimal	Status for Transmit Status
0	Off	00	0	One or both cash drawers open.
	On	01	1	Both cash drawers closed.
1	Off	00	0	One or both cash drawers open.
	On	02	2	Both cash drawers closed.
2	-	-	-	Undefined
3	-	-	-	Undefined
4	Off	00	0	Not used. Fixed to off.
5	-	-	-	Undefined
6	-	-	-	Undefined
7	Off	00	0	Not used. Fixed to off.

Flash Memory Status ($n = 4$ or $n = 52$)				
Bit	Off/On	Hex	Decimal	Status for Transmit Status
0	Off	00	0	Undefined. Fixed to off.
1	Off	00	0	Undefined. Fixed to off.
2	Off	00	0	Not used. Fixed to off.
3	Off	00	0	Flash logo area adequate. Definition stored.
	On	08	8	Flash logo area not adequate for recent definition.
4	Off	00	0	Not used. Fixed to off.
5	Off	00	0	No thermal user-defined characters written to Flash
	On	20	32	Thermal user-defined characters written to Flash.
6	Off	00	0	Not used. Fixed to off.
7	Off	00	0	Not used. Fixed to off.

Range of n : 1 - 4
 49 - 52

Exceptions:

When n is out of the specified range, the command is ignored.

Send Printer Firmware Version

ASCII: US V

Hexadecimal: 1F 56

Decimal: 31 86

The printer returns 16 bytes containing the boot and Flash Firmware version. The first 8 bytes returned are an ASCII string for the boot version. The second 8 bytes are an ASCII string for the main firmware version.

Current firmware supports the first 5 byte data of 8 byte data of each version data. (The last 3 byte data is always ".00".)

- Example: When response is 12.34.0056.78.00(16 bytes), the boot version is 12.34.00 and the main firmware version is 56.78.00.

Recognizing Data from the Printer

An application sending various Real Time and non-Real Time commands to which the printer responds can determine which command a response belongs to by the table below.

Responses to Transmit Peripheral Device Status (1B 75) and Transmit Paper Sensor Status (1B 76) are non-Real Time responses and will arrive in the order in which they were solicited.

Batch Mode Response		Response Recognized By:									
ASCII	HEX										
ESC u 0	1B 75 0	0	0	0	0	0	0	x	x		Binary
ESC v	1B 76	0	0	0	0	0	x	x	x		Binary
GS I <i>n</i>	1D 49 <i>n</i>	0	x	x	0	x	x	x	x		Binary
GS r <i>n</i>	1D 72 <i>n</i>	0	x	x	0	x	x	x	x		Binary
Real-Time Response		Response Recognized By:									
ASCII	HEX										
GS EOT <i>n</i>	1D 04 <i>n</i>	0	x	x	1	x	x	1	0		Binary
DLE EOT <i>n</i>	10 04 <i>n</i>	0	x	x	1	x	x	1	0		Binary
GS ENQ	1D 05	1	x	x	x	x	x	x	x		Binary
XON		0	0	0	1	0	0	0	1		Binary
XOFF		0	0	0	1	0	0	1	1		Binary

Real Time Commands

These commands provide an application interface to the printer even when the printer is not handling other commands (RS-232C communication interface only):

1. Real Time Status Transmission (GS Sequence and DLE Sequence)
2. Real Time Request to Printer (GS Sequence and DLE Sequence)
3. Real Time Printer Status Transmission

The Batch Mode Printer Status commands are placed in the printer's data buffer as they are received and handled by the firmware in the order in which they are received. If the paper exhausts while printing data that was in the buffer ahead of the status command, the printer goes busy at the RS-232C interface and suspends processing the data in the buffer until paper is reloaded. This is true for all error conditions: knife home error, thermal print head overheat, etc.

The Real Time commands are implemented in two ways to correct these problems. Both implementations offer the same functionality; which one you choose depends on the current usage of your application.

Preferred Implementation

For a new application the GS (1D) sequences are recommended to avoid possible misinterpretation of a DLE (0x10) sequence as a Clear Printer (0x10 0, ASCII DLE NUL) command.

An application using these GS (1D) sequences, does not need to distinguish for the printer between the new real time commands and the Clear Printer command. This implementation is ideal for an existing [7193](#) application that already uses the Clear Printer command or for a new application being developed.

Alternate Implementation

The alternate implementation uses the DLE (0x10) sequences as implemented on other printers. An application using these DLE (0x10) sequences and the original [7193](#) Clear Printer command (0x10) must distinguish for the printer between the new real time commands and the Clear Printer command by adding a NUL (0x00) to the Clear Printer command.

An application using these DLE (0x10) sequences must also send the second byte of the sequence within 100 milliseconds of the first, to prevent the first byte being mistaken for a Clear Printer command.

Rules for Using Real Time Commands

Three situations must be understood when using real time commands.

First, the printer executes the Real Time command upon receiving it and will transmit status regardless of the condition of the DSR signal.

Second, the printer transmits status whenever it recognizes a Real Time Status Transmission command sequence, even if that sequence happens to occur naturally within the data of another command, such as graphics data.

In this case the sequence will also be handled correctly as the graphics data it is intended to be when the graphics command is executed from the buffer.

Third, care must be taken not to insert a Real Time command into the data sequence of another command that consists of two or more bytes.

In this case the printer will use the real time command sequence bytes instead of the other command's parameter bytes when finally executing that other command from the buffer; the other command will NOT be executed correctly.

These three situations generally preclude use of standard DOS drivers for the serial communication ports when using real time commands.

Moving Data Through the Buffer

Another consideration is that an application should take care not to let the buffer fill up with real time commands when the printer is busy at the RS-232C interface. A busy condition at the RS-232C interface can be determined by bit 3 of the response to 1D 05 or 1D 04 1 or 10 04 1. The reason for a particular busy condition can be determined by other responses to 1D 04 n or 10 04 n.

Although the printer responds to Real Time commands when it is busy, it will place them into the buffer behind any other data there, and flush them out in the order in which they were received. When the printer is busy due simply to buffer full (that is, it can't print data as fast as it can receive it), then data continues to be processed out of the buffer at approximately print speed and the Real Time commands will eventually get flushed out.

When the printer is busy due to an error condition, then data stops being processed out of the buffer until the condition clears one way or another. In either case, but more quickly in the case of an error condition, the buffer can fill with real time commands.

When the DLE sequences are being used, the last byte stored when the buffer fills up could be the DLE code, with no room for the subsequent EOT or ENQ. When this lone DLE byte is finally processed out of the buffer it will be interpreted as a Clear Printer command.

Similarly, when the GS sequences are being used, the last byte stored when the buffer fills up could be the GS code, with no room for the subsequent EOT or ETX or ENQ. When this lone GS byte is finally processed out of the buffer it will use the next byte, whatever it is, as the second byte in its GS sequence.

To guard against this situation, an application should determine the cause of a busy condition and take appropriate action or pace further real time commands to avoid filling the buffer. There are a minimum of 256 bytes available in the printer's buffer when it goes busy.

Real Time Status Transmission

	<u>GS Sequence</u>	<u>DLE Sequence</u>
ASCII:	GS EOT <i>n</i>	DLE EOT <i>n</i>
Hexadecimal:	1D 04 <i>n</i>	10 04 <i>n</i>
Decimal:	29 4 <i>n</i>	16 4 <i>n</i>
Value of <i>n</i>:	GS/DLE Sequence	
	1 = Transmit printer status	
	2 = Transmit RS-232C busy status	
	3 = Transmit error status	
	4 = Transmit receipt paper status	

Transmits the selected one byte printer status specified by *n* in Real Time according to the following parameters. This command includes two sequences: GS and DLE and using either or will produce the same result.

Exceptions:

The command is ignored if *n* is out of range.

An application using the DLE sequence must send EOT within 100 milliseconds of DLE or the printer will misinterpret the DLE and execute a Clear Printer command. Avoid this possibility by using the 1D 04 *n* sequence, which is handled exactly the same as 10 04 *n*.

Related Information:

1 = Transmit Printer Status

Bit	Status	Hex	Decimal	Function
0	Off	00	0	Fixed to Off
1	On	02	2	Fixed to On
2	Off	00	0	One or both cash drawers open
	On	04	4	Both cash drawers closed
3	Off	00	0	Not busy at the RS-232C interface
	On	08	8	Printer is Busy at the RS-232C interface
4	On	10	16	Fixed to On
5	-	-	-	Undefined
6	-	-	-	Undefined

7 Off 00 0 Fixed to Off

2 = Transmit RS-232C Busy Status

Bit	Status	Hex	Decimal	Function
0	Off	00	0	Fixed to Off
1	On	02	2	Fixed to On
2	Off	00	0	Cover closed
	On	04	4	Cover open
3	Off	00	0	Paper Feed Button is not pressed
	On	08	8	Paper Feed Button is pressed
4	On	10	16	Fixed to On
5	Off	00	0	Printing not stopped due to paper condition
	On	20	32	Printing stopped due to paper condition
6	Off	00	0	No error condition
	On	40	64	Error condition exists in the printer
7	Off	00	0	Fixed to Off

3 = Transmit Error Status

Bit	Status	Hex	Decimal	Function
0	Off	00	0	Undefined. Fixed to Off
1	On	02	2	Undefined. Fixed to On
2	Off	00	0	Undefined. Fixed to Off
3	Off	00	0	No knife error
	On	08	8	Knife error occurred
4	On	10	16	Fixed to On
5	Off	00	0	No unrecoverable error
	On	20	32	Unrecoverable error occurred
6	Off	00	0	Thermal print head temp./power supply voltage are in range
	On	40	64	Thermal print head temp./power supply voltage are out of range
7	Off	00	0	Fixed to Off

4 = Transmit Receipt Paper Status

Bit	Status	Hex	Decimal	Function
0	Off	00	0	Fixed to Off
1	On	02	2	Fixed to On
2	Off	00	0	Receipt paper adequate
	On	04	4	Receipt paper low
3	Off	00	0	Receipt paper adequate
	On	08	8	Receipt paper low

4	On	10	16	Fixed to On
5	Off	00	0	Receipt paper present
	On	20	32	Receipt paper exhausted
6	Off	00	0	Receipt paper present
	On	40	64	Receipt paper exhausted
7	Off	00	0	Fixed to Off

Real Time Request to Printer

ION USB or RS232

	<u>GS Sequence</u>	or	<u>DLE Sequence</u>
ASCII:	GS ETX <i>n</i>		DLE ENQ <i>n</i>
Hexadecimal:	1D 03 <i>n</i>		10 05 <i>n</i>
Decimal:	29 3 <i>n</i>		16 5 <i>n</i>
Value of <i>n</i>:	1 = Recover and restart		
	2 = Recover and clear buffers		

Standard USB

ASCII:	Since this command is used by Control transfer, the command strings are not defined.
Hexadecimal:	15 02 <i>n</i> (bRequest = 0x15, wValue = 0x02 <i>n</i>)
Decimal:	21 02 <i>n</i>
Values of <i>n</i>:	1 = Recover and restart
	2 = Recover and clear buffers

The printer responds to a request from the host specified by *n*. This command includes two sequences: GS and DLE. The operations performed depend on the value of *n*, according to the following parameters.

n = 1:

Restarts printing from the beginning of the line or page (decided by printing mode and diagnostics setting) where an error occurred, after recovering from the error. If reprint message is defined by Download 1-line Top/Bottom/Reprint Message into ROM (US e command) and 'Reprint the Error Page' is selected by diagnostics, printer prints the reprint message before reprinting of error page.

Print settings that are normally preserved from line to line, such as character height and width, are still preserved with this command. This sequence is ignored except when the printer is busy due to an error condition.

If the receipt is selected, this command will attempt recovery from a knife error. Other errors associated with the receipt, such as paper out or print head overheating, can be recovered from only by clearing the specific condition, such as loading paper or letting the print head cool down.

Recovery printing

The recovery printing is selected as follows.

(Single side mode)	Line Recovery
(Double side mode)	Line Recovery (Reprint Error Page setting = Resume from Error) Page Recovery (Reprint Error Page setting = Reprint Error Page)

$n = 2$:

Recovers from an error after clearing the receive and print buffers. Print settings that are normally preserved from line to line, such as character height and width, are still preserved with this command. This sequence is ignored except when the printer is busy due to an error condition.

Exceptions:

The command is ignored if n is out of range

An application using the DLE sequence must send ENQ within 100 milliseconds of DLE or the printer will misinterpret the DLE and execute a Clear Printer command. Avoid this possibility by using the 1D 03 n sequence that is handled exactly the same as 10 05 n .

Real Time Printer Status Transmission

ASCII: GS ENQ

Hexadecimal: 1D 05

Decimal: 29 5

Transmits one byte status of the printer in real time.

Value of Byte:

Bit	Status	Hex	Decimal	Function
0	Off	00	0	Receipt paper adequate
	On	01	1	Receipt paper low
1	Off	00	0	Receipt paper adequate
	On	02	2	Receipt paper low
2	Off	00	0	Cover closed
	On	04	4	Cover open
3	Off	00	0	Not busy at the RS-232C interface
	On	08	8	Printer is busy at the RS-232C interface
4	Off	00	0	One or both cash drawers open
	On	1	16	Both cash drawers closed

5	Off	00	0	Undefined. Fixed to off
6	Off	00	0	No error condition
	On	40	64	Error condition exists in the printer
7	On	00	0	Fixed to on

Unsolicited Status Update Validation

Non ION USB PRTR mode doesn't support USU function. USB device cannot communicate with the host unless the host specifically requests communication. Because PRTR mode uses Printer Class, it doesn't have any specially requests from host as trigger to reply USU status.

The Host uses this command to determined if the device supports USU

ASCII:	GS <i>a x</i>
Hexadecimal:	1D 61 <i>x</i>
Decimal:	29 97 <i>x</i>
Value of <i>x</i>	0 - FF

Response To Host (Hex): 1A, 9F, 1F

If the printer responds to the Unsolicited Status Update Validation message with this 3-byte response message, then the printer firmware supports the Unsolicited Status Update messages. If there is no response, or the printer responds with some other sequence of bytes, then the printer does not support the Unsolicited Status Updates messages.

Enable / Disable Unsolicited Status Update

Tells the printer to start or stop reporting Unsolicited Status Updates.

ASCII:	GS US <i>n</i>
Hexadecimal:	1D 1F <i>n</i>
Decimal:	29 31 <i>n</i>
Value of <i>n</i>	0 or 1

Where *n* defines the action to be taken by the firmware.

n = 0 – Tell the printer to stop sending Unsolicited Status Updates to the host.

n = 1 – Tells the printer to start sending Unsolicited Status Updates to the host upon change of a sensor or state.

This command is ignored in Non ION USB PRTR mode.

Baseline State Request

This request tells the printer to send an Unsolicited Status Update message for all Sensors and States supported by the firmware. This allows the Application, Driver, or Control to establish an initial picture of the state of the printer.

ASCII: GS RS US

Hexadecimal: 1D 1E 1F

Decimal: 29 30 31

The printer send and Unsolicited Status Update message for all Sensors and States supported by the firmware. This allows the Application, Driver or Control to establish an initial picture of the state of the printer.

This command is ignored in Non ION USB PRTR mode.

The following is the general message structure for the Unsolicited Status Update messages:

The Unsolicited Message will always consist of at least three bytes. The top 4 bits (7, 6, 5, 4) of each byte will be an identifier that when compared to the bytes before and after it will identify the byte as part of the three byte Unsolicited Status Update (USU) message. The remaining 4 bits (3, 2, 1, 0) will contain the information that is being passed to the host from the printer.

The lower 4 bits of the first two bytes when examined as continuous bits of a single number identify the sensor or state for which USU message is reporting a change. The lower 4 bits of the last byte will identify the state that is being reported to the host.

	BIT							
	7	6	5	4	3	2	1	0
Byte (1)	1	0	0	1	x	x	x	x
Byte (2)	1	0	1	0	y	y	y	y
Byte (3)	1	0	1	1	z	z	z	z

The host can determine if any unsolicited 3-byte sequence from the printer is a USU message by checking the upper 4 bits of the three bytes received. If the upper 4 bits match those of the USU message, then the remaining lower 4 bits are to be interpreted as the information bits of a USU message.

The information bits of a USU message are to be interpreted as follows:

The lower 4 bits of Byte (1) and Byte (2) should be combined in the following manner to constitute an identifier value in the range of 0-255. This **identifier** then determines how the host should interpret the **state value** of the lower 4 bits of Byte (3).

Combined Bits from Byte (1) and Byte (2) in high bit to low bit order:

Identifier Value by Bit Definition							
7	6	5	4	3	2	1	0
x	x	x	x	y	y	y	y

Status Update Messages Defined

The following table defines the sensor or state information specified by each identifier value, and the meaning of the information in the lower 4 bits of the 3rd byte for that identifier value. In cases where there are two different messages that refer to the same RTC response bit, separate USU messages should be sent if the printer firmware can distinguish between the events. If the firmware does not have separate sensors, then a USU message should be chosen to send when either event is encountered:

Identifier Value (Hex)	Description of sensor or state RTC Sensor Bit if Applicable for 7168 / 7198 (Note: RTC might be different for other printers)	State Value	Meaning
1	Receipt Paper Exhaust Sensor	1	No paper available for printing
	RTC Response (10 04 04) – Bit 6	0	Paper available for printing
2	Receipt Paper Low Sensor	1	Paper has reach low threshold limit
	RTC Response (10 04 04) – Bit 3	0	Paper has been replenished
3	Journal Paper Exhaust Sensor	1	No paper available for printing
	(Reserved Not Used 7197 / 7198 RTC Response 10 04 04 – Bit 5)	0	Paper available for printing
4	Journal Paper Low Sensor	1	Paper has reach low threshold limit
	(Reserved Not Used 7197 / 7198 RTC Response 10 04 04 – Bit 2)	0	Paper has been replenished
5	Slip leading edge sensor (Not Used 7198)	1	Paper Present
	RTC Response (10 04 05) – Bit 5	0	No Paper
6	Slip trailing edge sensor (Not Used 7198)	1	Paper Present
	RTC Response (10 04 05) – Bit 6	0	No Paper
7	Paper Station Selected (Not Used 7198)	1	Slip Paper Selected
	RTC Response (10 04 05) – Bit 2	2	Receipt Paper Selected
		3	Journal Paper Selected
8	Slip Paper Waiting State (Not Used 7198)	1	Waiting for Slip Paper
	RTC Response (10 04 05) – Bit 3	0	Not waiting for Slip Paper
9	Cash Drawer 1 (Both if printer cannot determine)	1	Drawer Open
	RTC Response (10 04 01) – Bit 2	0	Drawer Closed
A	Cash Drawer 2 (if printer can determined drawer 2)	1	Drawer Open
	Reserved Not Used 7197/7198	0	Drawer Closed
B	RS-232 Interface Status	1	Busy due to Error or Flow Control
	RTC Response (10 04 01) – Bit 3	0	Printer in Normal state
C	Receipt Paper Door on Print Mechanism	1	Door Open
	RTC Response (10 04 02) – Bit 2	0	Door Closed
D	Slip Cassette Door (Not Used 7198)	1	Door Open
	RTC Response (10 04 02) – Bit 2	0	Door Closed
E	Paper Feed Button	1	Pressed
	RTC Response (10 04 02) – Bit 3	0	Not Pressed

F	Print Stopped due to Error Condition	1	Stopped
	RTC Response (10 04 02) – Bit 5	0	Returned to Normal
10	Error Condition	1	Error Detected
	RTC Response (10 04 02) – Bit 6	0	No Error
11	Slip Flip Jam (Not Used 7198)	1	Jam Error on Slip Flip
	RTC Response (10 04 03) – Bit 2	0	Normal State

Identifier Value (Hex)	Description of sensor or state RTC Sensor Bit if Applicable for 7168 / 7198 (Note: RTC might be different for other printers)	State Value	Meaning
12	Slip Motor Jam (Not Used 7198)	1	Motor in Jam state
	RTC Response (10 04 03) – Bit 2	0	Normal State
13	Knife Condition	1	Knife in Error Condition
	RTC Response (10 04 03) – Bit 3	0	Normal State
14	Unrecoverable Error	1	Unrecoverable Error Encountered
	RTC Response (10 04 03) – Bit 5	0	Printer has been Reset
15	Thermal Print Head Temperature	1	Out of operating range
	RTC Response (10 04 03) – Bit 6	0	Normal operating range
16	Power Supply Voltage	1	Out of operating range
	RTC Response (10 04 03) – Bit 6	0	Normal operating range
17	Printer Paper Sensor	1	Paper Present
	RTC Response (10 19 01) – Bit 0	0	No Paper
18	Printer Reset	1	Printer Physical Reset Took Place
	RTC Response (10 19 01) – Bit 6		
19	Presenter Mechanism State	1	Presenter in Error
	RTC Response (10 19 02) – Bit 0	0	Presenter in Normal State
1A	Paper jam status	1	Printer is in Jam State
	RTC Response (10 19 02) – Bit 1	0	Printer in Normal State
1B	Kiosk Door State	1	Door Open
	RTC Response (10 19 02) – Bit 3	0	Door Closed
1C	Black Mark Detection Status	1	Detection Failure
	RTC Response (10 19 02) – Bit 5	0	Normal Status
1D	Double side buffer exceed	1	Received data exceed double side buffer
	No RTC Equivalent	0	Double side buffer adequate
1E	Flip Mechanism Door State (Not Used 7198)	1	Door Open
	No RTC equivalent	0	Door Closed
FA	Reserved for future use which might include defining additional bytes to extend the message structure beyond the existing 3 bytes.		
FB	Reserved for future use which might include defining additional bytes to extend the message structure beyond the existing 3 bytes.		
FC	Reserved for future use which might include defining additional bytes to extend the message structure beyond the existing 3 bytes.		
FD	Reserved for future use which might include defining additional bytes to extend the message structure beyond the existing 3 bytes.		
FE	Reserved for future use which might include defining additional bytes to extend the message structure beyond the existing 3 bytes.		
FF	Reserved for future use which might include defining additional bytes to extend the message structure beyond the existing 3 bytes.		

Printer Firmware Implementation Considerations

The printer firmware will constantly monitor the states listed above. Once the **Enable USU** command has been received, from that time forward until the **Disable USU** command is received, the printer firmware should transmit a USU message anytime there is a change to a state. When multiple messages need to be transmitted, there should be a delay of at least 100ms between messages.

The current state of the USU mechanism Enabled or Disabled should be maintained in the non-volatile memory. If the printer is reset or power-cycled, and the USU mechanism is in the Enabled state based on the value in non-volatile memory, the printer should transmit the current status of all Sensor and State information in the same manner it does in response to a **Baseline State Request**. This transmission should be performed once the power-up initialization of the printer has been completed, and the communications channel has been established.

The purpose of the transmission after power-up is to handle the case of the printer entering an error state that requires a reset, or power-cycle of the printer to correct it. Unless the current status of Sensor and State information is transmitted to the host, the controlling software on the host might be unaware of any changes in status resulting from the reset or power-cycle. The host software would remain in an error state unless it polled the printer for status information.

Bar Code Commands

The following describes the commands for the printing of bar codes and described in the order of their hexadecimal codes.

Note: 7193 firmware can be set for module widths in bar codes ranging from 2 dots to 4 dots per module (DPM) for the narrow modules. The default is 3 DPM.

7194 firmware ranges from 1 dot per module to 5 dots per module (DPM) printed on the receipt. The default is 2 DPM.

Select Printing Position for HRI Characters

ASCII: GS H *n*

Hexadecimal: 1D 48 *n*

Decimal: 29 72 *n*

Value of *n*: Printing position

0 = Not printed

1 = Above the bar code

2 = Below the bar code

3 = Both above and below the bar code

Default: 0 (Not printed)

Prints HRI (Human Readable Interface) characters above or below the bar code.

Select Pitch for HRI Characters**ASCII:** GS f *n***Hexadecimal:** 1D 66 *n***Decimal:** 29 102 *n***Value of *n*:** Pitch

0 = Standard Pitch at 15.2 CPI on receipt

1 = Compressed Pitch at 19 CPI on receipt

Default: 0 (Standard Pitch at 15.2 CPI)

Selects standard or compressed font for printing Bar Code characters.

Select Bar Code Height**ASCII:** GS h *n***Hexadecimal:** 1D 68 *n***Decimal:** 29 104 *n***Value of *n*:** Number of dots**Range of *n*:** 1 - 255**Default:** 162Sets the bar code height to *n* dots or *n*/8 mm (*n*/203 inch) for receipt.

Print Bar Code

	<u>First Variation</u>	or	<u>Second Variation</u>
ASCII:	GS k <i>m d1...dk</i> NUL		GS k <i>m n d1...dn</i>
Hexadecimal:	1D 6B <i>m d1...dk</i> 00		1D 6B <i>m n d1...dn</i>
Decimal:	29 107 <i>m d1...dk</i> 0		29 107 <i>m n d1...dn</i>

0 = End of command.

Values:

First Variation: String terminated with NUL Character

m = 0 - 6, 10

d = 32 - 126 (see the table)

n = 1 - 255 (see the table)

Selects the bar code type and prints a bar code for the ASCII characters entered. If the width of the bar code exceeds one line, the barcode is not printed.

There are two variations to this command. The first variation uses a NUL character to terminate the string; the second uses a length byte at the beginning of the string to compensate for the Code 128 bar code, which can accept a NUL character as part of the data. With the second variation the length of byte is specified at the beginning of the string.

Fixed-length codes can be aligned left, center, or right using the Align Positions command (1B 61). Variable-length codes are always center aligned in 7193 Emulation.

The check digit is calculated for UPC and JAN (EAN) codes if it is not sent from the host computer. Six-character zero-suppressed UPC-E tags are generated from full 11 or 12 characters sent from the host computer according to standard UPC-E rules. Start/Stop characters are added for Code 39 if they are not included.

<i>m</i>	Bar Code	<i>D</i>	<i>n</i> , Length
0	UPC-A	48- 57 (ASCII numerals)	Fixed Length: 11, 12
1	UPC-E	48- 57	Fixed Length: 11, 12
2	JAN13 (EAN13)	48- 57	Fixed Length: 12, 13
3	JAN8 (EAN8)	48- 57	Fixed Length: 7, 8
4	Code 39	48- 57, 65- 90 (ASCII alphabet), 32, 36, 37, 43, 45, 46, 47 (ASCII special characters) <i>d1 = dk = 42</i> (start/stop code is supplied by printer if necessary)	Variable Length
5	Interleaved 2 of 5 (ITF)	48- 57	Variable Length (Even Number)
6	CODABAR (NW-7)	65- 68, start code 48- 57, 36, 43, 45, 46, 47, 58	Variable Length
10	PDF 417 (7194 Native Mode and 7197 Native Mode)	1-255	Variable Length 7194 Native Mode and 7197 Native Mode

Second Variation: Length of Byte Specified at Beginning of String

m = 65 - 73, 75 (see the table)

d = 0 - 127 (see the table)

n = 1 - 255 (see the table)

The value of *m* selects the bar code system as described in the table. When data is present in the print buffer, the printer processes the data following *m* as normal data.

The variable *d* indicates the character code to be encoded into the specified bar code system. See the table. If character code *d* cannot be encoded, the printer prints the bar code data processed so far, and the following data is treated as normal data.

M	Bar Code	D	n, Length
65	UPC-A	48- 57 (ASCII numerals)	Fixed Length: 11, 12
66	UPC-E	48- 57	Fixed Length: 11, 12
67	JAN13 (EAN13)	48- 57	Fixed Length: 12, 13
68	JAN8 (EAN8)	48- 57	Fixed Length: 7, 8
69	CODE 39	48- 57, 65- 90 (ASCII alphabet), 32, 36, 37, 43, 45, 46, 47 (ASCII special characters) <i>d1 = dn = 42</i> (start/stop code is supplied by printer if necessary)	Variable
70	Interleaved 2 of 5 (ITF)	48- 57	Variable (Even Number)
71	CODABAR (NW-7)	65- 68, start code 48- 57, 36, 43, 45, 46, 47, 58	Variable
72	Code 93	0 - 127	Variable (<u>A748 Native Mode</u> only)
73	Code 128	0-105 <i>d1 = 103-105</i> (must be a Start code) <i>d2 = 0-102</i> (data bytes) (Stop code is provided by the printer)	Variable
75	PDF417	0 - 255	Variable Length (<u>A748 Native Mode</u> only)

```
MSComm1.Output = Chr$(&H1D) & Chr$(&H6B) & Chr$(m) & "123456789012" & Chr$(0)
```

The above command will print the number above or below the bar code, depending on which parameter for *m* that specify.

Exceptions:

Illegal data cancels this command.

The command is valid only at the beginning of a line.

PDF417 and Code 93 are only available in 7194 Mode.

When the bar code printing area exceed 72mm

If bar width "1" => ignore this command (Barcode is not printed.)

If bar width "2-6" => print barcode using selected bar width -1

Note) The readability of scanner may be affected when bar width is changed to "1".

Select Bar Code Width**ASCII:** GS w *n***Hexadecimal:** 1D 77 *n***Decimal:** 29 119 *n***Value of *n*:** 1, 2, 3, 4, 5, 6 (except 7193 mode)

1,2,3,4 (7193 mode)

Default: 3 for receiptSets the bar code width to *n* dots.**Formulas:** $n + 1/8$ mm ($n + 1/203$ inch) for receipt.

Page Mode Commands

Page Mode is one of two modes, which the 7194 printer uses to operate. Standard Mode is typical of how most printers operate by printing data as it is received and feeding paper as the various paper feed commands are received. Page Mode is different in that it processes or prepares the data as a “page” in memory before it prints it. Think of this as a virtual page. The page can be any area within certain parameters that you define. Once the printer receives the (0x0C) command, it prints the page and returns the printer to Standard Mode.

The Select Page Mode command (1B 4C) puts the printer into Page Mode. Any commands that are received are interpreted as Page Mode commands. Several commands react differently when in Standard Mode and Page Mode. The descriptions of these individual commands in this chapter indicate the differences in how they operate in the two modes.

Limitations

Page mode is only implemented on the receipt station in 7194 Mode only.

Print and Return to Standard Mode

ASCII: FF

Hexadecimal: 0C

Decimal: 12

The processed data is printed and the printer returns to Standard Mode. The developed data is deleted after being printed.

Exceptions:

This command is enabled only in Page Mode.

Cancel Print Data in Page Mode

ASCII: CAN

Hexadecimal: 18

Decimal: 24

Deletes all the data to be printed in the “page” area. Any data from the previously selected “page” area that is also part of the current data to be printed is deleted.

This command has the same code as the Open Form command, which is performed when the printer is not in Page Mode.

•

Exceptions:

This command is only used in Page Mode.

Print Data in Page Mode**ASCII:** ESC FF**Hexadecimal:** 1B 0C**Decimal:** 27 12

Collectively prints all buffered data in the printing area.

After printing, the printer does not clear the buffered data and sets values for Select Print Direction in Page Mode (1B 54 n) and Set Print Area in Page Mode (1B 57...), and sets the position for buffering character data.

For Double Side Mode, this command is ignored.

Exceptions:

This command enabled only in Page Mode.

Select Page Mode**ASCII:** ESC L**Hexadecimal:** 1B 4C**Decimal:** 27 76

Switches from Standard Mode to Page Mode. After printing has been completed either by the Print and Return to Standard Mode (FF) command or Select Standard Mode (1B 53) the printer returns to Standard Mode. The developed data is deleted after being printed.

This command sets the position where data is buffered to the position specified by Select Print Direction in Page Mode (1B 54) within the printing area defined by Set Print Area in Page Mode (1B 57).

This command switches the settings for the following commands (which values can be set independently in Standard Mode and Page Mode) to those for Page Mode.

1. Set Right-Side Character Spacing (1B 20)
2. Select 1/6-Inch Line Spacing (1B 32)
3. Set Line Spacing (1B 33)

It is possible only to set values for the following commands in Page Mode. These commands are not executed.

4. Select or Cancel 90 Degree Clockwise Rotation (1B 56)
5. Select Justification (1B 61)
6. Select or Cancel Upside Down Printing (1B 7B).
7. Set Left Margin (1D 4C)
8. Set Print Area Width (1D 57)

Exceptions:

The command is enabled only when input at the beginning of a line.
The command has no effect if Page Mode has previously been selected.
In 7193 Emulation Mode, (1B 4C...) is used for double density graphics.

Select Standard Mode

ASCII: ESC S

Hexadecimal: 1B 53

Decimal: 27 83

Switches from Page Mode to Standard Mode. In switching from Page Mode to Standard Mode, data buffered in Page Mode is cleared, the printing area set by Set Print Area in Page Mode (1B 57) is initialized and the print position is set to the beginning of the line.

This command switches the settings for the following commands (the values for these commands can be set independently in Standard Mode and Page Mode) to those for Standard Mode:

1. Set Right-Side Character Spacing (1B 20)
2. Select 1/6 Inch Line Spacing (1B 32)
3. Set Line Spacing (1B 33)

Standard Mode is automatically selected when power is turned on, the printer is reset, or the Initialize Printer command (1B 40) is used.

Exceptions:

This command is effective only in Page Mode.


Select Print Direction in Page Mode**ASCII:** ESC T *n***Hexadecimal:** 1B 54 *n***Decimal:** 27 84 *n***Value of *n*:** Start position

- 0 Upper left corner proceeding across page to the right (A)
- 1 Lower left corner proceeding up the page (B)
- 2 Lower right corner proceeding across page to the left (upside down) (C)
- 3 Upper right corner proceeding down page (D)

A, B, C and D note the direction of print. See illustration.

Selects the printing direction and start position in Page Mode. See the illustration.

The command can be sent multiple times so that several different print areas, aligned in different print directions, can be developed in the printer's page buffer before being printed by the Print and Return to Standard mode command (0C).



Default: 0 (Upper left corner proceeding across page to the right)

Exceptions:

This command is valid only in Page Mode.

This command is ignored if the value of *n* is out of the specified range.

Set Printing Area in Page Mode

ASCII: ESC W *n1, n2 ...n8.*]

Hexadecimal: 1B 57 *n1, n2 ...n8]*

Decimal: 27 87 *n1,n2 ...n8]*

Range: 0 - 255

Default: *n1-4 = 0*

n5 = 64

n6 = 2

n7 = 64

n8 = 2

Sets the position and size of the printing area in Page Mode.

The command can be sent multiple times so that several different print areas, aligned in different print directions, can be developed in the printer's page buffer before being printed by the Print and Return to Standard mode command (0C).

Defaults equal an origin of 0,0 and a size of 576x576. This command is allowed in any mode.

Formulas:

The starting position of the print area is the upper left of the area to be printed (x0, y0). The length of the area to be printed in the y direction is set to dy inches. The length of the area to be printed in the x direction is set to dx inches. Use the equations to determine the Value of x0, y0, dx, and dy.

See the illustration for a graphic representation of the printing area. For more information about the fundamental calculation pitch, see the Set Fundamental Calculation Pitch command (1D 50).

1. $x0 = [(n1 + n2 \times 256) \times (\text{horizontal direction of the fundamental calculation pitch})]$
2. $y0 = [(n3 + n4 \times 256) \times (\text{vertical direction of the fundamental calculation pitch})]$
3. $dx = [(n5 + n6 \times 256) \times (\text{horizontal direction of the fundamental calculation pitch})]$
4. $dy = [(n7 + n8 \times 256) \times (\text{vertical direction of the fundamental calculation pitch})]$

Keep the following notes in mind for this command.

5. The fundamental calculation pitch depends on the vertical or horizontal direction.
6. The maximum printable area in the x direction is 576/203 inches.
7. The maximum printable area in the y direction is 2000/203 inches.

First the printer must be set to page mode, then the following command should be sent.

Exception:

This command is effective only in Page Mode.

Set Absolute Vertical Print Position in Page Mode

ASCII: `GS $ nL nH`

Hexadecimal: `1D 24 nL nH`

Decimal: `29 36 nL nH`

Formulas:

$[(nL + nH \times 256) \times (\text{vertical or horizontal motion unit})]$ inches.

Sets the absolute vertical print starting position for buffer character data in Page Mode.

The vertical or horizontal motion unit for the paper roll is used and the horizontal starting buffer position does not move.

The reference starting position is set by Select Print Direction in Page Mode (1B 54). This sets the absolute position in the vertical direction when the starting position is set to the upper left or lower right; and sets the absolute position in the horizontal direction when the starting position is set to the upper right or lower left. The horizontal and vertical motion unit are specified by the Set Horizontal and Vertical Minimum Motion Units (1D 50) command.

The Set Horizontal and Vertical Minimum Motion Units (1D 50) command can be used to change the horizontal and vertical motion unit. However, the value cannot be less than the minimum horizontal movement amount, and it must be in even units of the minimum horizontal movement amount.

Exceptions:

This command is effective only in Page Mode.

If the $[(nL + nH \times 256) \times (\text{vertical or horizontal motion unit})]$ exceeds the specified printing area, this command is ignored.

Set Relative Vertical Print Position in Page Mode

ASCII: `GS \ nL nH`

Hexadecimal: `1D 5C nL nH`

Decimal: `29 92 nL nH`

Sets the relative vertical print starting position from the current position. This command can also change the horizontal and vertical motion unit. The unit of horizontal and vertical motion is specified by this command.

This command functions as follows, depending on the print starting position set by Select Print Direction in Page Mode (1B 54):

- When the starting position is set to the upper left or lower left of the printing area, the vertical motion unit (y) is used.
- When the starting position is set to the upper right or lower right of the printing area, the horizontal motion unit (x) is used.

Value:

The value for the horizontal and vertical movement cannot be less than the minimum horizontal movement amount, and must be in even units of the minimum horizontal movement amount.

Formulas:

The distance from the current position is set to $[(nL + nH \times 256) \times \text{vertical or horizontal motion unit}]$ inches. The amount of movement is calculated only for the receipt.

When pitch n is specified to the movement downward:

$$nL + nH \times 256 = n$$

When pitch n is specified to the movement upward (the negative direction), use the complement of 65536.

When pitch n is specified to the movement upward:

$$nL + nH \times 256 - 65536 = N$$

Exceptions:

This command is used only in Page Mode, otherwise it is ignored.

Any setting that exceeds the specified printing area is ignored.

Macro Commands

These commands are used to select and perform a user-defined sequence of printer operations.

Start or End Macro Definition

ASCII: GS :

Hexadecimal: 1D 3A

Decimal: 29 58

Starts or ends macro definition. Macro definition begins when this command is received during normal operation and ends when this command is received during macro definition. The macro definition is cleared, during definition of the macro, when the Execute Macro (1D 5E) command is received.

The defined contents of the macro are not cleared by the Initialize Printer (1B 40), thus, the Initialize Printer (1B 40) command may be used as part of the macro definition.

If the printer receives a second Select or Cancel Macro Definition (1D 3A) command immediately after previously receiving a Select or Cancel Macro Definition (1D 3A) the printer remains in the macro undefined state.

Formulas:

Exceptions:

If the macro definition exceeds 50 Kbytes, excess data is not stored.

This command is available in 7194 Mode only.

Execute Macro**ASCII:** GS ^ *r t m***Hexadecimal:** 1D 5E *r t m***Decimal:** 29 94 *r t m***Value of *r*:** The number of times to execute the macro.**Value of *t*:** The waiting time for executing the macro.**Value of *m*:** Macro executing mode0 (Bit0): The Macro executes *r* times continuously with waiting time specified by *t*.1 (Bit0): The printer waits for feed button to be pressed after waiting for the period specified by *t*. If the button is pressed, the printer executes the macro once. The printer repeats the operation *r* times.

Executes a macro. After waiting for a specified period the LED indicators blink and the printer waits for the Paper Feed Button to be pressed. After the button is pressed, the printer executes the macro once. The printer repeats this operation the number of specified times.

When the macro is executed by pressing the Paper Feed Button ($m = 1$), paper cannot be fed by using the Paper Feed Button.

Formulas:

The waiting time is $t \times 100$ msec for every macro execution.

m specifies macro executing mode when the LSB (Least significant bit) $m = 0$

The macro executes *r* times continuously at the interval specified by *t* when the LSB (Least significant bit) of $m = 1$.

Exceptions:

When a macro is being defined, if this command is without change Macro ID, printer will clear this Macro at Macro execution.

If the macro is not defined or if *r* is 0, nothing is executed.

This command is available in 7194 Mode only.

User Data Storage Commands

Write to User Data Storage

ASCII: ESC ' m a0 a1 a2 d1 ... dm

Hexadecimal: 1B 27 m a0 a1 a2 d1 ... dm

Decimal: 27 39 m a0 a1 a2 d1 ... dm

Value of m: 0 – 255

Writes *m* bytes of data to the User Data Storage Flash Page at the address specified. The printer waits for *m* bytes of data following the 3-byte address, *addr*.

If any of the memory locations addressed by this command are not currently erased, the command is not executed.

The above command writes the word 'Hello' to the User Data Storage Flash Page.

Read from User Data Storage

ASCII: ESC 4 *m a0 a1 a2*

Hexadecimal: 1B 34 *m a0 a1 a2*

Decimal: 27 52 *m a0 a1 a2*

Value of *m*: 0 – 255

Reads *m* bytes of data from the User Data Storage Flash Page at the address specified.

Read from Non-Volatile Memory

ASCII: ESC *j k*

Hexadecimal 1B 6A *k*

:

Decimal: 27 106 *k*

Range of *k*: 20 – 63 (decimal)

Reads a two-byte word from location *k* in the history EEROM. The printer returns the word at the next available opportunity.

Write to Non-Volatile Memory (NVRAM)

ASCII:	ESC s <i>n1 n2 k</i>
Hexadecimal:	1B 73 <i>n1 n2 k</i>
Decimal:	27 115 <i>n1 n2 k</i>
Value of <i>n1</i> :	1 st Byte
Value of <i>n2</i> :	2 nd Byte
Range of <i>k</i> :	20 - 63 (decimal)

Writes the two-byte word, *n1 n2*, to location *k* in history EEROM.

Select Memory Type (SRAM/Flash) Where to Save Logos or User-Defined Fonts

ASCII:	GS " <i>n</i>
Hexadecimal:	1D 22 <i>n</i>
Decimal:	29 34 <i>n</i>
Value of <i>n</i>:	48 - 53

Specifies whether to load the logos or user-defined characters to Flash Memory or to RAM (volatile memory). The selection remains in effect until it is changed via this command or until the power cycles.

n = 48 (ASCII *n* = 0)

Loads active logo to RAM only. This is used to print a special logo but not have it take up Flash Memory. A logo defined following this command is not preserved over a power cycle.

n = 49 (ASCII *n* = 1)

Loads active logo to Flash Memory. This is the default condition for logo Flash storage. A logo defined following this command is stored in Flash Memory.

n = 50 (ASCII *n* = 2)

Loads user-defined characters to RAM only. This is the default condition for user-defined character storage. Any user-defined characters defined following this command are not preserved over a power cycle.

n = 51 (ASCII *n* = 3) Loads user-defined characters to Flash Memory. An application must use this command to store user-defined characters in Flash Memory. Any user-defined characters defined following this command are stored in Flash Memory. A

user-defined character cannot be redefined in Flash Memory. The Flash Memory page must be erased by an application before redefining user-defined characters. For more information, see the Erase User Flash Sector (1D 40 *n*) command.

n = 52 (ASCII *n* = 4)

Loads Macro to RAM only. This is the default condition for Macro. Any Macro defined following this command is not preserved over a power cycle.

n = 53 (ASCII *n* = 5)

Loads Macro to Flash Memory. A Macro defined following this command is stored in Flash Memory.

•

Flash Allocation

ASCII: GS " U *n1 n2*

Hexadecimal: 1D 22 55 *n1 n2*

Decimal: 29 34 85 *n1 n2*

Default Value of *n1*: 1 (see below)

Default Value of *n2*: 1 (see below)

n1 is the number of 64k sectors used for logos and user-defined characters.
n2 is the number of 64k sectors used for user data storage.

This command sets the allocation of Flash sectors between user data storage and logos/user-defined characters. This allocation is saved in the EEPROM of the printer and is therefore saved across power cycles. Printer always keeps 64 Kbytes for User-defined characters.

$n1 + n2 \leq 5$ (3M)

The 7198 has been configured at the factory with 512K, 1M or 2M of Flash memory. If *n1* + *n2* is greater than the maximum number of sectors available, the command is ignored. Reissuing this command with different parameters will erase all sectors.

Exception:

This command is available only in 7194 Mode

Erase User Flash Sector**ASCII:** GS @ *n***Hexadecimal:** 1D 40 *n***Decimal:** 29 64 *n***Value of *n*:** 49 - 50

Erases a page of Flash Memory and sends a carriage return when the operation is complete.

n = 49 (ASCII *n* = 1)

This command erases all sectors available for user-defined characters and multiple logos. The page should be erased in two situations: when the logo definition area is full and an application is attempting to define new logos, and when an application wants to replace one user-defined character set with another. In both cases, all logos and character set definitions are erased and must be redefined.

n = 50 (ASCII *n* = 2)

This command erases all sectors available for user data storage.

Important: While erasing Flash Memory, the printer disables all interrupts, including communications. To provide feedback to the application, the printer responds to the application when the erase is complete. After sending the Erase User Flash Sector (1D 40 *n*) command, an application should wait for the response from the printer before sending data. Otherwise, data will be lost. If an application is unable to receive data, it should wait a minimum of five seconds after sending the Erase User Flash Sector (1D 40 *n*) command before sending data.

Printer Setting Change**ASCII:** US DC1 [*m n*], [*m n*], ... [*m n*] 0FFH**Hexadecimal:** 1F 11 [*m n*], [*m n*], ... [*m n*] 0FFH**Decimal:** 31 17 [*m n*], [*m n*], ... [*m n*] 0FFH**Value of *m, n*:**

<i>m</i> (Hex)	Function	<i>n</i> (Hex)	Function
10	Interface type	00	USB/RS232C
		01	RS232C
		02	USB
11	Baud rate	00	115200 bps
		01	57600 bps
		02	38400 bps
		03	19200 bps
		04	9600 bps
12	Number of data bit	00	8 data bits
		01	7data bits
13	Number of stop bit	00	1 stop bits
		01	2 stop bits
14	Parity	00	No parity
		01	Even parity
			Odd parity
15	Flow control	00	Software (XON/XOFF)
		01	Hardware (DTR/DSR)
16	Data reception errors option	00	Ignore errors
		01	Print "?"
17	One Line Buffer	00	Normal size receive buffer(4K)
		01	One Line Buffer (128 Bytes)
18	DSR signal option	00	Enable DSR signal
		01	Disable DSR signal
19	Printer ID Mode	00	7194 Native ID
		01	Emulated Printer ID
		02	7197 Native ID
20	Emulation	00	7194 Mode
		01	7193 mode
		02	7197 Native Mode

<i>M</i> (Hex)	Function	<i>N</i> (Hex)	Function
21	Default lines per inch	00	8.13 lines per inch
		01	7.52 lines per inch
		02	6 lines per inch
22	Carriage return usage	00	Ignore CR
		01	Use CR as Print cmd.
23	Asian mode	00	Asian mode on
		01	Asian mode off
24	Power LED control	00	Power LED control disabled
		01	Power LED control enabled
25	Receipt synchronization	00	Synchronization Enabled
		01	Synchronization Disabled
27	PDF417 Print Column	00	9 Columns
		01	14 Columns
30	Print Density	00	100%
		01	110%
		02	120%
31	Paper Low sensor option	00	Paper low sensor enable
		01	Paper low sensor disable
32	Paper width	00	80 mm
		01	58 mm
33	Knife option	00	Enable knife
		01	Disable knife
36	Max Power	00	55 W
		01	75 W
37	Color Paper Option	00	One color paper
		01	Two color paper
40	Default Code page	00	437
		01	850
		02	852
		03	858
		04	860
		05	862
		06	863
		07	864
		08	865
		09	866
		0A	874
		0B	1252
		0C	Katakana
0D	932 (or 936, 949, 950)		

41	Reserved		
42	Reserved		
43	Reserved		
45	Set paper detection	0	Enable
		1	Disable
50	EEPROM default setting	00	EEPROM default setting
<i>M</i> (Hex)	Function	<i>N</i> (Hex)	Function
60	Thermal Printing Mode	00	Single Sided Mode
		01	Double Sided Mode with Single Side command
		02	Double Sided Mode with Double Side Command
		03	Double Sided Mode with Pre-Defined data
61	Upside Down Printing for Double Side	00	Front: Normal, Back: Normal
		01	Front: Upside down, Back Normal
		02	Front: Normal, Back: Upside Down
		03	Front: Upside Down, Back Upside Down
62	Swap Front Side and Back Side	00	Not Swap
		01	Swap Front side and Back side
63	Pre-Defined Bottom/Top Message	00	No Message
		01	Bottom Message on Front
		02	Top Message on Back
		03	Both Bottom Message on Front and Top Message on Back
64	Minimum Receipt Length (Remainder after dividing Min. Receipt Length by 256)	00-FF	Length in dot rows for Minimum receipt length
65	Minimum Receipt Length (Integer after dividing Min. Receipt Length by 256)	00-FF (max value to be defined)	Length in dot rows for Minimum receipt length
66	Reprint when Error Occurs	00	Resume printing from last error line
		01	Reprint the error page
67	Reprint Message	00	No Message
		01	Reprint Message
68	USB Interface Type	00	Not use (Reserve for Epic)
(Refer		01	NHPI
Notes)		02	PRTR

Set the printer configuration specified by *m* and *n*. If *m* or *n* is out of range, this command is ignored. But the printer waits the data until terminator code "OFFH".

Notes

This command changes configuration setting in EEPROM. If same value that is set in EEPROM is set, this command doesn't write to EEPROM.

USB Interface Type is set as follows. It depend on firmware version.

command Value	ION USB version	Non ION USB version
00 (Epic) (If used)	Ignore	01 (NHPI)
01 (NHPI)	Ignore	01 (NHPI)
02 (PRTR)	Ignore	02 (PRTR)

The default value of EEPROM is

ION USB version : 0x00 (EPiC)

Non ION USB version : 0x01 (NHPI)

Asian Character Commands

Select print modes for Kanji characters

ASCII: FS ! *n*

Hexadecimal: 1C 21 *n*

Decimal: 28 33 *n*

Value of *n*: The character attribute for Asian character

Bit	Off/On	Hex	Decimal	Function
0	-	-	-	Select font
1	Off	00	0	Undefined
2	Off	00	0	Double width mode is not selected
	On	01	1	Double width mode is selected
3	Off	00	0	Double height mode is not selected
	On	01	1	Double height mode is selected
4	-	-	-	Undefined
5	-	-	-	Undefined
6	-	-	-	Undefined
7	Off	00	0	Underline mode is not selected
	On	01	1	Underline mode is selected

Default of *n*: 0

Selects character attribute for Asian character.

The underline mode can be turned on or off by using FS - or ESC - also.

The thickness of underline is defined by FS - or ESC -, it does not relate to character size.

FS – Turn underline mode ON/OFF for Kanji

ASCII:	FS - <i>n</i>
Hexadecimal:	1C 2D <i>n</i>
Decimal:	28 45 <i>n</i>
Value of <i>n</i>:	0 = Cancel 1 = 1 dot height underline 2 = 2 dot height underline
Default <i>n</i>:	0 (Cancel)

Turn underline mode on or off for Asian character.

All characters could be underlined, including character right side spacing.

Underline can be selected by FS ! and ESC - also, the last received command is effective.

Define user-defined Kanji characters

ASCII:	FS 2 <i>c1 c2 d1 ... dn</i>	
Hexadecimal:	1C 32 <i>c1 c2 d1 ... dn</i>	
Decimal:	28 50 <i>c1 c2 d1 ... dn</i>	
Value of <i>c1</i>:	Specified the beginning Asian character code	
Value of <i>c2</i>:	Specified the end Asian character code	
Value of <i>d</i>:	Image data	
Range of <i>c1,c2</i>:	Japanese (CP932)	$F0 \leq c1 \leq F9, 40 \leq c2 \leq 7E$ and $80 \leq c2 \leq FC$
	Simplified Chinese (CP936)	$A1 \leq c1 \leq A7, 40 \leq c2 \leq 7E$ and $80 \leq c2 \leq A0, AA \leq c1 \leq AF, A1 \leq c2 \leq FE,$ $F8 \leq c1 \leq FE, A1 \leq c2 \leq FE$
	Korean (CP949)	$c1 = C9$ and $c1 = FE, A1 \leq c2 \leq FE$
	Traditional Chinese	$81 \leq c1 \leq A0$ and $FA \leq c1 \leq FE, 40 \leq c2 \leq 7E$ and $80 \leq c2 \leq FE$

(CP950) $C7 \leq c1 \leq C8, A1 \leq c2 \leq FE$

Defines and enters downloaded characters into RAM. The user-defined character will be cleared by ESC @ or power off of printer. Each character requires 72 bytes for character definition.

The maximum number of user-defined character is 100.

Set Kanji character spacing

ASCII: FS S *n1 n2*

Hexadecimal: 1C 53 *n1 n2*

Decimal: 28 83 *n1 n2*

Value of *n1*: Ignored (0)

Value of *n2*: Character right side spacing dots (1/203 inch)

Default of *n2*: 1 for 1 byte character, 2 for 2 bytes character

Sets the character right side spacing for characters in Asian character.

The underline is valid on the space set by this command. ESC SP command is not valid for Asian character code pages. Therefore, this command is used to set the character right side spacing for characters in Asian code page.

FS W (Set quadruple mode ON/OFF for Kanji)

ASCII: FS W *n*

Hexadecimal: 1C 57 *n*

Decimal: 28 87 *n*

Value of *n*: The quadruple mode for Asian characters.

0 (Bit 0) = Quadruple mode off

1 (Bit 0) = Quadruple mode on

Default of *n*: 0 (Quadruple mode off)

Selects or cancels the quadruple mode for Asian characters.

FS ! and GS ! also have control over character size. This, latest received command is effective.

Flash Download Commands

These commands are used to load firmware into the printer.

The commands are listed in numerical order according to their hexadecimal codes. Each command is described and the hexadecimal, decimal, and ASCII codes are listed.

There are three ways to enter the Download Mode.

1. Powering the printer up with DIP Switch 2 up.
2. While the printer is running normally, use the command Switch to Flash Download Mode, to leave normal operation and enter the Download Mode.
3. If the Flash is found corrupted during Level 0 diagnostics the Download Mode is automatically entered after the printer has reset.

The printer never goes directly from the Download Mode to normal printer operation. To return to normal printer operation either the operator must turn the power off and then on to reboot or the application must send a command to cancel Download Mode and reboot.

Switch to Flash Download Mode

ASCII: ESC [}

Hexadecimal: 1B 5B 7D

Decimal: 27 91 125

Puts the printer in Flash Download Mode in preparation to receive commands controlling the downloading of objects into Flash Memory. When this command is received, the printer leaves normal operation and can no longer print transactions until the Reboot the Printer command (1D FF) is received or the printer is rebooted.

This command does not affect the current communication parameters. Once the printer is in Flash Download Mode, this command is no longer available.

Request Printer ID

ASCII: GS NUL

Hexadecimal: 1D 00

Decimal: 29 0

Returns ACK (06 hex) + 12 bytes ASCII string describing the Flash Memory Boot Sector Firmware part number. Ex : 189-1234567A

Return Segment Number Status of Flash Memory**ASCII:** GS SOH**Hexadecimal:** 1D 01**Decimal:** 29 1

Returns the size of the Flash used. There may be 8, 16, or 32 sectors (64K each) in Flash Memory. This command assures that the firmware to be downloaded is the appropriate size for Flash Memory. The value returned is the maximum sector number that can be accepted by the Select Sector to Download (1D 02 *n*) command.

Exceptions:

Available only in Download Mode.

Select Flash Memory Sector to Download**ASCII:** GS STX *n***Hexadecimal:** 1D 02 *n***Decimal:** 29 2 *n*

Value of *n*: The Flash sector to which the next download operation applies

Range of *n*: 0 - 7 (512K)

0 - 15 (1 mB)

0 - 31 (2 mB)

Selects the Flash sector (*nn*) for which the next download operation applies. The values of the possible sector are restricted, depending upon the Flash part type. The printer transmits an ACK if the sector number is acceptable or an NAK if the sector number is not acceptable. Sector numbers start at 0.

Exceptions:

Available only in Download Mode.

Get Firmware CRC**ASCII:** GS ACK**Hexadecimal:** 1D 06**Decimal:** 29 6

Causes the printer to calculate the CRC for the currently selected sector and transmits the result. This is performed normally after downloading a sector to verify that the downloaded firmware is correct. The printer also calculates the CRC for each sector during power up and halts the program if any sector is erroneous.

The printer transmits ACK if the calculated CRC is correct for the selected sector; NAK if the CRC is incorrect or if no sector is selected.

Return Microprocessor CRC

ASCII: GS BEL

Hexadecimal: 1D 07

Decimal: 29 7

Returns the CRC calculated over the boot sector code space.

Formulas: ACK <low byte> <high byte>

Erase the Flash Memory

ASCII: GS SO

Hexadecimal: 1D 0E

Decimal: 29 14

Causes the entire Flash Memory (except the boot) to be erased.

The printer returns ACK if the command is successful; NAK if it is unsuccessful.

Exceptions:

Available only in Download Mode.

Return Main Program Flash CRC

ASCII: GS SI

Hexadecimal: 1D 0F

Decimal: 29 15

Returns the CRC calculated over the Flash firmware code space. The format of the response is ACK <low byte> <high byte>.

Erase Selected Flash Sector

ASCII:	GS DLE <i>n</i>
Hexadecimal:	1D 10 <i>n</i>
Decimal:	29 16 <i>n</i>
Value and Range of <i>n</i>:	0 - 7 = 512K bytes Flash
	0 - 15 = 1M bytes Flash
	0 - 31 = 2M bytes Flash

Erases the previously selected sector. The printer transmits ACK when the sector has been erased printer transmits NAK.

Exceptions:

Available only in Download Mode.

Download to Active Flash Sector

ASCII:	GS DC1 <i>al ah cl ch d1...dn</i>
Hexadecimal:	1D 11 <i>al ah cl ch d1...dn</i>
Decimal:	29 17 <i>al ah cl ch d1...dn</i>
Value of <i>al</i>:	low byte of the address
Value of <i>ah</i>:	high byte of the address
Value of <i>cl</i>:	low byte of the count
Value of <i>ch</i>:	high byte of the count
Value of <i>d</i>:	data bytes, from 1 to <i>n</i>

Contains a start address ($ah * 256 + al$) and count ($ch * 256 + cl$) of binary bytes to load into the selected sector, followed by that many bytes. The start address is relative to the start of the sector. Addresses run from 0 to 64K.

The printer may return one of several responses. ACK means that the data was written correctly and the host should transmit the next block. NAK means that, for some reason, the data was not written correctly. This could mean that communications failed or that the write to Flash failed. The alternatives seem to be to retry the block or halt loading and assume a hardware failure.

Value of n (for number of data bytes)	Range of Address (al ah)	Range of Count (cl ch)
$((ch * 256) + cl)$	2000-FFFF (hexadecimal)	0001-0400 (hexadecimal)

Range: Addresses run from 0 to 64K.

Related Information:

Available only in Download Mode.

Reboot the Printer

ASCII: GS (SPACE)

Hexadecimal: 1D FF

Decimal: 29 255

Ends the load process and reboots the printer. Before executing this command, the printer should have firmware loaded and external switches set to the runtime settings. Application software for downloading should prompt the user to set the external switches and confirm before sending this command. If the downloading was started from a diagnostic, the reboot will cause the printer to reenter download state unless the external switches are changed.

Double Side Printing Commands

There are four types of modes for the printing on the two side thermal paper.

1. Single sided mode which is the same as the 7167 printer.,
2. Double sided mode with single side command.
In this mode the printer receives single sided data until a paper cut command is received. The print data is then automatically divided into two parts where the first part is printed on the front side and the second part prints on the back of the receipt when the knife cut command is sent to the printer. **(Refer Appendix 3 How to make printing pattern from single side to double side.)**
3. Double sided mode with Double side command.
In this mode the application controls the location of the printing. The front or back side of the receipt is selected and the data is sent to the printer. The data is then printed when the knife cut command is sent to the printer.
4. Double side mode with pre-defined data
This setting will allow for the automatic printing of predefined data on the back of the receipt. An example would be terms and conditions. The pre-defined data is preloaded into the printer and when a receipt is printed the predefined data is automatically printed on the back of each receipt.

This thermal receipt printing mode can be selected either printer diagnostics or command (Printer Setting Change: 1F 11 and Select Thermal Printing Mode: 1F 60).

Two Side Printing Capacity

When in double side mode with single side command and double side mode with double side command the paper length is 120 inches. Therefore when the printer is in single side mode it will print an identical length of paper. When the printer is in double side mode with single side mode or double side mode with double side command the receipt length would be 60 inches with printing on the front and back side of the receipt for a total length of 120 inches.

Select Thermal Printing Modes

ASCII: US ' *n*

Hexadecimal: 1F 60 *n*

Decimal: 31 96 *n*

Value of *n*: 0 = Single Sided Mode

1 = Double Sided Mode with Single Side Command

2 = Double Sided Mode with Double Side Command

3 = Double Sided Mode with Pre-defined Data

Default: The selected setting in diagnostic mode

Selects the thermal printing mode: single side or double side mode. If single side mode is selected, thermal printing can only be executed on the front side of the receipt paper. If Double side mode is selected, printing can be executed on the front side and/or backside of the receipt paper.

With selection n=0, printing format is the same as the 7167 printer..

With selection n=1 (Single Side Command), print buffer is first divided into two parts. The first half of the print buffer will be printed on the front side of the receipt and the second half of the print buffer will be printed on the back side of the receipt paper.

(Exception: The command Select Thermal Printing Side and Start Double Sided Printing will be ignored)

With selection n=2 (Double Side Command), the information to printed can be selectively printed on the front or back side of the receipt paper.

When the two side print mode is switched from one mode to Double Side Mode w/Double Side Command, printer's default side is front side.

Sending a 1Fh 62h will print the receipt.

With selection n=3 (Pre-defined data), the pre-defined data is printed on the back side and print data will be printed on the front side.

Back side data will only be printed once for each single receipt. Receipt length is determined by the longer side.

This command is valid only on receipt station.

The Printer Setting Change command (1FH 11H) is used to store setting.

Note

When double side paper auto detection is enabled in diagnostics, this command is ignored depend on combination of paper and print mode. The detail condition is below table.

For 1F 11 60 command sequence, "Ignore" means the setting does not take effect immediately but will be saved to EEPROM

Print mode	Paper	Paper matching status (Bit 5 & 4 of 1F 6C, 1F 6D)	Actual print mode	Warning message print	1F 60 and 1F 11 60 command	Reset of Print mode in ESC @
Single side mode	Single side	01	Single side	No print	Ignore	Ignore
	Double side	01	Single side	No print	Valid	Valid
Double side with single side command	Single side	10	Single side	Print	Ignore	Ignore
	Double side	01	Double side with single side command	No print	Valid	Valid

Double side with double side command	Single side	10	Double side with double side command ^{*note1}	Print	Valid	Valid
	Double side	01	Double side with double side command	No print	Valid	Valid
Double side with predefined data	Single side	10	Double side with predefined data ^{*note} Predefined data is printed on Front side.	Print	Valid	Valid
	Double side	01	Double side with predefined data	No print	Valid	Valid

Select Thermal Printing Side

ASCII: US a *n*

Hexadecimal: 1F 61 *n*

Decimal: 31 97 *n*

Value of *n*: 0 = Front Side

1 = Back Side and

Default: 0 (Front Side)

Selects the thermal printing side: front side or back side in Double Side Mode w/Double Side Command.(1Fh 60h 02h)

This command is valid for subsequent lines.

Exceptions:

The command is enabled only when input is at the beginning of a print line, printer is in Double Side Mode w/ Double Side Command, and receipt station is selected.

If either side is larger than buffer, printer prints out automatically and print buffer is cleared. Thermal printing mode and selected print size are not changed.

If current side is in page mode when this command is received, printer will return to standard mode and clear defined page area before changing sides.

Limitations

Character attributes are not changed when print side is changed

Start Double Sided Printing

ASCII: US b

Hexadecimal: 1F 62

Decimal: 31 98

Start double sided printing.

This command executes if the Thermal Printing Modes, Double Side Mode with Double Side Command is selected (n=2), and receipt station is selected, otherwise, this command is ignored.

Receipt length is determined by the longer side.

If page mode has been selected the printer will return to non page mode command after the data has been printed. If printer is in page mode when this command is received, page mode data will be printed and defined page area will be cleared.

Select or Cancel Upside Down Printing for Double Side Mode

ASCII: US c n

Hexadecimal: 1F 63 n

Decimal: 31 99 n

Value of n: Bit 0 = 0: Cancel Front Side upside down printing

1: Enable Front Side upside down printing

Bit 1 = 0: Cancel Back Side upside down printing

1: Enable Back Side upside down printing

Printing side (Front/Back side) is physical side of printing

Default: 0 (Cancel upside printing for both side)

This command will print the data upside down on the side as defined by n.

Execution of this command doesn't change EEPROM settings.

The Printer Setting Change command (1FH 11H) is used to store setting.

Swap Front Side and Back Side

ASCII: US d *n*

Hexadecimal: 1F 64 *n*

Decimal: 31 100 *n*

Value of *n*: 0: Cancel swap.

1: Swap Front Side and Back Side. Original Front Side data is printed on the back side and the Back Side data is printed on the front side.

Default: 0 (Cancel swap)

This command will swap the front side data and backside data when in Double Side Mode.

Before swapping Front Side and Back Side, the Front Side data is printed by the Front Side thermal head. After swapping, the Front Side data is printed by the Backside thermal head.

Before starting double side printing, only the last received swap front side and backside command is effective.



This command is valid only when Double Side Mode (all 3 double side modes (1Fh 60h 01h, 02h or 03h)) and receipt station are selected.

Execution of this command doesn't change EEPROM settings.

The Printer Setting Change command (1FH 11H) is used to store setting.

Limitation:

For Double Side Mode w/Single Side Command, if Logo is printed immediately before paper cut, after swap, the printing pattern on Front Side (Backside before swap) will have a 41mm blank area.

Before Swapping of Sides**After Swapping of Sides****Download 1-line Top/Bottom/Reprint Message into ROM**

ASCII: US e n k₁ d₁ d₂ ... d_i NUL
Hexadecimal: 1F 65 n k₁ d₁ d₂ ... d_i 0
Decimal: 31 101 n k₁ d₁ d₂ ... d_i 0
Value of n: n: The line number. n = 0,1,2,3,4,5
k₁: The character attribute
d₁, d₂, ... , d_i: Strings of 1-line Text Message. Strings terminated with NUL

This command will download one line of text into flash memory.

The message is used in all Double Side Modes. User can select to automatically add a 1-line/2-line text message at the bottom of the Front Side or/and at top of the Back Side or at the top of the page reprint data after error recovery.

Front Side uses line 0 and line1, and Back Side uses line 2 and line 3.

Printing side (Front/Back side) is logical side of printing.

Logical Front Side is the side that contains the first information to be printed.

Logical Back Side is the side that contains the last information to be printed.

Physical Front side is the side printed by the front thermal head.

Physical Back side is the side printed by the back thermal head.

Lines 4 and 5 are defined as the reprint messages. These lines are printed if they are defined, the reprint message is enabled and an error occurs during the printing of a receipt.

The line number n

n	Message	printing side
0	Bottom Message line 1	Logical Front Side
1	Bottom Message line 2	
2	Top Message line 1	Logical Back Side
3	Top Message line 2	
4	Reprint Message line 1	Physical Front Side
5	Reprint Message line 2	

Setting of Character Attribute

k_1			
Bit 7	0: Italic Mode off		1: Italic Mode on
Bit 6	0: Inverse video mode off		1: Inverse video mode on
Bit 5	0: Black		1: Color
Bit 4	0: Emphasize mode off		1: Emphasize mode on
Bit 3	0: Double width off		1: Double width on
Bit 2	0: Double height off		1: Double height on
Bit 1&0	Bit1	Bit0	
	0	0	Underline mode off
	0	1	1 dot underline
	1	0	2 dot underline

Data exceeding one line will be ignored.

If command sequence is US e n k NUL, printer will clear the nth line message in flash memory.

If only one line is defined, printer will only print the defined line.

When print data is only one side data, Top/Bottom message will not be printed.

Limitation:

1. The following attributes will not be supported: Script mode, Double strike mode, 90° Left/Right Rotation, Print Start Position, Character size
2. Attributes cannot be changed within print line.
3. The printable width for Top/Bottom message is 576 dots (80mm paper), or 424 dots (58mm paper). If 58 mm print width is selected, printer automatically uses compress pitch font to print Top/Bottom/Reprint message.

4. Top/Bottom/Reprint message is printed based on diagnostic setting. If user changes printer setting during printer operation, the current top/bottom/reprint message is not affected unless the message is redefined or printer is restarted

Enable Top/Bottom/Reprint Message

ASCII:	US f n
Hexadecimal:	1F 66 n
Decimal:	31 102 n
Value of n:	Bit 0 = 0: Disable pre-defined bottom message on front side 1: Enable pre-defined bottom message on front side Bit 1 = 0: Disable pre-defined top message on back side 1: Enable pre-defined top message on back side Bit 2 = 0: Disable printing of error message 1: Enable printing of error message
Default:	0 (Disable predefined bottom and top message)

When this function is enabled, printer will automatically add a 1-line or 2-line text message at the bottom/top of front side/backside of receipt.

This command is only valid when Double Side Modes (1Fh 60h 01h , 02h or 03h) (All w/Single Side Command and w/Double Side Command and w/Pre-defined data) and receipt station is selected.

Execution of this command doesn't change EEPROM settings.

The Printer Setting Change command (1FH 11H) is used to store setting.

Select nth Macro

ASCII: US g *n*

Hexadecimal: 1F 67 *n*

Decimal: 31 103 *n*

Value of *n*: 1 to 25

Default: *n* = 1

Select nth macro for definition or execution.

The existing commands to define macro and execute macro are used in conjunction with the US g command which are listed below.

Start or End Macro Definition (GS :)

Execute Macro 1Dh 5Eh(GS ^)

The Macro buffer size is up to 25*2048 bytes. A macro can exceed 2048 bytes, but the total macros size cannot exceed 50 Kbytes.

Printer will not check Macro data validity during Macro definition.

A macro can be nested, but can only be nested 1 Macro deep.

Exception

If GS ^ (Execute Macro) is in Macro data without changing the Macro ID, this Macro will be cleared during first time execution.

Printer will not check whether Macro is nested more than 1 Macro deep during Macro definition. If printer executes a Macro nested with 2 (or more) Macro deep, printer will abort execution before the 2nd deep Macro's execution.

For example, command sequence is

1F 67 03(Select 3rd Macro), 1D 3A(Start/End Macro definition) data... 1F 67 01(Select 1st Macro) ... 1D 5E(Execute selected Macro) data... 1D 3A(End Macro definition)

In this example, Macro #3 is defined, and it will execute Macro #1. However, if the definition of Macro #1 is changed and it is nested with another Macro, printer will abort Macro #3's execution.

Start or End Pre-Defined Back Side Printing Data Definition

ASCII: US h

Hexadecimal: 1F 68

Decimal: 31 104

Starts or ends Pre-Defined Back Side Printing and stored into the flash memory. Pre-defined back side printing definition begins when this command is received during normal operation. A second US h command is required to finalize the definition of the pre-defined data. For example the US h command is issued and then the pre-defined data is sent to the printer and then a second US h command is sent to end the definition of the pre-defined data.

If the printer receives a second "Start or End Pre-Defined Back Side Printing" immediately after previously receiving a "Start or End Pre-Defined Back Side Printing" the printer will clear Pre-Defined Back Side Printing data.

Exceptions:

During definition of pre-defined backside printing data, printer will not check data validity.

If pre-defined backside data definition contains GS : (Start or End Macro Definition), the definition will be cleared during the first execution (when Double Side Mode w/Predefined Backside is selected).

Below commands are ignored in predefined backside data.

1F 60 03 (Select Double Side Mode w/Predefined Backside Data)

1F 65 (Download 1 line Text Message into ROM)

Define Minimum Receipt Length

ASCII: US i *n1 n2*

Hexadecimal: 1F 69 *n1n2*

Decimal: 31 105 *n1 n2*

Value of *n*: Number of dots to be moved from the beginning of the line

Value of *n1*: Remainder after dividing *n* by 256. (0 - 255)

Value of *n2*: Integer after dividing *n* by 256. (0 - 255)

Default: $n1 = 0$

$n2 = 0$

This command defines the minimum receipt length before the printer will print in double side mode. This setting is only enabled for "Double Sided Mode with Single Side Command". (1F 60 01)

If the Set Horizontal and Vertical Minimum Motion Units command (1D 50) is used to change the horizontal and vertical minimum motion units, the parameters of this command (Minimum Receipt Length) will be interpreted accordingly.

Printer will not split receipt into two sides if defined length is less than 23.5mm.

Formulas:

To set minimum receipt length to two inches at the default vertical motion unit of 1/203 inches, send the four-byte string:

US i 150 1

2 inches = $2 \times 203 = 406$, and $406 = (1 \times 256) + 150$.

Notes:

Receipt length in this command refers to the length from top of the receipt to the last valid print line. (excluding Top Margin area and line feeds before knife cut)




Figure: Single side receipt sample

Print a Variable

ASCII: US j n [m, o]

Hexadecimal: 1F 6A n [m, o]

Decimal: 31 106 n [m, o]

Value of n: 1 to 50 (Variable ID), 0 -- Use [m, o]

Value of m, o: These parameters only exist if n = 0

m - 1 to 50 (Variable ID)

o - Fixed length to print 1 to 57

This command will print a selected variable.

If the variable is not defined, this command is ignored.

If number of characters in variable ID is > o then it is truncated and only prints o characters

If number of characters in variable ID is < o then blank space fill printing until length of o is reached

Define a Variable

ASCII: US k n d₁ d₂ ... d_i NUL

Hexadecimal: 1F 6Bn d₁ d₂ ... d_i 0

Decimal: 31 107 n d₁ d₂ ... d_i 0

Value of n: The variable ID. n = 1 to 50

d₁, d₂, ..., d_i: Strings of character data. Strings terminated with NUL

Default: n = 1

Defines the content of the nth Variable.

The maximum data length is 57 bytes.

Variables can be included in the macro and pre-defined backside data.

The defined variables are only saved in RAM. They need to be redefined after a power cycle.

Exceptions:

Variable data can only be characters. If any control code is included, these commands will be ignored.

Notes:

This command doesn't support printing position. In standard mode, printer cannot print data that is higher than current print position. If in page mode, user can use positioning command (1D 24 or 1D 5C) for page mode.

Return Thermal Printing Mode (Batch mode command)

ASCII: US1 *n*

Hexadecimal: 1F 6C *n*

Decimal: 31 108 *n*

Value of *n*: 1 = Thermal printing mode status

Transmits the status specified by *n*. This is a batch mode command which transmits the response after all prior data in the receive buffer has been processed.

Thermal printing mode status

Bit	Off/On	Bin	Decimal	Function
1, 0	-	00	0	Single Side Mode
	-	01	1	Double Side Mode w/Single Command
	-	10	2	Double Side Mode w/Double Command
	-	11	3	Double Side Mode w/Predefined Backside
2	-	0	0	Not defined. Fixed at 0.
3	Off	00	0	Front Side selected (valid only in Double Side Mode w/Double Command)
	On	01	8	Back Side selected (valid only in Double Side Mode w/Double Command)
4,5	-	00	0	Paper detection not finished yet
	-	01	16	Paper and thermal printing mode match
	-	10	32	Paper and thermal printing mode does not match
	-	11	48	Not defined
6	-	0	0	Not defined. Fixed at 0.
7	-	0	0	Not defined. Fixed at 0.

Printing mode	Paper	Bit 5 & 4 status
Single side mode	Single Side	01
	Double Side	01
Double Side Mode w/Single Command	Single Side	10
	Double Side	01
Double Side Mode w/Double Command	Single Side	10
	Double Side	01
Double Side Mode w/Predefined Backside	Single Side	10
	Double Side	01

Return Thermal Printing Mode (Real time command)

ASCII: US m n

Hexadecimal: 1F 6D n

Decimal: 31 109 n

Value of n: 1 = Thermal printing mode status

Transmits the status specified by n when in real time mode

Thermal printing mode status

Bit	Off/On	Bin	Decimal	Function
1, 0	-	00	0	Single Side Mode
	-	01	1	Double Side Mode w/Single Command
	-	10	2	Double Side Mode w/Double Command
	-	11	3	Double Side Mode w/Predefined Backside
2	-	0	0	Not defined. Fixed at 0.
3	Off	00	0	Front Side selected (valid only in Double Side Mode w/Double Command)
	On	01	8	Back Side selected(valid only in Double Side Mode w/Double Command)
4,5	-	00	0	Paper detection not finished yet
	-	01	16	Paper and thermal printing mode match
	-	10	32	Paper and thermal printing mode does not match
	-	11	48	Not defined
6	-	0	0	Not defined. Fixed at 0.
7	-	0	0	Not defined. Fixed at 0.

Printing mode	Paper	Bit 5 & 4 status
Single side mode	Single Side	01
	Double Side	01
Double Side Mode w/Single Command	Single Side	10
	Double Side	01
Double Side Mode w/Double Command	Single Side	10
	Double Side	01
Double Side Mode w/Predefined Backside	Single Side	10
	Double Side	01

Chapter 7: Re-flashing the Printer Firmware

Flash Utility Information

The following instructions provide information on how to use the Flash Utilities provided for the 7167, 7168, 7197, 7198, 7401-K590 and 7342-F306 printers. These instructions cover the utilities provided for Windows 9x/NT/2000 GUI, Windows Command Line, and DOS.

The following are the files which comprise the utilities:

TseFlash.exe – Windows GUI version of the Flash Utility

TseFlash.com – Windows Command Line Flash Utility

Aflash.exe – DOS Command Line Flash Utility

help.bat – Batch file that causes TseFlash.com to display command line options.

msvcrt.dll – Windows system DLL used by TseFlash utility and distributed with it.

mfc42.dll – Microsoft Foundation Class Library DLL used by TseFlash utility and distributed with it.

File Configurations

There are several different kinds of firmware loads that can be sent to the printer:

1. Boot Firmware
2. Main Firmware
3. Single Byte Font
4. Two Byte Receipt Font
5. Two Byte Slip Font

The **Single Byte Font** file has a file extension of **.sfn**. It is the font used for OEM Codepages such as 437, 850, 858, etc. which require only a single byte of data to define the character to be printed.

The **Two Byte Font** files (Separately Defined for Slip & Receipt) have a file extension **.dfn**.

These are used to define Code Pages 932 – Japanese, 936 – Simplified Chinese, 949 – Korean, 950 – Traditional Chinese.

If is very rare for the Single Byte Font to have to be updated. Since there is only enough memory in the printer for one of the Two Byte Fonts to be loaded at any time, the Two Byte Font will typically need to be loaded prior to installation in the appropriate country.

The Font files both Single and Two byte should be loaded into the printer after the Boot and Main firmware have been loaded.

Printer Languages Cross Reference

FONT TYPE	FILENAME	PRINTER	PRINT STATION	DOWNLOAD TYPE
Non Asian	A0106.sfn *	7167	Receipt & Slip	ANK FONT
	EA0111.sfn *	7168	Receipt & Slip	ANK FONT
	EA0111.sfn *	7198	Receipt	ANK FONT
	A0106.sfn *	7197	Receipt	ANK FONT
	ANK.sfn *	K590	Receipt	ANK FONT
	A0106.sfn *	7342-F306	Receipt	ANK FONT
Japanese CP932	A0106.sfn *	7167	Receipt & Slip	ANK FONT
	J0104.dfn *	7167	Receipt	RECEIPT ASIAN FONT
	J0106_s.dfn *	7167	Slip	SLIP ASIAN FONT
	EA0111.sfn *	7168	Receipt & Slip	ANK FONT
	EA0111.sfn *	7198	Receipt	ANK FONT
	EJ104.dfn *	7168/7198	Receipt	RECEIPT ASIAN FONT
	EJ106_s.dfn *	7168	Slip	SLIP ASIAN FONT
	SamJ0100.dfn *	7197	Receipt	RECEIPT ASIAN FONT
	ANK.sfn *	K590	Receipt	ANK FONT
	J0103.dfn *	K590	Receipt	RECEIPT ASIAN FONT
	PARKJV20.dfn *	7342-F306	Receipt	RECEIPT ASIAN FONT
Korean CP949	A0106.sfn *	7167	Receipt & Slip	ANK FONT
	K0103.dfn	7167	Receipt	RECEIPT ASIAN FONT
	K0101_s.dfn	7167	Slip	SLIP ASIAN FONT
	EA0111.sfn *	7168	Receipt & Slip	ANK FONT
	EA0111.sfn *	7198	Receipt	ANK FONT
	EK103.dfn *	7168/7198	Receipt	RECEIPT ASIAN FONT
	EK0101_s.dfn *	7168	Slip	SLIP ASIAN FONT
	A0106.sfn *	7197	Receipt	ANK FONT
	K0103.dfn	7197	Receipt	RECEIPT ASIAN FONT
	ANK.sfn *-	K590	Receipt	ANK FONT
	K0103.dfn	K590	Receipt	RECEIPT ASIAN FONT
	A0106.sfn *	7342-F306	Receipt	ANK FONT
	K0103.dfn	7342-F306	Receipt	RECEIPT ASIAN FONT
	Simple Chinese CP936	A0106.sfn *	7167	Receipt & Slip
S0102.dfn		7167	Receipt	RECEIPT ASIAN FONT
S0102_s.dfn		7167	Slip	SLIP ASIAN FONT
EA0111.sfn *		7168	Receipt & Slip	ANK FONT
EA0111.sfn *		7198	Receipt	ANK FONT
ES0102.dfn *		7168/7198	Receipt	RECEIPT ASIAN FONT
ES0102_s.dfn *		7168	Slip	SLIP ASIAN FONT
A0106.sfn *		7197	Receipt	ANK FONT
S0102.dfn		7197	Receipt	RECEIPT ASIAN FONT
ANK.sfn *		K590	Receipt	ANK Font
S0102.dfn		K590	Receipt	RECEIPT ASIAN FONT
A0106.sfn *		7342-F306	Receipt	ANK FONT
S0102.dfn		7342-F306	Receipt	RECEIPT ASIAN FONT

FONT TYPE	FILENAME	PRINTER	PRINT STATION	DOWNLOAD TYPE
Traditional Chinese	A0106.sfn *	7167	Receipt & Slip	ANK FONT
CP950	T0102.dfn	7167	Receipt	RECEIPT ASIAN FONT
	TC0101_s.dfn	7167	Slip	SLIP ASIAN FONT
	EA0111.sfn *	7168	Receipt & Slip	ANK FONT
	EA0111.sfn *	7198	Receipt	ANK FONT
	ET0102.dfn *	7168/7198	Receipt	RECEIPT ASIAN FONT
	ET0101_s.dfn *	7168	Slip	SLIP ASIAN FONT
	A0106.sfn *	7197	Receipt	ANK FONT
	T0102.dfn	7197	Receipt	RECEIPT ASIAN FONT
	ANK.sfn *	K590	Receipt	ANK FONT
	T0102.dfn	K590	Receipt	RECEIPT ASIAN FONT
	A0106.sfn *	7342-F306	Receipt	ANK FONT
	T0102.dfn	7342-F306	Receipt	RECEIPT ASIAN FONT

Note:

1. The noted font files are include on LPIN A370-0050-0000 or are available from the NCR web site under Retail Solution Specific Printer Firmware.
2. EA0111.sfn contains receipt and slip ANK fonts.
3. The * denotes that the printer is preloaded with these fonts from the factory. The exception is that the 7342-F306 with version 0.32 and later version is not preloaded with CP932 Japanese font. Please take note that the 7342-F306 with version 0.33 and later version does not support CP932 Japanese compressed font.
4. When Asian fonts are to be used select the appropriate Asian Code Page in the diagnostic set and also enable the Asian Mode.

DOS Flash Utility

The DOS flash utility is intended for use from a DOS Boot only. It is mainly provided for remote flash capabilities by providing a way to create a DOS Boot Image that will automatically load and flash update the printer firmware without user intervention.

If you type AFLASH.EXE without any parameters you will get the following screen that describes the parameter usage:

```

Flash Memory Writer V2.11
Usage: AFLASH.EXE <model> <type> <port> <baud rate> <filename>
Options:
  <model>      : K590, 7167, 7197, 7167-X035, 7167-X115, 7168,
                7168-X122, 7198, 7342-F306, 7346-F306 , 734X-F307
  <type>
  -m          : Download main firmware program
  -i          : Download ipl firmware program
  -a          : Download ANK single byte font
  -s          : Download ASIAN two byte font
  -rs        : Download receipt ASIAN two byte
                font
  -ss        : Download slip ASIAN two byte font
  -sb        : Download SBCS CG Font
  -db        : Download DBCS CG Font
  <port>      : COM1, COM2
  <baud rate> : 1200, 2400, 4800, 9600, 19200, 38400, 57600,
                115200
  <filename>  : *.mfw | *.ipl | *.sfn | *.dfn

```

An example of a command line for updating the Main Firmware on a 7168 printer is as follows:

```
AFLASH.EXE 7198 -m COM1 115200 DSV3502.MFW
```

NOTE: The DOS version of the Flash Utility can only be used for printers that are connected on COM1 or COM2. The current version of the utility does not function for COM ports higher than 2.

If an error is encountered, the Usage information will be dumped to the screen followed by a status line that displays information along such as:

```
Error : Unable to open data file!
```

```
Error : Invalid parameter <com>!
```

Windows Command Line Firmware Update Utility

The Windows Command Line version of the Flash Utility is provided to allow batch mode of operation in a Windows 95/98/NT4/2000 environment. If you issue a call to **TseFlash.com** with the **/?** parameter you will get the following out put that explains the parameters.

NOTE: This utility requires the **TseFlash.exe** to be in the same directory. **TseFlash.com** is just a shell that sends the command line options to **TseFlash.exe** to process.

```
*****
*** TseFlash.com Ver 2.02 ***
```

```
Thank you for using TseFlash Flash Memory Writer command line interface utility!
```

```
Error: Usage: No Parameters attempt to be sent to TSEFLASH.EXE!
```

```
TseFlash [model] [file type] [COM] [baud] [parity] [stop] [file] [check model] [print(opt)]
[ErrorTimeOut(opt) 420 - 1800s]
```

```
Selections for the model:
```

```
/[K590] [7402-K592] [7167] [7197] [7167-X035] [7342-F306] [7346-F306] [7167-X115]
[7168] [7168-X122][7198][734X-F307]
```

```
Selections for the download type:
```

```
/m      Download firmware main program.
/i      Download firmware IPL program.
/a      Download ANK font or combined ANK & CP932 font
        for 7197/7342-F306/7346-F306/7168/7168-X122/7198.
/s      Download ASIAN font for K590/7402-K592/7197/7342-F306/7346-F306
        except 7197/7342-F306 combined ANK & CP932 font, 7167-X115
/rs     Download receipt ASIAN font for 7167,7168,7168-X122,7198, except 7167-
X035 & 7167-X115
/ss     Download slip ASIAN font for 7167,7168,7168-X122,except 7167-X035 &
7167-X115
/sb     Download SBCS font for 734X-F307
/db     Download DBCS font for 734X-F307
```

```
Selections for the COM port or CPMI:
```

```
/COMX   Where X is any valid integer within 1-20.
```

```
Selections for the baud rate (for RS232 Only):
```

```
/[115200] | [57600] | [38400] | [19200] | [9600] | [4800] | [2400] | [1200]
```

```
Selections for the parity bit (for RS232 Only): /[none] | [even] | [odd]
```

```
Selections for the stop bit (for RS232 Only): /[1] | [2]
```

```
Selections for the filename :
```

```
Any valid binary file with extension *.mfw | *.sfn | *.dfn | *.ipl.
```

```
Selections for the check model:
```

```
/skip   Bypass checking printer model number.
```

```
/noskip Check printer model number & exit when there's a mismatch.
```

```
Selections for the print: (Optional Parameter)
```

```
/print   (default) Print printer configuration form.
```

```
/noprint Bypass printing printer configuration form.
```

```
Failsafe: Max Time Allowed for Called Exe: (Optional Parameter)
```

```
(ONLY USED BY TseFlash.COM
```

```
  /ErrorTimeOut=xxx (minimum=420) xxx is number of Seconds - limit 1800.
```

If you fail to use the correct parameters an error message will be displayed similar to the one below.

Error : Too few / many command line parameters!

The following is an example of a command line:

```
TseFlash.com /7198 /m /COM1 /115200 /none /1 DSV3502.MFW
```

This invokes the GUI interface shown in the next section, and displays a progress bar indicator as you would see if you had run the program through the GUI. Windows GUI Printer Firmware Update Utility

The printer firmware can be updated from the host terminal, a laptop, or a PC by executing the TSEFlash.exe utility. There are two file formats for the flash firmware, IPL which is for the Initial Program Load (Boot) and the MFW, Main FirmWare.

Examples of the firmware are:

```
DSV1101.ipl 7198 boot firmware  
DSV3502.mfw 7198 firmware
```


As noted this is an example and firmware version will vary as updates are provided.

These instruction show how to reflash a 7198 printer. However the same instructions can be used for reflashing other printers as well by selection the appropriate printer in the Change Mode button.


Unzip the flash utility (Flash311) and the flash files that you will be using into a directory on your hard disk.

Using TseFlash.exe Utility


On the host terminal or PC running Windows, execute the utility TSEFlash.exe to start the program. A window similar to the example below will appear on the screen.




Click on the button indicated by the red arrow to display the dropdown box. From the list, click on the printer type to be flashed. Select **7198** from the list for this printer.




Next, click on the "Select" button indicated by the red arrow. This will permit you to continue by making the remaining options available.




At this point, any of the properties in the red box can be changed. Clicking on the button to the right of the property (red arrow) will display the drop-down box with options available for the associated property.




There are only two options in the "Download Type" property drop-down box to be concerned with. *Main FIRMWARE* is used to flash the main firmware file and *IPL FIRMWARE* is used to flash the boot firmware. The utility also provides the ability to download various font files that use the noted file extensions.




Select the COM port being used on the PC or host device to flash the printer. The flash utility will be running on this PC.




Select the printer baud rate setting. Make certain that that the COM port selected on the host device will support 115,200 baud. The utility will reset the printer baud rate to 115,200 baud flash the printer and then reset the baud rate back to the baud rate that was originally selected.




From the Parity type, select None, Odd, or Even to match this setting on the printer.




Again, match this property to this setting in the printer.




Once all the Properties are configured to match the printer settings, it is time to select the binary file to load into the printer firmware. Click on the "Browse" button to make this selection.




If "MAIN FIRMWARE" was selected as the Download Type, the search window will default to Main Firmware Files with a .mfw extension.







If "IPL FIRMWARE" was selected as the Download Type, the search window will default to IPL Program Files with a .ipl extension.








With the desired file selected and all properties set to the correct values, click on the "FLASH NOW" button to start the download process.



Once you start the flash process, a series of windows similar to the example shown here will appear.



The flash sectors on this screen may vary depending on the quantity of sectors to be flashed.



Appendix A: Specifications

Printing Specifications

	Thermal Receipt Station
Print head	Fixed 576 Print Elements Direct Thermal Fixed Heads Line of Dots
Character Cell	Standard: 13 x 24 Dots Compressed: 10 x 24 Dots
Character Size	.0525" Wide by .092" High
Character Spacing	15.25 Characters per Inch (horizontal)
Character Pitch	15.6 Characters/Inch (Standard) 20.3 Characters/Inch (Compressed)
Columns (maximum)	For 80 mm paper: 44 Columns (Standard) 56 Columns (Compressed) For 58 mm paper: 32 Columns (Standard) 42 Columns (Compressed)
Print Mode	Standard, Compressed, Double High, Double Wide, Upside Down, Rotated, Underline, Scalable, Bold, Superscript, Italic, Subscript
Resident Fonts	Code Page 437, 850, 852, 860, 863, 865, 858, 866, 1252, Katakana, 874, 862, 864, and Space page
Speed	3019 Lines / Minute (44 columns) maximum, Depend on Line Spacing
Print Order	Descending
Line Spacing	7.52 Lines per Inch (default) 8.47, 8.13, 7.81, 7.25, 7.00, 5.98 Lines / Inch and variable lines per inch.
Slew Speed	6.7 Inches per Second
Print Zone	2.83 Inches Maximum

Thermal Receipt Station	
Noise	57 dBA Sound Pressure (ISO 7779)
Graphics (Optional)	User-Defined Graphics, Logo
Other	No Reverse Paper Feed

Thermal Receipt Station	
Paper Diameter	80 mm Max.
Paper Length	83 Meters (273 feet)
Paper Width	80 mm \pm 1mm (3.15 Inches \pm .02 Inches)
Paper Thickness	Not Applicable
Printable Area	2.83 Inches (Max.)

Power Requirements

The 7198 printer receives power from a separate power supply. Here are the voltage requirements for the power supply.

Voltage	Station	Maximum Current	
		Short Term	Long Term
24.0 V \pm 10%	Receipt	6.5 Amps	3.15 Amps

Environmental Conditions

Operating Temperature	5°C to 45°C (40°F to 112°F), models with knife
	5°C to 50°C (40°F to 120°F), models with no knife
Operating Humidity	5% to 90%

Condensation may occur when equipment is transferred from cold to warm areas after shipment. The printer's design permits operation after drying out and stabilizing at room temperature.

Reliability

The numbers in the table refer to the Mean Cycle Between Failure (MCBF) for the items indicated.

Thermal Receipt Printer	52 Million Lines
Electronics	460,000 On time Hours
Communications Card	1,300,000 On Time Hours
Control Panel	33,000,000 On Time Hours
Knife	1 Million Cuts
Power Supply	200,000 On-time Hours

*Reliability statistics based on averages exhibited under lab conditions and do not constitute a warranty.

Dimensions and Weight

Height	139.00 mm (5.5 Inches)
Height with Cover Open	256.00 mm (10.1 Inches)
Width	145.40 mm (5.7 Inches)
Depth	220.00 mm (8.7 Inches)
Weight	2.20 Kg (4.85 Pounds)

Density of Receipt Print Lines

When the receipt station prints high density print lines (graphics), it automatically slows down to a rate slower than 902 lines per minute. High density print lines are defined as lines with over 50% of the dots printing on the line (there are 576 total dot columns on the print station).

Duty Cycle Restrictions (Printing Solid Blocks)

There are restrictions on the duty cycle because of the heat generated by the receipt thermal print head when printing solid blocks (regardless of the length of the block in relation to the print line). The restrictions are ambient temperature, the percentage of time (measured against one minute) of continuous solid printing, and the amount of coverage.

Caution: When the duty cycle approaches the limits shown in the table, the receipt print head will heat up and shut down. This may damage the print head.

To avoid this problem, do one or a combination of the following:

1. Reduce the amount of coverage.
2. Reduce the time of continuous solid printing.
3. Reduce the ambient temperature.

Amount of Solid Coverage	Ambient Temperature		
	25° C	35° C	50° C
20%	100% of 1 min. continuous printing	50% of 1 min. continuous printing	20% of 1 min. continuous printing
40%	50% of 1 min. continuous printing	25% of 1 min. continuous printing	10% of 1 min. continuous printing
100%	20% of 1 min. continuous printing	10% of 1 min. continuous printing	3% of 1 min. continuous printing

Above data is for Single side printing mode only.

Appendix B: Print Characteristics


Character Size

This section shows the dot pattern for characters printed on the receipt station.

Receipt Station


The following two illustrations show the dot patterns of sample characters for standard pitch (15.6 CPI) and compressed pitch (20.3 CPI). Note that compressed pitch uses fewer dots horizontally than standard pitch.

Standard Pitch



- B - Upper Case
- m - Lower Case
- g - With Descender
- Ö - With Ascender
- \$ - Both Ascender and Desender
- # - Graphic Symbol

203 DPI, 15.6 CPI Pitch (Standard)



Print Zones

This section shows the printable area for the receipt station.


Receipt Station

For 80 mm Paper


The receipt station centers characters (standard pitch and compressed pitch) and graphics on an 80 mm wide (3.15 inches) receipt.

- Standard pitch: 13 x 24 dots in character cell, 44 characters (columns) per line
- Compressed pitch: 10 x 24 dots in character cell, 56 characters (columns) per line
- Double byte character: 24 x 24 dots in character cell, 24 characters (columns) per line
- Graphics: 576 addressable bits

The minimum print line height is 24 dots for characters and 24 dots for graphics. The standard print line height is 27 dots (3.38 mm, .133 inches) for characters (with three extra dot rows). See the following illustration (not to scale).



When Print information in previous transaction, printable are as follows




For 58 mm Paper


The receipt station centers characters (standard pitch and compressed pitch) and graphics on an 58 mm wide (2.28 inches) receipt.

- Standard pitch: 13 x 24 dots in character cell, 32 characters (columns) per line
- Compressed pitch: 10 x 24 dots in character cell, 42 characters (columns) per line
- Double byte character: 24 x 24 dots in character cell, 17 characters (columns) per line
- Graphics: 424 addressable bits

The minimum print line height is 24 dots for characters and 24 dots for graphics. The standard print line height is 27 dots (3.38 mm, .133 inches) for characters (with three extra dot rows). See the following illustration (not to scale).



When Print information in previous transaction, printable are as follows



Character Sets

The following pages show the character sets.

- PC Code Page 437 (US)
- PC Code Page 850 (Multilingual)
- PC Code Page 852 (Slavic)
- PC Code Page 860 (Portuguese)
- PC Code Page 862 (Hebrew)
- PC Code Page 863 (French-Canadian)
- PC Code Page 864 (Arabic)
- PC Code Page 865 (Nordic)
- PC Code Page 866 (Cyrillic)
- PC Code Page 1252 (Windows Latin #1)

- PC Code Page Katakana
- PC Code Page 874 (Thai)
- Space Page
- Code Page 932
- Code Page 936
- Code Page 949
- Code Page 950

Code Page 950 Code Page 437, 850, 852 and 858

Code Page 437.

	2	3	4	5	6	7	8	9	A	B	C	D	E	F
00	0	@	P	`	p	Ç	É	á	∴	L	∟	∟	∟	∟
01	!	1	A	Q	a	q	Û	æ	í	ó	∴	∟	∟	∟
02	"	2	B	R	b	r	é	Æ	ó	∴	∟	∟	∟	∟
03	#	3	C	S	c	s	â	ô	ú	ñ	∟	∟	∟	∟
04	\$	4	D	T	d	t	ä	ö	ñ	∟	∟	∟	∟	∟
05	%	5	E	U	e	u	à	ò	ñ	∟	∟	∟	∟	∟
06	&	6	F	V	f	v	â	ü	∴	∟	∟	∟	∟	∟
07	'	7	G	W	g	w	ç	ù	∴	∟	∟	∟	∟	∟
08	(8	H	X	h	x	ê	ÿ	∴	∟	∟	∟	∟	∟
09)	9	I	Y	i	y	ë	ÿ	∴	∟	∟	∟	∟	∟
0A	*	:	J	Z	j	z	è	ÿ	∴	∟	∟	∟	∟	∟
0B	+	;	K	[k	{	í	∴	∟	∟	∟	∟	∟	∟
0C	,	<	L	\	l		í	∴	∟	∟	∟	∟	∟	∟
0D	-	=	M]	m	}	í	∴	∟	∟	∟	∟	∟	∟
0E	.	>	N	^	n	~	∴	∟	∟	∟	∟	∟	∟	∟
0F	/	?	0	_	o	o	∴	∟	∟	∟	∟	∟	∟	∟

Code Page 850.

	2	3	4	5	6	7	8	9	A	B	C	D	E	F
00	0	@	P	`	p	Ç	É	á	∴	L	∟	∟	∟	∟
01	!	1	A	Q	a	q	Û	æ	í	ó	∴	∟	∟	∟
02	"	2	B	R	b	r	é	Æ	ó	∴	∟	∟	∟	∟
03	#	3	C	S	c	s	â	ô	ú	ñ	∟	∟	∟	∟
04	\$	4	D	T	d	t	ä	ö	ñ	∟	∟	∟	∟	∟
05	%	5	E	U	e	u	à	ò	ñ	∟	∟	∟	∟	∟
06	&	6	F	V	f	v	â	ü	∴	∟	∟	∟	∟	∟
07	'	7	G	W	g	w	ç	ù	∴	∟	∟	∟	∟	∟
08	(8	H	X	h	x	ê	ÿ	∴	∟	∟	∟	∟	∟
09)	9	I	Y	i	y	ë	ÿ	∴	∟	∟	∟	∟	∟
0A	*	:	J	Z	j	z	è	ÿ	∴	∟	∟	∟	∟	∟
0B	+	;	K	[k	{	í	∴	∟	∟	∟	∟	∟	∟
0C	,	<	L	\	l		í	∴	∟	∟	∟	∟	∟	∟
0D	-	=	M]	m	}	í	∴	∟	∟	∟	∟	∟	∟
0E	.	>	N	^	n	~	∴	∟	∟	∟	∟	∟	∟	∟
0F	/	?	0	_	o	o	∴	∟	∟	∟	∟	∟	∟	∟

Code Page 852.

	2	3	4	5	6	7	8	9	A	B	C	D	E	F
00	0	@	P	`	p	Ç	É	á	∴	L	∟	∟	∟	∟
01	!	1	A	Q	a	q	Û	æ	í	ó	∴	∟	∟	∟
02	"	2	B	R	b	r	é	Æ	ó	∴	∟	∟	∟	∟
03	#	3	C	S	c	s	â	ô	ú	ñ	∟	∟	∟	∟
04	\$	4	D	T	d	t	ä	ö	ñ	∟	∟	∟	∟	∟
05	%	5	E	U	e	u	à	ò	ñ	∟	∟	∟	∟	∟
06	&	6	F	V	f	v	â	ü	∴	∟	∟	∟	∟	∟
07	'	7	G	W	g	w	ç	ù	∴	∟	∟	∟	∟	∟
08	(8	H	X	h	x	ê	ÿ	∴	∟	∟	∟	∟	∟
09)	9	I	Y	i	y	ë	ÿ	∴	∟	∟	∟	∟	∟
0A	*	:	J	Z	j	z	è	ÿ	∴	∟	∟	∟	∟	∟
0B	+	;	K	[k	{	í	∴	∟	∟	∟	∟	∟	∟
0C	,	<	L	\	l		í	∴	∟	∟	∟	∟	∟	∟
0D	-	=	M]	m	}	í	∴	∟	∟	∟	∟	∟	∟
0E	.	>	N	^	n	~	∴	∟	∟	∟	∟	∟	∟	∟
0F	/	?	0	_	o	o	∴	∟	∟	∟	∟	∟	∟	∟

Code Page 858.

	2	3	4	5	6	7	8	9	A	B	C	D	E	F
00	0	@	P	`	p	Ç	É	á	∴	L	∟	∟	∟	∟
01	!	1	A	Q	a	q	Û	æ	í	ó	∴	∟	∟	∟
02	"	2	B	R	b	r	é	Æ	ó	∴	∟	∟	∟	∟
03	#	3	C	S	c	s	â	ô	ú	ñ	∟	∟	∟	∟
04	\$	4	D	T	d	t	ä	ö	ñ	∟	∟	∟	∟	∟
05	%	5	E	U	e	u	à	ò	ñ	∟	∟	∟	∟	∟
06	&	6	F	V	f	v	â	ü	∴	∟	∟	∟	∟	∟
07	'	7	G	W	g	w	ç	ù	∴	∟	∟	∟	∟	∟
08	(8	H	X	h	x	ê	ÿ	∴	∟	∟	∟	∟	∟
09)	9	I	Y	i	y	ë	ÿ	∴	∟	∟	∟	∟	∟
0A	*	:	J	Z	j	z	è	ÿ	∴	∟	∟	∟	∟	∟
0B	+	;	K	[k	{	í	∴	∟	∟	∟	∟	∟	∟
0C	,	<	L	\	l		í	∴	∟	∟	∟	∟	∟	∟
0D	-	=	M]	m	}	í	∴	∟	∟	∟	∟	∟	∟
0E	.	>	N	^	n	~	∴	∟	∟	∟	∟	∟	∟	∟
0F	/	?	0	_	o	o	∴	∟	∟	∟	∟	∟	∟	∟

Code Page 860, 862, 863 and 864

Code Page 860.

	2	3	4	5	6	7	8	9	A	B	C	D	E	F
00	0	@	P	`	p	Ç	É	à	í	ü	ü	ü	ü	ü
01	!	1	A	Q	a	ç	é	á	í	ó	ü	ü	ü	ü
02	"	2	B	R	b	r	ê	â	ó	ô	ñ	ü	ü	ü
03	#	3	C	S	c	s	â	ô	ú	ñ	ü	ü	ü	ü
04	\$	4	D	T	d	t	â	ô	ú	ñ	ü	ü	ü	ü
05	%	5	E	U	e	u	â	ô	ú	ñ	ü	ü	ü	ü
06	&	6	F	V	f	v	â	ô	ú	ñ	ü	ü	ü	ü
07	'	7	G	W	g	w	ç	ê	î	ï	ü	ü	ü	ü
08	(8	H	X	h	x	ê	î	ï	ö	ü	ü	ü	ü
09)	9	I	Y	i	y	ê	î	ï	ö	ü	ü	ü	ü
0A	*	:	J	Z	j	z	ê	î	ï	ö	ü	ü	ü	ü
0B	+	;	K	[k	{	î	ï	ö	ü	ü	ü	ü	ü
0C	,	<	L	\	l		î	ï	ö	ü	ü	ü	ü	ü
0D	-	=	M]	m	}	î	ï	ö	ü	ü	ü	ü	ü
0E	.	>	N	^	n	~	î	ï	ö	ü	ü	ü	ü	ü
0F	/	?	O	_	o	¸	î	ï	ö	ü	ü	ü	ü	ü

Code Page 862

	2	3	4	5	6	7	8	9	A	B	C	D	E	F
00	0	@	P	`	p	ç	é	à	í	ü	ü	ü	ü	ü
01	!	1	A	Q	a	ç	é	á	í	ó	ü	ü	ü	ü
02	"	2	B	R	b	r	ê	â	ó	ô	ñ	ü	ü	ü
03	#	3	C	S	c	s	â	ô	ú	ñ	ü	ü	ü	ü
04	\$	4	D	T	d	t	â	ô	ú	ñ	ü	ü	ü	ü
05	%	5	E	U	e	u	â	ô	ú	ñ	ü	ü	ü	ü
06	&	6	F	V	f	v	â	ô	ú	ñ	ü	ü	ü	ü
07	'	7	G	W	g	w	ç	ê	î	ï	ü	ü	ü	ü
08	(8	H	X	h	x	ê	î	ï	ö	ü	ü	ü	ü
09)	9	I	Y	i	y	ê	î	ï	ö	ü	ü	ü	ü
0A	*	:	J	Z	j	z	ê	î	ï	ö	ü	ü	ü	ü
0B	+	;	K	[k	{	î	ï	ö	ü	ü	ü	ü	ü
0C	,	<	L	\	l		î	ï	ö	ü	ü	ü	ü	ü
0D	-	=	M]	m	}	î	ï	ö	ü	ü	ü	ü	ü
0E	.	>	N	^	n	~	î	ï	ö	ü	ü	ü	ü	ü
0F	/	?	O	_	o	¸	î	ï	ö	ü	ü	ü	ü	ü

Code Page 863.

	2	3	4	5	6	7	8	9	A	B	C	D	E	F
00	0	@	P	`	p	Ç	É	à	í	ü	ü	ü	ü	ü
01	!	1	A	Q	a	ç	é	á	í	ó	ü	ü	ü	ü
02	"	2	B	R	b	r	ê	â	ó	ô	ñ	ü	ü	ü
03	#	3	C	S	c	s	â	ô	ú	ñ	ü	ü	ü	ü
04	\$	4	D	T	d	t	â	ô	ú	ñ	ü	ü	ü	ü
05	%	5	E	U	e	u	â	ô	ú	ñ	ü	ü	ü	ü
06	&	6	F	V	f	v	â	ô	ú	ñ	ü	ü	ü	ü
07	'	7	G	W	g	w	ç	ê	î	ï	ü	ü	ü	ü
08	(8	H	X	h	x	ê	î	ï	ö	ü	ü	ü	ü
09)	9	I	Y	i	y	ê	î	ï	ö	ü	ü	ü	ü
0A	*	:	J	Z	j	z	ê	î	ï	ö	ü	ü	ü	ü
0B	+	;	K	[k	{	î	ï	ö	ü	ü	ü	ü	ü
0C	,	<	L	\	l		î	ï	ö	ü	ü	ü	ü	ü
0D	-	=	M]	m	}	î	ï	ö	ü	ü	ü	ü	ü
0E	.	>	N	^	n	~	î	ï	ö	ü	ü	ü	ü	ü
0F	/	?	O	_	o	¸	î	ï	ö	ü	ü	ü	ü	ü

Code Page 864

	2	3	4	5	6	7	8	9	A	B	C	D	E	F
00	0	@	P	`	p	ç	é	à	í	ü	ü	ü	ü	ü
01	!	1	A	Q	a	ç	é	á	í	ó	ü	ü	ü	ü
02	"	2	B	R	b	r	ê	â	ó	ô	ñ	ü	ü	ü
03	#	3	C	S	c	s	â	ô	ú	ñ	ü	ü	ü	ü
04	\$	4	D	T	d	t	â	ô	ú	ñ	ü	ü	ü	ü
05	%	5	E	U	e	u	â	ô	ú	ñ	ü	ü	ü	ü
06	&	6	F	V	f	v	â	ô	ú	ñ	ü	ü	ü	ü
07	'	7	G	W	g	w	ç	ê	î	ï	ü	ü	ü	ü
08	(8	H	X	h	x	ê	î	ï	ö	ü	ü	ü	ü
09)	9	I	Y	i	y	ê	î	ï	ö	ü	ü	ü	ü
0A	*	:	J	Z	j	z	ê	î	ï	ö	ü	ü	ü	ü
0B	+	;	K	[k	{	î	ï	ö	ü	ü	ü	ü	ü
0C	,	<	L	\	l		î	ï	ö	ü	ü	ü	ü	ü
0D	-	=	M]	m	}	î	ï	ö	ü	ü	ü	ü	ü
0E	.	>	N	^	n	~	î	ï	ö	ü	ü	ü	ü	ü
0F	/	?	O	_	o	¸	î	ï	ö	ü	ü	ü	ü	ü

Code Page 865, 866, 874 and 1252

Code Page 865.

	2	3	4	5	6	7	8	9	A	B	C	D	E	F
00	0	@	P	`	p	Ç	É	á	â	ã	ä	å	æ	ç
01	!	1	A	Q	a	q	Ë	í	ï	ï	ï	ï	ï	ï
02	"	2	B	R	b	r	Ê	ó	õ	ö	÷	ø	ù	ú
03	#	3	C	S	c	s	Ë	ñ	ñ	ñ	ñ	ñ	ñ	ñ
04	\$	4	D	T	d	t	Ë	ñ	ñ	ñ	ñ	ñ	ñ	ñ
05	%	5	E	U	e	u	Ë	ñ	ñ	ñ	ñ	ñ	ñ	ñ
06	&	6	F	V	f	v	Ë	ñ	ñ	ñ	ñ	ñ	ñ	ñ
07	'	7	G	W	g	w	Ë	ñ	ñ	ñ	ñ	ñ	ñ	ñ
08	(8	H	X	h	x	Ë	ñ	ñ	ñ	ñ	ñ	ñ	ñ
09)	9	I	Y	i	y	Ë	ñ	ñ	ñ	ñ	ñ	ñ	ñ
0A	*	:	J	Z	j	z	Ë	ñ	ñ	ñ	ñ	ñ	ñ	ñ
0B	+	;	K	[k	{	Ë	ñ	ñ	ñ	ñ	ñ	ñ	ñ
0C	,	<	L	\	l		Ë	ñ	ñ	ñ	ñ	ñ	ñ	ñ
0D	-	=	M]	m	}	Ë	ñ	ñ	ñ	ñ	ñ	ñ	ñ
0E	.	>	N	^	n	~	Ë	ñ	ñ	ñ	ñ	ñ	ñ	ñ
0F	/	?	0	_	o	ð	Ë	ñ	ñ	ñ	ñ	ñ	ñ	ñ

Code Page 866.

	2	3	4	5	6	7	8	9	A	B	C	D	E	F
00	0	@	P	`	p	А	Р	а	б	в	г	д	е	ё
01	!	1	A	Q	a	q	Б	С	Т	У	Г	Д	Е	Ё
02	"	2	B	R	b	r	В	С	Т	У	Г	Д	Е	Ё
03	#	3	C	S	c	s	Г	У	Г	У	Г	Д	Е	Ё
04	\$	4	D	T	d	t	Д	Ф	Х	Ц	Ж	Ш	Щ	Ъ
05	%	5	E	U	e	u	Е	Х	Ц	Ж	Ш	Щ	Ъ	Ъ
06	&	6	F	V	f	v	Ж	Ц	Ж	Ш	Щ	Ъ	Ъ	Ъ
07	'	7	G	W	g	w	З	Ш	И	Й	Э	Ю	Я	Я
08	(8	H	X	h	x	И	Ш	И	Й	Э	Ю	Я	Я
09)	9	I	Y	i	y	Й	Ш	И	Й	Э	Ю	Я	Я
0A	*	:	J	Z	j	z	К	Ъ	К	Ъ	К	Ъ	К	Ъ
0B	+	;	K	[k	{	Л	Ы	Л	Ы	Л	Ы	Л	Ы
0C	,	<	L	\	l		М	Ы	М	Ы	М	Ы	М	Ы
0D	-	=	M]	m	}	Н	Э	Н	Э	Н	Э	Н	Э
0E	.	>	N	^	n	~	О	Ю	О	Ю	О	Ю	О	Ю
0F	/	?	0	_	o	ð	П	Я	П	Я	П	Я	П	Я

Code Page 874.

	2	3	4	5	6	7	8	9	A	B	C	D	E	F
00	0	@	P	`	p									
01	!	1	A	Q	a	q								
02	"	2	B	R	b	r								
03	#	3	C	S	c	s								
04	\$	4	D	T	d	t								
05	%	5	E	U	e	u								
06	&	6	F	V	f	v								
07	'	7	G	W	g	w								
08	(8	H	X	h	x								
09)	9	I	Y	i	y								
0A	*	:	J	Z	j	z								
0B	+	;	K	[k	{								
0C	,	<	L	\	l									
0D	-	=	M]	m	}								
0E	.	>	N	^	n	~								
0F	/	?	0	_	o	ð								

Code Page 1252.

	2	3	4	5	6	7	8	9	A	B	C	D	E	F
00	0	@	P	`	p	€			À	Á	Â	Ã	Ä	Å
01	!	1	A	Q	a	q			Á	Ñ	À	á	ñ	ò
02	"	2	B	R	b	r			À	Ñ	À	á	ñ	ò
03	#	3	C	S	c	s			À	Ñ	À	á	ñ	ò
04	\$	4	D	T	d	t			À	Ñ	À	á	ñ	ò
05	%	5	E	U	e	u			À	Ñ	À	á	ñ	ò
06	&	6	F	V	f	v			À	Ñ	À	á	ñ	ò
07	'	7	G	W	g	w			À	Ñ	À	á	ñ	ò
08	(8	H	X	h	x			À	Ñ	À	á	ñ	ò
09)	9	I	Y	i	y			À	Ñ	À	á	ñ	ò
0A	*	:	J	Z	j	z			À	Ñ	À	á	ñ	ò
0B	+	;	K	[k	{			À	Ñ	À	á	ñ	ò
0C	,	<	L	\	l				À	Ñ	À	á	ñ	ò
0D	-	=	M]	m	}			À	Ñ	À	á	ñ	ò
0E	.	>	N	^	n	~			À	Ñ	À	á	ñ	ò
0F	/	?	0	_	o	ð			À	Ñ	À	á	ñ	ò

Code Page Katakana

Code Page KATAKANA.

	2	3	4	5	6	7	8	9	A	B	C	D	E	F
00	0	@	P	'	p	...	上
01	!	1	A	Q	a	q
02	"	2	B	R	b	r
03	#	3	C	S	c	s
04	\$	4	D	T	d	t
05	%	5	E	U	e	u
06	&	6	F	V	f	v
07	'	7	G	W	g	w
08	<	8	H	X	h	x
09)	9	I	Y	i	y
0A	*	:	J	Z	j	z
0B	+	;	K	[k	{
0C	,	<	L	\	l	
0D	-	=	M]	m	}
0E	.	>	N	^	n	~
0F	/	?	0	_	o	o

Code Page 932 (Cont)

Code page 932-8A

40 魁晦械海灰界皆繪芥蟹開階貝凱劾外
 50 咳害崖慨概涯碍蓋街該鐵骸涅馨蛙垣
 60 柿蛎鈎劃嚇各廓拉攬格核殼獲確穰覺
 70 角赫較郭閣隔革學岳樂額顛掛笠檉
 80 檀棍鯁瀉割喝恰括活渴滑葛褐轄且鯉
 90 叶椹樺鞣株兜甯蒲釜鐮啣鴨栢茅董粥
 A0 刈刈互乾侃冠寒刊勸勸卷喚堪姦完官
 B0 寬干幹患感憤憾換敢柑柑棺款歡汗漢
 C0 澗漣環甘監看竿管簡緩缶翰肝艦莢觀
 D0 諫貢遠鑑閭闕闕閩韓館館丸含岸廠玩
 E0 癌眼岩翫廣雁頑顏願企伎危喜器基奇
 F0 嬾寄岐希幾忌揮机旗既期棋棄

Code page 932-8B

40 機婦毅氣汽畿祈季稀紀微規記貴起軌
 50 輝飢騎鬼龜偽儀妓宜戲技擬欺懣疑祇
 60 義蟻誼議掬菊鞠吉吃喫桔橘詰砧杵黍
 70 却客脚虐逆丘久仇休及吸宮弓急救
 80 朽求汲泣灸球究窮笈級糾給旧牛去居
 90 巨拒拋拳渠虛許距鋸漁禦魚享享京供
 A0 俠僑兇競共凶協匡卿叫喬境峽強疆怯
 B0 恐恭揆教橋況狂狹矯胸脅興薈鄉鏡響
 C0 饜驚仰凝堯晚業局曲極玉桐杆僅勤均
 D0 巾錦斤欣欽琴禁禽筋繫芹菌衿襟謹近
 E0 金吟銀九俱句区狗玖矩苦艱驅駁駒具
 F0 愚虞噙空偶寓遇隅串樹釧屑屈

Code page 932-8C

40 掘窟沓靴轡窪熊隈桑乘縲桑繳勳君薰
 50 訓群軍郡卦袞祁係傾刑兄啓圭珪型契
 60 形徑惠慶慧翹揭携敬景桂溪畦稽系經
 70 繼繫繫莖荊蚩計詣馨輕頸鷄芸迎鯨
 80 劇戟擊激隙析傑欠決潔穴結血訣月件
 90 儉倦健兼券劍墮圍堅嫌遠憲懸拳捲檢
 A0 權牽犬獻研硯緝臬肩見謙賢軒遺鍵險
 B0 頭驗驗元原戲幻弦滅源玄現絃絃言諺
 C0 限乎個古呼固姑孤己庫弧戶故枯湖狐
 D0 糊袴股胡孤虎誇跨鈞履顧鼓五互伍午
 E0 吳吾娛後御悟梧檣瑚暮語誤護翻乞鯉
 F0 交伎侯候倖光公功效勾厚口向

Code page 932-8D

40 后喉坑垢好孔孝宏工巧巷幸庑康弘
 50 恒慌抗拘控攻昂更杭校梗構江洪浩
 60 港溝甲皇硬穉糠紅紅紋綱耕考肯肱腔
 70 膏航荒行衡講貢購郊醇鉏砒鋼閣降
 80 項香高鴻剛劫号合壤拷滾豪轟趨克刻
 90 告国穀酷鷓黑獄濃腰甌忽惚骨狍込此
 A0 頃今困坤墾婚恨惡昏昆根梱混痕紺艮
 B0 魂些佐又峻嵯左差查沙璫砂詐鎖裝坐
 C0 座挫價催再最哉妻妻幸彩才採裁歲濟
 D0 災采犀碎皆祭齋細菜裁戰際劑在材罪
 E0 財呀坂阪堺榭榭肴峒崎崎礪驚作削咋搾
 F0 昨朔柵窄策索錯梭銼銼匙匙冊刷

Code page 932-8E

40 察撿撮擦札殺薩雜舉鯖捌鑄絞皿晒三
 50 傘參山慘撒散棧燦珊產算纂蚤讚贊酸
 60 餐斬暫殘仕仔伺使刺司史嗣四士始飾
 70 姿子屍市師志思指支孜斯施旨枝止
 80 死氏獅社私系紙紫肢脂至視詞詩試誌
 90 諮資賜雌飼齒事似侍兒字寺慈持時次
 A0 滋治爾靈痔磁示而耳自蒔辞夕鹿式識
 B0 鳴竺軸穴喫七叱軌失嫉室悉湿溼疾質
 C0 寔蔀篠偃柴芝屢蕊縞舍写射捨赦斜煮
 D0 社紗著謝車遮蛇邪備勺尺杓灼爵酌鞣
 E0 錫若寂弱惹主取守手朱殊狩珠種腫趨
 F0 酒首儒受呪壽授樹綬帶囚収周

Code page 932-8F

40 宗就州修愁拾洲秀秋終繡習臬舟菟衆
 50 襲譬蹶轄週酋酬集醜什住充十從戎柔
 60 汁汶獸縱重銃叔夙宿淑縮肅塾熟出
 70 術述俊峻春曉竣舜駿准循旬楮殉淳
 80 準濶盾純巡邏醇順処初所暑曙渚庶緒
 90 署書薯薯諸助叙女序徐恕鋤除傷僕勝
 A0 匠升召哨商唱嘗獎妾媼宵將小少尚庄
 B0 床廠彰承抄招掌捷昇昌昭晶松梢樟樵
 C0 沼消涉湘燒焦照症省硝礮祥称章裝粧
 D0 紹肖蔞蔞蕪衝裝訟証詔詳象賞選錠鐘
 E0 鐘障鞘上丈丞乘冗剗城墻壤壤常情擾
 F0 桑杖淨狀量穰蒸讓釅錠嗎壇飾

Code Page 932 (Cont)

Code page 932-90

40 拭植殖燭織職色蝕食蝕辱尻伸信侵啓
 50 娠瓊審心慎振新晉森榛漫深申疹真神
 60 秦紳臣苾薪親診身辛進針震人仁刃廬
 70 壬尋甚尽腎訊迅陣鞫箭諏須酢凶厨
 80 逗吹垂帥推水炊睡粹翠衰遂醉錐錘隨
 90 瑞髓崇嵩數枢趨難据杉樞菅頰雀裾澄
 A0 摺寸世瀨欵是凜制勢姓征性成政整星
 B0 睛樓栖正濟牲生盛精聖声製西誠誓請
 C0 逝醒青靜齊稅脆臆席惜戚斥昔析石積
 D0 籍績脊責赤跡蹟碩切拙接攝折設窃節
 E0 說雪絕舌蟬仙先干占宣專尖川戰扇撰
 F0 栓栴泉淺洗染藩煎爛旋穿箭線

Code page 932-92

40 叩但達辰奪脫巽豎迪棚谷狸鱈樽誰丹
 50 單嘆坦担探巨歎淡湛炭短端筆綻耽胆
 60 蛋誕鍛团壇彈断暖檀段男談值知地弛
 70 恥智池痴稚置致蚰遲馳築蓄竹筑蓄
 80 逐秩窰茶嫡着中仲宙忠抽昼柱注虫衷
 90 註耐鑄駐樗瀨猪苧著貯丁兆凋喋龍帖
 A0 帳序弔張彫徵懲挑暢朝潮牒町眺聽脹
 B0 腸蝶調諜超跳銚長頂烏勅抄直朕沈珍
 C0 質鎮陳津墜椎植追鎚痛塚樞樞楓佃
 D0 濱柘辻蕙綴錫椿潰坪壺孀紬爪吊釣鮑
 E0 亭低停偵剝貞呈堤定帝底庭廷弟悌抵
 F0 擬提梯汀碇禎程締艇訂諦蹄遞

Code page 932-94

40 如尿菲任妊忍認滯欄柵率葱猫熱年念
 50 捻撚燃粘乃迺之埜囊惱濃納能腦膿農
 60 覩蚤巴把播霸杷波派琶破婆罵芭馬俳
 70 糜拜排敗杯盃牌背肺輩配倍培媒梅
 80 煤煤猥買壳賸陪這蠅秤矧萩伯剝搏拍
 90 柏泊白箔粕舶薄迫曝漠爆縛莫駁麥函
 A0 箱裕箸聳菩檣幡肌焯龔八鉢澆發髻髮
 B0 伐罰拔笈閱鳩嘶塢蛤隼伴判半反叛帆
 C0 搬斑板汜汎版犯班畔繁般藩販範采煩
 D0 頒飯挽晚蕃盤盤蕃蠻匪辜否妃庇彼悲
 E0 靡批披斐比泌疲皮碑秘緋罷肥被誹費
 F0 避非飛極箴備尾微枇毘毘眉美

Code page 932-91

40 織羨腺舛船薦詮賤踐選遷錢銃閃鮮前
 50 善漸然全禪繕膳癩贈塑岨措曾曾楚狙
 60 疏疎礎祖租粗素組蘇訴阻溯鼠僧劍双
 70 蕪倉喪壯奏爽宋層匝惣想搜搗搗搗
 80 操早曹巢槍槽漕燥争瘦相窓糟總綜聰
 90 草莊葬蒼藻裝走送遭鎗羅騷像增憎臟
 A0 臧贈造促側則即息捉束測足速俗屬賊
 B0 族統卒袖其掬存孫尊損村遜他多汰汰
 C0 訖唾墮妥愴打舵舵樞陀駮驂体堆对耐
 D0 岱帶待怠態戴替泰滯胎腿吞袋貸退遠
 E0 隊黛鯛代台大第醜題厲瀉瀉卓啄宅托
 F0 扞拓沃濯琢託鐸濁諾葦風蛸只

Code page 932-93

40 邱鄭釘鼎泥摘擗敵滴的笛適鑄溺哲徹
 50 撤撤迭鉄典墳天展店添繕甜貼軫顛点
 60 伝殿澱田電兎吐堵塗妬屠徒斗杜渡登
 70 莧賭途都鍍砥砺努度土奴怒倒党冬
 80 凍刀唐塔塘套宕島嶋悼投搭東桃榜棟
 90 盜淘湯滂灯燈当痘禱等答筒糖統到董
 A0 蕩藤討臘豆踏逃透鑽陶頭騰關動動同
 B0 堂導懂撞洞贖童胴葡道銅峠鴉鴉得德
 C0 洸特誓禿篤毒獨誘朽椽凸突楸扇薦苦
 D0 實酉潯噸屯惇敦沌豚遁頓吞疊鈍奈那
 E0 内乍厖薙謎灘捺鍋槽馴緇礙南楠軟難
 F0 汝二尼忒迹勾賑肉虹廿日乳入

Code page 932-95

40 鼻柁稗匹疋髭彦膝菱肘粥必畢筆逼桧
 50 姬媛紐百謬儀彪標冰凜瓢票表評豹廟
 60 描病秒苗錨鉸赫蛭鱧品彬斌浜瀕貧寶
 70 頻敏瓶不付埠夫婦冨冨布府怖扶敷
 80 斧普浮父符腐膚芙譜貧賦赴阜附侮撫
 90 武舞葡蕪部封楓風蕪蔀伏副復幅服福
 A0 腹複覆淵弗弘沸仏物酌分吻噴墳憤扮
 B0 焚奮粉蕪紛霧文闌丙併兵嬭幣平弊柄
 C0 並蔽閉陞米頁僻壁癖碧別警麗麗偏變
 D0 片篇編辺返還便勉媿弁鞞保舖鋪團捕
 E0 步甫補輔總募墓慕戍暮毋簿著倅包
 F0 杲報奉宝峰臺崩庖抱捧放方朋

Code Page 932 (Cont)

Code page 932-96

40 法泡烹砲縫胞芳萌蓬蜂褒訪豐邦鋒飽
 50 鳳騰乏亡傍剖坊妨幘忘忙房暴望某棒
 60 冒紡肪膨謀貌賢鉍防吠頰北僕卜墨撲
 70 朴牧睦穆鉅勃沒殆堀幌奔本翻凡盆
 80 靡磨廢麻埋昧枚每哩禳幕膜枕鮪枉
 90 鱗柳亦侯又抹末沫迄促繭曆万慢瀉漫
 A0 蔓味未魅已箕岬密蜜濩蕪稔脈妙耗民
 B0 眠務夢無牟矛霧鷓棕孀娘冥名命明盟
 C0 迷銘鳴嗚牝滅免棉綿緬面麵撲模茂妄
 D0 孟毛猛盲網耗蔓儲木默目奎勿餅尤戾
 E0 初賁問悶紋門勾也冶夜爺耶野弥矢厄
 F0 役約藥詛躍靖柳藪鍾愉愈油癒

Code page 932-97

40 諭輸唯佑僂勇友宥幽悠憂揖有柚湧涌
 50 猶猷由祐裕誘遊邑鄣雄融夕予余与蒼
 60 與預備幼妖容膚揚播擺囉楊樣洋溶熔
 70 用窯羊耀葉蓉耍詔踊遙陽養慾抑欲
 80 沃浴翌翼淀羅螺裸來萊賴雷洛絡落酪
 90 乱卵嵐欄濫藍蘭覽利吏掠略劉流溜琉留
 A0 裏裡里離陸律率立徂掠略劉流溜琉留
 B0 疏粒隆竜龍侶慮旅虜了亮僚兩凌寮料
 C0 梁涼獠療瞭稜糧良諒遼量陵領力綠倫
 D0 厘林淋熾琳臨輪隣鱗璘璠璽淚累類令
 E0 伶例冷勵嶺伶玲礼斧鈴練零靈麗齡曆
 F0 歷列劣烈裂廉恋憐漣煉簾練聯

Code page 932-98

40 蓮連鍊呂魯櫓炉賂路露勞婁廊弄朗樓
 50 榔浪瀉牢狼箠老聾蠟郎六鷲祿肋錄論
 60 倭和話歪賄脇惑粹鷲互巨鱗詫蕪蕨椀
 70 灣碗腕
 80
 90 式
 A0 丐丕个卅、井丿乂乖乘亂丿豫爭舒式
 B0 于亞亞一亢京毫置从仍仄仆仗仗仞仗
 C0 仔价伉仗估佛佻佻佻佻佻佻佻佻佻
 D0 侑佻來侑儂儂俛俛俛俛俛俛俛俛俛俛
 E0 倨倨倨倨倨倨倨倨倨倨倨倨倨倨倨
 F0 會偕僂僂僂僂僂僂僂僂僂僂僂僂僂僂

Code page 932-99

40 僉僉傳僂僂僂僂僂僂僂僂僂僂僂僂僂
 50 僂僂僂僂僂僂僂僂僂僂僂僂僂僂僂僂
 60 僂僂僂僂僂僂僂僂僂僂僂僂僂僂僂僂
 70 僂僂僂僂僂僂僂僂僂僂僂僂僂僂僂僂
 80 夙夙夙夙夙夙夙夙夙夙夙夙夙夙夙
 90 劬劬劬劬劬劬劬劬劬劬劬劬劬劬劬
 A0 劬劬劬劬劬劬劬劬劬劬劬劬劬劬劬
 B0 匆匆匆匆匆匆匆匆匆匆匆匆匆匆
 C0 卅卅卅卅卅卅卅卅卅卅卅卅卅卅卅
 D0 厰厰厰厰厰厰厰厰厰厰厰厰厰厰厰
 E0 吭吭吭吭吭吭吭吭吭吭吭吭吭吭
 F0 咀咀咀咀咀咀咀咀咀咀咀咀咀咀

Code page 932-9A

40 咫晒咤咤咤咤咤咤咤咤咤咤咤咤咤
 50 哩咤咤咤咤咤咤咤咤咤咤咤咤咤
 60 啞啞啞啞啞啞啞啞啞啞啞啞啞啞啞
 70 嘖嘖嘖嘖嘖嘖嘖嘖嘖嘖嘖嘖嘖嘖嘖
 80 噫噫噫噫噫噫噫噫噫噫噫噫噫噫噫
 90 嘖嘖嘖嘖嘖嘖嘖嘖嘖嘖嘖嘖嘖嘖嘖
 A0 國國國國國國國國國國國國國國國
 B0 垝垝垝垝垝垝垝垝垝垝垝垝垝垝垝
 C0 坵坵坵坵坵坵坵坵坵坵坵坵坵坵坵坵
 D0 墟墟墟墟墟墟墟墟墟墟墟墟墟墟墟墟
 E0 壘壘壘壘壘壘壘壘壘壘壘壘壘壘壘壘
 F0 夸夾奇奕奕奕奕奕奕奕奕奕奕奕奕奕

Code page 932-9B

40 奸妁妝倭倭妣妣妣妣妣妣妣妣妣
 50 娜嫫嫫嫫嫫嫫嫫嫫嫫嫫嫫嫫嫫嫫嫫
 60 嫫嫫嫫嫫嫫嫫嫫嫫嫫嫫嫫嫫嫫嫫嫫
 70 嫫嫫子孕孕孕孕孕孕孕孕孕孕孕孕
 80 它官宸冤冠雀畫寤寤寤寤寤寤寤寤寤
 90 實剋將專對尔訖尤彪尸尹屁屈屎屎屎
 A0 屏屏屏屏屏屏屏屏屏屏屏屏屏屏屏
 B0 岍岍岍岍岍岍岍岍岍岍岍岍岍岍岍岍
 C0 巖巖巖巖巖巖巖巖巖巖巖巖巖巖巖
 D0 嶼嶼嶼嶼嶼嶼嶼嶼嶼嶼嶼嶼嶼嶼嶼嶼
 E0 厝厝厝厝厝厝厝厝厝厝厝厝厝厝厝
 F0 幣幣幣幣幣幣幣幣幣幣幣幣幣幣幣

Code Page 932 (Cont)

Code page 932-FB

40 泣滓淚清淚淚淚濁濕涕漢泮澈漸瀆濇瀆
 50 瀨炆炫恣焄焄焄焄焄焄焄焄焄焄焄焄焄焄焄
 60 珣珣珣珣珣珣珣珣珣珣珣珣珣珣珣珣珣
 70 皂皦皦皦皦皦皦皦皦皦皦皦皦皦皦皦皦
 80 祥禔福禔竝身靖淨簪精紉紉紉紉紉紉紉
 90 鱗羨羽茁葶葶葶葶葶葶葶葶葶葶葶葶葶
 A0 蛭蟻夔夔夔夔夔夔夔夔夔夔夔夔夔夔夔夔
 B0 赶赶赶赶赶赶赶赶赶赶赶赶赶赶赶赶赶
 C0 鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇
 D0 鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇
 E0 鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇
 F0 鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇

Code page 932-FC

40 高界分戶姓鮭鮭鮭鮭鮭鮭鮭鮭鮭鮭鮭鮭
 50
 60
 70
 80
 90
 A0
 B0
 C0
 D0
 E0
 F0

Code Page 936 Simple Chinese1e (Cont.)

A840 - A8FF

40
50
60
70
80
90
A0 ǒ ó ô õ ö è é ê ë ì í î ï ð ó ô
B0 ò ǒ ú û ü ò ó ô õ ö è é ò ǎ ǎ
C0 ǒ ǎ ǎ ǎ ǎ ǎ ǎ ǎ ǎ ǎ ǎ ǎ ǎ
D0 ǎ ǎ ǎ ǎ ǎ ǎ ǎ ǎ ǎ ǎ ǎ ǎ ǎ ǎ ǎ ǎ
E0 ǎ ǎ ǎ ǎ ǎ ǎ ǎ ǎ ǎ ǎ ǎ ǎ ǎ ǎ ǎ ǎ
F0

AC40 - ACFF

40
50
60
70
80
90
A0
B0
C0
D0
E0
F0

A940 - A9FF

40
50
60
70
80
90
A0 — | | | | | |
B0 F F F F F F F F F F F F F F F F F F
C0 F F F F F F F F F F F F F F F F F F
D0 F F F F F F F F F F F F F F F F F F
E0 F F F F F F F F F F F F F F F F F F
F0

AD40 - ADFF

40
50
60
70
80
90
A0
B0
C0
D0
E0
F0

AA40 - AAFF

40
50
60
70
80
90
A0
B0
C0
D0
E0
F0

AE40 - AEFF

40
50
60
70
80
90
A0
B0
C0
D0
E0
F0

AB40 - ABFF

40
50
60
70
80
90
A0
B0
C0
D0
E0
F0

AF40 - AFFF

40
50
60
70
80
90
A0
B0
C0
D0
E0
F0

Code Page 936 Simple Chinese (Cont.)

B040 - B0FF

40
50
60
70
80
90
A0 啊阿埃挨哎唉哀皑癌蔼矮艾碍爱隘
B0 鞍氨安俺按暗岸胺案肮昂盎凹敖熬翱
C0 袄傲奥懊澳澳色捌扒叭吧笆八疤巴拔跋
D0 靶把耙坝霸罢爸白柏百摆佰败拜裨斑
E0 班搬扳般颁版版扮伴瓣半办绊邦帮
F0 梆榜膀绑磅磅蚌镑傍镑苞包褒剥

B140 - B1FF

40
50
60
70
80
90
A0 薄雹保堡饱宝抱报暴豹鲍爆杯碑悲
B0 卑北辈背贝钡倍狈备惫焙被奔笨笨
C0 崩崩甬泵蹦迸逼鼻比鄙笔彼碧蔽毕
D0 毙毙币庇痹闭敝弊必辟壁臂避陛辘边
E0 编贬扁便变卞辨辨辨遍标彪曝表鳖憋
F0 别瓠彬斌濒滨冥缤兵冰柄丙秉饼炳

B240 - B2FF

40
50
60
70
80
90
A0 病并玻菠播拨钵波博勃搏铂铂伯帛
B0 舶脖膊泊泊驳捕卜哺补埠不布步簿部
C0 怖擦猜裁材才财睬睬采彩菜蔡餐参蚕
D0 残惨惨灿苍仓沧藏操糙槽曹草厕策
E0 恻册测层蹭插叉茬茶查碴搽察岔差诧
F0 拆柴豺撵撵撵撵撵撵撵撵撵撵撵撵撵撵

B340 - B3FF

40
50
60
70
80
90
A0 场尝常长偿肠厂敞畅唱倡超抄钞朝
B0 嘲潮巢吵炒车扯撤掣彻澈郴臣辰尘晨
C0 忱沉陈趁衬撑称城橙成呈乘程恁澄诚
D0 承逞骋秤吃痴痴持匙池迟弛驰趾齿侈尺
E0 赤翅斥炽充冲虫崇宠抽酬畴稠愁筹
F0 仇绸瞅丑臭初出橱厨踟踟维滁除楚

B440 - B4FF

40
50
60
70
80
90
A0 础储矗矗触触处揣川穿椽传船喘串疮
B0 窗幢床闯创吹炊炊捶垂春椿醇唇淳纯
C0 蠢戳绰疵茨磁磁雌辞慈瓷瓷词此刺赐次聪
D0 葱囱匆从丛凄粗醋簇促蹙篡窜摧崔催
E0 脆瘁粹淬翠村存寸磁撮搓措措措搭
F0 答瘩打大呆歹歹戴戴带殆代袋袋待逮

B540 - B5FF

40
50
60
70
80
90
A0 怠耽担丹单郸掸胆旦氮但惮淡诞弹
B0 蛋当挡党档档刀捣蹈倒岛祷导到稻悼
C0 道盗德得的蹬灯登等瞪凳邓堤低滴迪
D0 敌笛狄涤翟嫡抵底地蒂蒂弟递缔颠
E0 掂滇滇点典颠垫电佃甸店惦奠淀殿碾
F0 刁雕凋刁掉吊吊钓调跌爹碟蝶迭谍叠

B640 - B6FF

40
50
60
70
80
90
A0 丁叮叮钉顶鼎锭定订丢东冬董懂动
B0 栋恫洞冻洞兜抖斗陡豆痘都督毒核
C0 独读堵睹赌杜镀肚度渡妒端短锻段断
D0 锻堆兑队对墩吨蹲敦顿钝盾遁遁哆
E0 多夺埃埃埃踪踪踪剥情堕蛰峨鹅俄额讹
F0 娥恶厄扼遏鄂饿恩而儿耳尔洱洱二

B740 - B7FF

40
50
60
70
80
90
A0 貳发罚筏伐乏阙法珐藩帆番翻樊矾
B0 钺繁凡烦反返范贩犯饭泛坊芳方肪房
C0 防妨仿访妨放非啡啡飞肥匪匪吠肺废
D0 沸费芬酚吩氛纷纷坟焚汾粉奋份忿愤
E0 粪丰封枫峰峰峰风疯烽逢冯缝讽奉凤
F0 佛否夫敷肤肤扶拂辐辐辐符伏伏服

Code Page 936 Simple Chinese (Cont.)

B840 - B8FF

40
50
60
70
80
90
A0 浮涪福袱弗甫抚辅俯釜斧脯腑腐
B0 赴副覆赋复傅付阜父腹负富讷附妇缚
C0 咐噏嘎该改概钙盖溉干甘杆柑竿肝赶
D0 感秆敢赣刚钢缸缸纲岗港杠篙皋高
E0 膏羔糕搞稿告哥歌搁戈鸽貉疙割革
F0 葛格蛤阁隔烙个各给根跟耕更庚羹

B940 - B9FF

40
50
60
70
80
90
A0 埂耿梗工攻功恭龚供躬公宫弓巩汞
B0 拱贡共钩勾沟苟垢构购够辜菇咕箍
C0 估沽孤姑鼓古蛊膏谷股故顾固雇刮瓜
D0 刮寡挂褂乖拐怪棺关官冠观馆罐惯
E0 灌贯光广逛瑰规圭硅归龟闺轨鬼诡
F0 桂柜跪贵刽辄滚棍锅郭国裹过哈

BA40 - BAFF

40
50
60
70
80
90
A0 骸孩海氦亥害骇酣憨邯韩含涵寒函
B0 喊罕翰撼捍旱憾捍焊汗汉夯杭航壕嚎
C0 豪毫郝好耗号浩呵喝荷荷核禾和何合
D0 盒貉阖河涸赫褐鹤贺嘿黑痕很狠很哼
E0 亨横衡恒轰哄烘鸿洪宏弘红喉侯猴
F0 吼厚候后呼乎忽瑚壶胡胡瑚狐糊湖

BB40 - BBFF

40
50
60
70
80
90
A0 弧虎唬护互沪户花哗华猾滑画划化
B0 话槐徊怀淮坏欢环桓还缓涣患唤痪豢
C0 涣涣宦幻荒慌黄磺蝗簧皇惶惶晃幌
D0 恍恍灰挥辉恢恢徊回毁悔慧卉惠晦
E0 秒会烩汇讳诲绘萃昏昏婚魂浑混豁活伙
F0 火获或惑霍货祸击圾基机畸稽积箕

BC40 - BCFF

40
50
60
70
80
90
A0 肌饥迹激讥鸡姬绩缉吉极棘辑籍集
B0 及急疾汲即嫉级挤几脊己筍技冀季伎
C0 祭剂悸济寄寂计记既忌际妓继纪嘉枷
D0 夹佳家加荚颊贾甲钾假稼架驾嫁歼
E0 监坚尖笺间煎兼肩艰奸碱茧检柬碱
F0 拣捡简俭剪减荐槛鉴践贱见键箭件

BD40 - BDFE

40
50
60
70
80
90
A0 健舰剑饯渐溅涧建僵姜将浆江疆蒋
B0 桨奖讲匠窘降蕉礁焦胶交郊浇骄娇
C0 嚼搅较矫侥脚狡角皎缴较剿教酵轿较
D0 叫窖揭接皆秸街阶截劫节桔杰捷睫竭
E0 洁结解姐戒藉芥界借介疥诫届巾筋斤
F0 金今津襟紧锦仅谨进靳晋禁近烬浸

BE40 - BEFF

40
50
60
70
80
90
A0 尽劲荆兢茎睛晶鲸京惊精梗经井警
B0 景颈静境敬镜径痉靖竟竞净炯窘揪究
C0 纠玖韭久灸九酒既救旧臼舅咎就疚鞠
D0 拘狙疽屠驹菊菊局咀矩举沮聚拒据巨具
E0 距踞辘俱句惧炬副捐鹃娟倦眷卷绢
F0 攫抉掘倔爵觉决决绝均菌钧军君峻

BF40 - BFFF

40
50
60
70
80
90
A0 俊竣浚郡骏喀咖卡咯开揩楷凯慨刊
B0 堪勘坎砍看康慷糠扛抗亢坑考拷烤靠
C0 坷苛柯棵磕颗科壳咳可渴克刻客课肯
D0 啃垦恳坑吭空恐孔控扣口扣寇枯哭窟
E0 苦酷库裤夸垮垮跨跨块袂快快宽款匡
F0 筐狂框矿眶旷况亏盔岙葵奎魁愧

Code Page 936 Simple Chinese (Cont.)

C040 - C0FF

40
50
60
70
80
90
A0 饋愧潰坤捆困括扩廓闊拉拉喇蜡
B0 脂辣啦莱来赖蓝婪栏拦蓝澜兰澜澜挽
C0 览懒纒烂滥琅榔狼廊郎朗浪捞劳牢老
D0 佬姥酪烙涝勒乐雷雷雷雷雷雷雷雷雷
E0 类泪棱楞冷厘梨梨黎篱理离漓理李里
F0 鯉礼莉荔吏栗丽厉励砾历利例例例

C140 - C1FF

40
50
60
70
80
90
A0 痢立粒沥隶力璃哩俩联莲连镰廉怜
B0 涟帘敛脸链恋炼练粮凉梁梁良两辆量
C0 晾亮凉撩聊僚疗療寥辽潦了撻鍊廖料
D0 列裂烈劣猎琳林磷霖临邻鳞淋凛赁吝
E0 拎玲菱零龄铃铃凌灵陵岭领另令溜
F0 琉榴硫溜留刘瘤流柳六龙聋咙笼隆

C240 - C2FF

40
50
60
70
80
90
A0 隆垄拢陇楼娄楼萎漏陋芦卢颅庐炉
B0 擄卤虜鲁麓碌露路赂鹿潞禄录陆戮驴
C0 吕铝侣旅履屨缕虑氯律率滤绿峦率
D0 滦卵乱掠略抡轮伦仑论论论螺罗罗
E0 锣箩骡裸裸落洛络络妈玛码妈马骂嘛
F0 吗埋买卖卖迈脉脉慢蛮满蔓曼慢慢

C340 - C3FF

40
50
60
70
80
90
A0 漫芒茫盲氓忙莽猫茅锚毛矛柳卯茂
B0 冒帽貌贸么玫枚梅霉霉煤没眉媒镁每
C0 美味寐妹媚闷们萌蒙蒙盟猛猛梦孟
D0 眯魅靡糜迷谜弥米秘觅蜜密幕棉眠
E0 绵冕免勉媵媵面苗描瞄藐秒渺庙妙蔑
F0 灭民抿皿敏讷闽明螟鸣铭名命谬摸

C440 - C4FF

40
50
60
70
80
90
A0 摹磨模膜磨摩魔抹末莫墨默沫漠寞
B0 陌谋牟某拇牡亩姆母墓暮募募木目
C0 睦牧穆拿哪呐纳那娜纳氛乃奶耐奈南
D0 男难囊挠脑恼闹滓呢馁内嫩能妮霓娘
E0 泥尼拟你匿腻逆溺溺拈年碾撵捻念娘
F0 酿鸟尿捏聂孽啮镊镍涅您柠拧凝宁

C540 - C5FF

40
50
60
70
80
90
A0 拧泞牛扭钮纽脓浓农弄奴努怒女暖
B0 虐疟挪糯糯诺哦欧鸥殴藕呕偶沏叭叭
C0 爬怕怕琶拍排牌徘徊派攀潘盘磐盼畔
D0 判叛乓庞旁磅胖抛咆咆咆咆咆咆咆
E0 培裴陪陪配佩沛喷盆砰抨烹澎彭蓬棚
F0 棚蓬膨朋鹏捧碰碰碰碰碰碰碰碰碰

C640 - C6FF

40
50
60
70
80
90
A0 啤脾疲皮匹痞僻屁譬篇偏片骗飘漂
B0 瓢票撇瞥拼频贫品聘乒坪苹萍平凭瓶
C0 评屏屏泼颇婆破魄迫柏剖扑铺仆莆葡
D0 菩蒲埔朴圃普浦谱曝瀑期欺栖戚妻七
E0 凄漆柒沏其棋奇歧畦崎脐齐旗祈祁骑
F0 起岂乞企启契砌器气迄弃汽泣乞拍

C740 - C7FF

40
50
60
70
80
90
A0 恰洽牵扞轩铅千迁签仟谦乾黔钱钳
B0 前潜遣浅遣筴欠歉枪呛腔羌墙蔷强
C0 抢纛鞞敲悄桥瞧乔侨巧鞘撬翘峭俏穹
D0 切茄且怯窃软侵秦琴琴勤芹擒禽寝沁
E0 青轻氢倾卿淸淸淸淸淸淸淸淸淸淸
F0 丘邱球求囚酋涸趋区蛆曲躬屈驱渠

Code Page 936 Simple Chinese (Cont.)

C840 - C8FF

40
50
60
70
80
90
A0 娶娶講趣去圈顛权醒泉全痊拳犬券
B0 劝缺缺癩却鵲權确雀裙群然燃冉染瓢
C0 壤壤壤让饶扰绕惹热壬仁人忍初任认
D0 刃妊纫扔仍戎茸蓉荣融溶容绒冗蕊
E0 揉柔肉茹孺孺孺如辱乳汝入褥软阮蕊
F0 瑞锐闰润若弱撒洒萨腮颞塞赛三叁

C940 - C9FF

40
50
60
70
80
90
A0 伞散桑嗓丧搔骚扫嫂瑟色涩森僧莎
B0 砂杀刹沙纱傻啥煞筛晒珊苫杉山删煽
C0 衫闪陕擅贖膳善汕扇缮墒伤商晌上
D0 尚裳梢稍稍烧芍勺韶少哨邵绍奢除蛇
E0 舌舍赦摄射慑涉社设呻申呻伸身深娠
F0 绅沈沈审婶甚肾慎渗声生甥牲升绳

CA40 - CAFF

40
50
60
70
80
90
A0 省盛剩胜圣师失狮施湿诗尸虱十石
B0 拾时什食蚀实识史矢使屎驶始式示士
C0 世柿事拭誓逝势是嗜适仕侍释饰
D0 市恃室视试收手首守寿授售受瘦善蔬
E0 枢梳殊抒输叔舒淑疏书赎孰熟薯暑
F0 薯黍黍鼠鼠术述树束束豎豎庶庶漱

CB40 - CBFF

40
50
60
70
80
90
A0 恕刷耍摔衰甩帅栓拴霜双爽淮水睡
B0 税吮瞬顺舜说硕朔烁斯嘶思私司丝
C0 死肆寺嗣四伺似伺已松耸丛颂送宋讼
D0 诵搜艘撤嗽苏酥俗索速粟儗塑朔宿诉
E0 肃酸蒜算虽隋随纛髓碎岁穗遂隼隼
F0 损笋蓑梭梭缩琐琐索锁所塌他她塔

CC40 - CCFF

40
50
60
70
80
90
A0 獭拏踏踏胎苔拍台泰馱太态汰坍摊
B0 贪雍滩坛檀痰潭谈坦毯袒袒探叹炭
C0 汤塘塘堂棠膛唐糖倘淌趟烫掏涛滔
D0 缘萄桃逃淘陶讨套特藤腾疼眷梯剔踢
E0 锤提题蹄啼体替嚏惕惕涕剃屉天添填田
F0 甜恬舔腆挑条迢眺眺贴帖帖厅听烺

CD40 - CDFF

40
50
60
70
80
90
A0 汀廷停亭庭挺艇通桐铜瞳同铜形童
B0 桶捅筒统捅偷投头透凸秃突图徒途涂
C0 屙土吐兔湍团推颓腿蜕褪退吞屯臀施
D0 托脱陀驮驮驼驼妥拓唾挖哇蛙娃瓦
E0 袜歪外腕弯湾玩顽丸烷完碗挽晚碗
F0 宛婉万腕汪王亡枉网往旺望忘妄威

CE40 - CEFF

40
50
60
70
80
90
A0 巍微危韦违拖拖围唯惟为淮淮淮委
B0 伟伪尾纬未蔚味畏胃喂魏位渭渭耐慰
C0 卫瘟温蚊文闻纹吻稳素问嗜翁瓮拉蜗
D0 涡窝我斡卧握沃巫鸣鸪乌污诬屋无羌
E0 梧吾吴毋武五梧午舞伍侮坞戊雾晤物
F0 勿务悟误昔熙析西晒砂晰嗜吸锡牺

CF40 - CFFF

40
50
60
70
80
90
A0 稀息希悉膝夕惜熄焯溪汐犀犀犀席
B0 习媳喜洗洗洗洗洗洗洗洗洗洗洗洗
C0 侠狭下厦夏吓掀掀先仙鲜纤威贤衔舷
D0 闲涎弦嫌显险现献县腺馅羨宪陷限线
E0 相厢镶香箱襄湘乡翔祥详想响享项巷
F0 橡像向象萧硝霄削峭峭峭峭峭峭峭

Code Page 936 Simple Chinese (Cont.)

D040 - D0FF

40
50
60
70
80
90
A0 小孝校肖啸笑效楔些歇蝎鞋协挟携
B0 邪斜肋谐写械卸蟹懈泄泻谢屑薪芯铤
C0 欣辛新忻心信衅星猩猩猩兴刑型形邢
D0 行醒幸杏性姓兄凶胸匈汹雄熊休修羞
E0 朽嗅锈秀袖绣墟戊需虚嘘须徐许蓄酗
F0 叙旭序畜恤絮婿绪续轩喧宣悬旋玄

D140 - D1FF

40
50
60
70
80
90
A0 选癣眩绚靴薛学穴雪血勋熏循旬询
B0 寻驯巡殉讯训迅逊迅压押鸦鸭呀丫芽
C0 牙蚜崖衙涯雅亚讶焉咽阉烟淹盐严
D0 研蜓岩延言颀阎炎沿奄掩眼衍演艳堰
E0 燕厌砚雁唁彦焰宴谚验殃央鸯秧扬扬
F0 佯疡羊洋洋氧仰痒痒痒痒痒痒痒痒痒

D240 - D2FF

40
50
60
70
80
90
A0 播尧遥窑滔姚咬召药要耀椰噎耶爷
B0 野冶也页掖业叶曳腋液一壹医揖铍
C0 依伊衣颐夷遗移仪胰疑沂宜姨彝椅蚁
D0 倚已乙矣以艺抑易邑屹亿役臆逸肄疫
E0 亦裔意毅忆义益溢诣议谊译异翼翌绎
F0 茵荫因殷音阴姻吟银淫寅饮尹引隐

D340 - D3FF

40
50
60
70
80
90
A0 印英櫻嬰鷹应纓莹莹营莢蠅迎羸盈
B0 影穎硬映哟拥佣臃痲庸雍踊踊咏泳涌
C0 永愿勇佑幽忧悠忧尤由邮铀犹油游酉
D0 有友右佑釉诱又幼迂淤于孟榆虞愚與
E0 余俞逾鱼愉渝渔隅予娱雨与屿禹宇语
F0 羽玉域芋郁吁遇喻峪御愈欲狄育誉

D440 - D4FF

40
50
60
70
80
90
A0 浴寓裕预豫驭骛渊冤元垣袁原援辕
B0 园员圆猿源缘远苑愿怨院曰约越跃钥
C0 岳粤月悦阅耘云邕匀陨允运蕴酝晕韵
D0 孕匝砸杂栽哉灾宰载再在咱攒暂贲贲
E0 脏葬遭糟凿藻枣早澡蚤躁噪造皂灶燥
F0 贲择则泽贼怎增憎曾赠扎渣渣札札

D540 - D5FF

40
50
60
70
80
90
A0 劓阏眨栅榨咋乍炸炸摘斋宅窄债寨
B0 瞻毡詹粘沾盞斩辗崭展蘸栈占站站
C0 绽樟章彰漳张掌涨杖丈帐胀仗杖瘴障
D0 招昭找沼赵照罩兆肇召遮折侦侦疹疹
E0 锺蔗这浙珍斟真甄砧臻贞针侦枕疹疹
F0 震振镇阵蒸挣睁征铮争征整拯正政

D640 - D6FF

40
50
60
70
80
90
A0 帧症郑证芝枝支肢蜘蛛知肢脂汁之织
B0 职直植殖执值侄址指止趾只旨纸志摯
C0 擲至致置帜峙制智秩稚质炙痔滞治窒
D0 中盅忠钟衷终种肿重仲众舟周州洵
E0 粥轴肘帚咒皱宙昼骤珠株蛛朱猪诸诛
F0 逐竹烛煮拄瞩瞩主薯柱助蛀贮铸筑

D740 - D7FF

40
50
60
70
80
90
A0 住注祝驻抓爪拽专砖转撰赚篆桩庄
B0 装妆撞壮状锥锥追赘坠缀淳准捉拙卓
C0 桌琢茁酌啄着灼油兹咨咨姿滋淄孜紫
D0 仔籽滓子自渍字辘踪踪踪踪踪踪踪踪
E0 奏揍租足卒族祖诅阻组钻纂嘴醉最罪
F0 尊遵昨左佐柞做作坐座

Code Page 936 Simple Chinese (Cont.)

E040 - E0FF

40
50
60
70
80
90
A0 唷啖啖啖啖啖啖啖啖啖啖啖啖
B0 啖啖啖啖啖啖啖啖啖啖啖啖啖
C0 啖啖啖啖啖啖啖啖啖啖啖啖啖
D0 啖啖啖啖啖啖啖啖啖啖啖啖啖
E0 啖啖啖啖啖啖啖啖啖啖啖啖啖
F0 啖啖啖啖啖啖啖啖啖啖啖啖啖

E140 - E1FF

40
50
60
70
80
90
A0 惟嵬嶷嶷嶷嶷嶷嶷嶷嶷嶷嶷
B0 嶷嶷嶷嶷嶷嶷嶷嶷嶷嶷嶷嶷嶷
C0 嶷嶷嶷嶷嶷嶷嶷嶷嶷嶷嶷嶷嶷
D0 嶷嶷嶷嶷嶷嶷嶷嶷嶷嶷嶷嶷嶷
E0 徕徕徕徕徕徕徕徕徕徕徕徕
F0 徕徕徕徕徕徕徕徕徕徕徕徕

E240 - E2FF

40
50
60
70
80
90
A0 狻猊猊猊猊猊猊猊猊猊猊
B0 猊猊猊猊猊猊猊猊猊猊猊猊
C0 猊猊猊猊猊猊猊猊猊猊猊猊
D0 猊猊猊猊猊猊猊猊猊猊猊猊
E0 狻猊猊猊猊猊猊猊猊猊猊
F0 狻猊猊猊猊猊猊猊猊猊猊

E340 - E3FF

40
50
60
70
80
90
A0 恪悫悫悫悫悫悫悫悫悫悫
B0 悫悫悫悫悫悫悫悫悫悫悫悫
C0 悫悫悫悫悫悫悫悫悫悫悫悫
D0 悫悫悫悫悫悫悫悫悫悫悫悫
E0 悫悫悫悫悫悫悫悫悫悫悫悫
F0 悫悫悫悫悫悫悫悫悫悫悫悫

E440 - E4FF

40
50
60
70
80
90
A0 洄洄洄洄洄洄洄洄洄洄洄洄
B0 洄洄洄洄洄洄洄洄洄洄洄洄洄
C0 洄洄洄洄洄洄洄洄洄洄洄洄洄
D0 洄洄洄洄洄洄洄洄洄洄洄洄洄
E0 洄洄洄洄洄洄洄洄洄洄洄洄洄
F0 洄洄洄洄洄洄洄洄洄洄洄洄洄

E540 - E5FF

40
50
60
70
80
90
A0 漶漶漶漶漶漶漶漶漶漶
B0 漶漶漶漶漶漶漶漶漶漶
C0 漶漶漶漶漶漶漶漶漶漶
D0 漶漶漶漶漶漶漶漶漶漶
E0 漶漶漶漶漶漶漶漶漶漶
F0 漶漶漶漶漶漶漶漶漶漶

E640 - E6FF

40
50
60
70
80
90
A0 姘姘姘姘姘姘姘姘姘姘姘姘
B0 姘姘姘姘姘姘姘姘姘姘姘姘姘
C0 姘姘姘姘姘姘姘姘姘姘姘姘姘
D0 姘姘姘姘姘姘姘姘姘姘姘姘姘
E0 姘姘姘姘姘姘姘姘姘姘姘姘姘
F0 姘姘姘姘姘姘姘姘姘姘姘姘姘

E740 - E7FF

40
50
60
70
80
90
A0 纒纒纒纒纒纒纒纒纒纒纒纒
B0 纒纒纒纒纒纒纒纒纒纒纒纒
C0 纒纒纒纒纒纒纒纒纒纒纒纒
D0 纒纒纒纒纒纒纒纒纒纒纒纒
E0 纒纒纒纒纒纒纒纒纒纒纒纒
F0 纒纒纒纒纒纒纒纒纒纒纒纒

Code Page 936 Simple Chinese (Cont.)

E840 - E8FF

40
50
60
70
80
90
A0 琬琰琤琮琿琻琼琽琿琿琿琿琿琿琿琿琿琿琿琿
B0 璋瑱瑛瑛瑛瑛瑛瑛瑛瑛瑛瑛瑛瑛瑛瑛瑛瑛瑛
C0 枳枇杪杪杪杪杪杪杪杪杪杪杪杪杪杪杪杪杪
D0 梳梳杷杷杷杷杷杷杷杷杷杷杷杷杷杷杷杷杷
E0 榭榭榭榭榭榭榭榭榭榭榭榭榭榭榭榭榭
F0 崇崇崇崇崇崇崇崇崇崇崇崇崇崇崇崇崇崇崇崇

EC40 - ECFF

40
50
60
70
80
90
A0 贖贖贖贖贖贖贖贖贖贖贖贖贖贖贖贖贖贖
B0 穀穀穀穀穀穀穀穀穀穀穀穀穀穀穀穀穀穀穀
C0 炮炮炮炮炮炮炮炮炮炮炮炮炮炮炮炮炮炮炮
D0 煨煨煨煨煨煨煨煨煨煨煨煨煨煨煨煨煨煨煨
E0 爨爨爨爨爨爨爨爨爨爨爨爨爨爨爨爨爨爨爨
F0 祓祓祓祓祓祓祓祓祓祓祓祓祓祓祓祓祓祓祓祓

E940 - E9FF

40
50
60
70
80
90
A0 椶椶椶椶椶椶椶椶椶椶椶椶椶椶椶椶椶椶
B0 槩槩槩槩槩槩槩槩槩槩槩槩槩槩槩槩槩槩
C0 榭榭榭榭榭榭榭榭榭榭榭榭榭榭榭榭榭
D0 榭榭榭榭榭榭榭榭榭榭榭榭榭榭榭榭榭
E0 猷猷猷猷猷猷猷猷猷猷猷猷猷猷猷猷猷猷
F0 軻軻軻軻軻軻軻軻軻軻軻軻軻軻軻軻軻軻軻軻

ED40 - EDFF

40
50
60
70
80
90
A0 愬愬愬愬愬愬愬愬愬愬愬愬愬愬愬愬愬愬愬愬
B0 愬愬愬愬愬愬愬愬愬愬愬愬愬愬愬愬愬愬愬愬
C0 砧砧砧砧砧砧砧砧砧砧砧砧砧砧砧砧砧砧
D0 砧砧砧砧砧砧砧砧砧砧砧砧砧砧砧砧砧砧
E0 砧砧砧砧砧砧砧砧砧砧砧砧砧砧砧砧砧砧
F0 眇眇眇眇眇眇眇眇眇眇眇眇眇眇眇眇眇眇眇眇

EA40 - EAFF

40
50
60
70
80
90
A0 掇掇掇掇掇掇掇掇掇掇掇掇掇掇掇掇掇掇掇掇
B0 臧臧臧臧臧臧臧臧臧臧臧臧臧臧臧臧臧臧
C0 眈眈眈眈眈眈眈眈眈眈眈眈眈眈眈眈眈眈眈眈
D0 昏昏昏昏昏昏昏昏昏昏昏昏昏昏昏昏昏昏昏
E0 咳咳咳咳咳咳咳咳咳咳咳咳咳咳咳咳咳咳咳
F0 笨笨笨笨笨笨笨笨笨笨笨笨笨笨笨笨笨笨笨笨

EE40 - EEFF

40
50
60
70
80
90
A0 睢睢睢睢睢睢睢睢睢睢睢睢睢睢睢睢睢睢睢睢
B0 眈眈眈眈眈眈眈眈眈眈眈眈眈眈眈眈眈眈眈眈
C0 盥盥盥盥盥盥盥盥盥盥盥盥盥盥盥盥盥盥盥
D0 钗钗钗钗钗钗钗钗钗钗钗钗钗钗钗钗钗钗钗钗钗钗
E0 钗钗钗钗钗钗钗钗钗钗钗钗钗钗钗钗钗钗钗钗钗钗
F0 钗钗钗钗钗钗钗钗钗钗钗钗钗钗钗钗钗钗钗钗钗钗

EB40 - EBFF

40
50
60
70
80
90
A0 辮辮辮辮辮辮辮辮辮辮辮辮辮辮辮辮辮辮
B0 氘氘氘氘氘氘氘氘氘氘氘氘氘氘氘氘氘氘氘氘
C0 彤彤彤彤彤彤彤彤彤彤彤彤彤彤彤彤彤彤彤
D0 肓肓肓肓肓肓肓肓肓肓肓肓肓肓肓肓肓肓肓
E0 豚豚豚豚豚豚豚豚豚豚豚豚豚豚豚豚豚豚豚
F0 膃膃膃膃膃膃膃膃膃膃膃膃膃膃膃膃膃膃膃膃膃膃

EF40 - EFFF

40
50
60
70
80
90
A0 銻銻銻銻銻銻銻銻銻銻銻銻銻銻銻銻銻銻銻
B0 銻銻銻銻銻銻銻銻銻銻銻銻銻銻銻銻銻銻銻
C0 銻銻銻銻銻銻銻銻銻銻銻銻銻銻銻銻銻銻銻
D0 銻銻銻銻銻銻銻銻銻銻銻銻銻銻銻銻銻銻銻
E0 銻銻銻銻銻銻銻銻銻銻銻銻銻銻銻銻銻銻銻
F0 銻銻銻銻銻銻銻銻銻銻銻銻銻銻銻銻銻銻銻

F040 - F0FF

40
50
60
70
80
90
A0 穧稷穉黏馥穰阪皎皓哲晡熨瓠甬鳩
B0 鸞鸞鸞鸞鸞鸞鸞鸞鸞鸞鸞鸞鸞鸞鸞鸞
C0 鸞鸞鸞鸞鸞鸞鸞鸞鸞鸞鸞鸞鸞鸞鸞鸞
D0 鸞鸞鸞鸞鸞鸞鸞鸞鸞鸞鸞鸞鸞鸞鸞鸞
E0 疣疔疔疔疔疔疔疔疔疔疔疔疔疔疔疔疔
F0 痧痧痧痧痧痧痧痧痧痧痧痧痧痧痧痧痧痧

F140 - F1FF

40
50
60
70
80
90
A0 瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵
B0 瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵
C0 瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵
D0 瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵
E0 瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵
F0 瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵瘵

F240 - F2FF

40
50
60
70
80
90
A0 颀颀颀颀颀颀颀颀颀颀颀颀颀颀颀颀颀
B0 虬虬虬虬虬虬虬虬虬虬虬虬虬虬虬虬
C0 蚘蚘蚘蚘蚘蚘蚘蚘蚘蚘蚘蚘蚘蚘蚘蚘
D0 蚘蚘蚘蚘蚘蚘蚘蚘蚘蚘蚘蚘蚘蚘蚘蚘
E0 蚘蚘蚘蚘蚘蚘蚘蚘蚘蚘蚘蚘蚘蚘蚘蚘
F0 蚘蚘蚘蚘蚘蚘蚘蚘蚘蚘蚘蚘蚘蚘蚘蚘

F340 - F3FF

40
50
60
70
80
90
A0 蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥
B0 蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥
C0 蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥
D0 蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥
E0 蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥
F0 蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥蟥

F440 - F4FF

40
50
60
70
80
90
A0 簪簪簪簪簪簪簪簪簪簪簪簪簪簪簪簪
B0 舩舩舩舩舩舩舩舩舩舩舩舩舩舩舩舩
C0 衾衾衾衾衾衾衾衾衾衾衾衾衾衾衾衾
D0 策栖策策策策策策策策策策策策策策策
E0 羿翎翥翥翥翥翥翥翥翥翥翥翥翥翥翥
F0 鞠鞠鞠鞠鞠鞠鞠鞠鞠鞠鞠鞠鞠鞠鞠鞠

F540 - F5FF

40
50
60
70
80
90
A0 酢酢酢酢酢酢酢酢酢酢酢酢酢酢酢酢
B0 醴醴醴醴醴醴醴醴醴醴醴醴醴醴醴醴
C0 酌酌酌酌酌酌酌酌酌酌酌酌酌酌酌酌
D0 洗洗洗洗洗洗洗洗洗洗洗洗洗洗洗洗
E0 醴醴醴醴醴醴醴醴醴醴醴醴醴醴醴醴
F0 醴醴醴醴醴醴醴醴醴醴醴醴醴醴醴醴

F640 - F6FF

40
50
60
70
80
90
A0 觥觥觥觥觥觥觥觥觥觥觥觥觥觥觥觥
B0 霭霭霭霭霭霭霭霭霭霭霭霭霭霭霭霭
C0 隼隼隼隼隼隼隼隼隼隼隼隼隼隼隼隼
D0 觥觥觥觥觥觥觥觥觥觥觥觥觥觥觥觥
E0 觥觥觥觥觥觥觥觥觥觥觥觥觥觥觥觥
F0 觥觥觥觥觥觥觥觥觥觥觥觥觥觥觥觥

F740 - F7FF

40
50
60
70
80
90
A0 整整整整整整整整整整整整整整整整
B0 粗粗粗粗粗粗粗粗粗粗粗粗粗粗粗粗
C0 骷骷骷骷骷骷骷骷骷骷骷骷骷骷骷骷
D0 履履履履履履履履履履履履履履履履
E0 颞颞颞颞颞颞颞颞颞颞颞颞颞颞颞颞
F0 颞颞颞颞颞颞颞颞颞颞颞颞颞颞颞颞

Code Page 936 Simple Chinese (Cont.)

F840 - F8FF

40
50
60
70
80
90
A0
B0
C0
D0
E0
F0

FC40 - FCFF

40
50
60
70
80
90
A0
B0
C0
D0
E0
F0

F940 - F9FF

40
50
60
70
80
90
A0
B0
C0
D0
E0
F0

FD40 - FDFF

40
50
60
70
80
90
A0
B0
C0
D0
E0
F0

FA40 - FAFF

40
50
60
70
80
90
A0
B0
C0
D0
E0
F0

FE40 - FEFF

40
50
60
70
80
90
A0
B0
C0
D0
E0
F0

FB40 - FBFF

40
50
60
70
80
90
A0
B0
C0
D0
E0
F0

FF40 - FFFF

40
50
60
70
80
90
A0
B0
C0
D0
E0
F0

Code Page 949 Korean (Cont.)

AC40 - ACFF

40
50
60
70
80
90
A0 А Б В Г Д Е Ё Ж З И Й К Л М Н
B0 О П Р С Т У Ф Х Ц Ч Ш Щ Ъ Ы Ь Э
C0 Ю Я
D0 а б в г д е ё ж з и й к л м н
E0 о п р с т у ф х ц ч ш щ ъ ы ь э
F0 ю я

AD40 - ADFF

40
50
60
70
80
90
A0
B0
C0
D0
E0
F0

AE40 - AEFF

40
50
60
70
80
90
A0
B0
C0
D0
E0
F0

AF40 - AFFF

40
50
60
70
80
90
A0
B0
C0
D0
E0
F0

B040 - B0FF

40
50
60
70
80
90
A0 가 각 간 간 갈 각 감 감 갑 갑 갑 갖 갖 갖 갖 갖 갖 갖 갖 갖 갖 갖 갖 갖 갖 갖 갖 갖 갖
B0 갈
C0 갓
D0 겅
E0 겉
F0 겘

B140 - B1FF

40
50
60
70
80
90
A0 팜
B0 팻
C0 팿
D0 팾
E0 팿
F0 팿

Code Page 949 Korean (Cont.)

BE40 - BEFF

40
50
60
70
80
90
A0 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤
B0 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤
C0 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤
D0 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤
E0 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤
F0 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤 쑤

BF40 - BFFF

40
50
60
70
80
90
A0 이 이 이 이 이 이 이 이 이 이 이 이 이 이 이 이
B0 이 이 이 이 이 이 이 이 이 이 이 이 이 이 이 이
C0 이 이 이 이 이 이 이 이 이 이 이 이 이 이 이 이
D0 이 이 이 이 이 이 이 이 이 이 이 이 이 이 이 이
E0 이 이 이 이 이 이 이 이 이 이 이 이 이 이 이 이
F0 이 이 이 이 이 이 이 이 이 이 이 이 이 이 이 이

C040 - C0FF

40
50
60
70
80
90
A0 율 율 율 율 율 율 율 율 율 율 율 율 율 율 율 율
B0 율 율 율 율 율 율 율 율 율 율 율 율 율 율 율 율
C0 율 율 율 율 율 율 율 율 율 율 율 율 율 율 율 율
D0 율 율 율 율 율 율 율 율 율 율 율 율 율 율 율 율
E0 율 율 율 율 율 율 율 율 율 율 율 율 율 율 율 율
F0 율 율 율 율 율 율 율 율 율 율 율 율 율 율 율 율

C140 - C1FF

40
50
60
70
80
90
A0 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬
B0 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬
C0 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬
D0 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬
E0 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬
F0 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬 쥬

C240 - C2FF

40
50
60
70
80
90
A0 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼
B0 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼
C0 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼
D0 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼
E0 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼
F0 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼 쥼

C340 - C3FF

40
50
60
70
80
90
A0 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰
B0 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰
C0 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰
D0 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰
E0 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰
F0 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰 찰

Code Page 949 Korean (Cont.)

C440 - C4FF

40
50
60
70
80
90
A0 치 칫 친 친 친 침 침 칫 칫 카 카 캬 캬
B0 캬 캬 캬 캬 캬 캬 캬 캬 캬 캬 캬 캬 캬
C0 캬 캬 캬 캬 캬 캬 캬 캬 캬 캬 캬 캬 캬
D0 캬 캬 캬 캬 캬 캬 캬 캬 캬 캬 캬 캬 캬
E0
F0

C540 - C5FF

40
50
60
70
80
90
A0 킨 킨 킨 킨 킨 킨 킨 킨 킨 킨 킨 킨 킨
B0 킨 킨 킨 킨 킨 킨 킨 킨 킨 킨 킨 킨 킨
C0 킨 킨 킨 킨 킨 킨 킨 킨 킨 킨 킨 킨 킨
D0 킨 킨 킨 킨 킨 킨 킨 킨 킨 킨 킨 킨 킨
E0
F0

C640 - C6FF

40
50
60
70
80
90
A0 퓌 퓌 퓌 퓌 퓌 퓌 퓌 퓌 퓌 퓌 퓌 퓌 퓌
B0 퓌 퓌 퓌 퓌 퓌 퓌 퓌 퓌 퓌 퓌 퓌 퓌 퓌
C0 퓌 퓌 퓌 퓌 퓌 퓌 퓌 퓌 퓌 퓌 퓌 퓌 퓌
D0 퓌 퓌 퓌 퓌 퓌 퓌 퓌 퓌 퓌 퓌 퓌 퓌 퓌
E0
F0

C740 - C7FF

40
50
60
70
80
90
A0 꺄 꺄 꺄 꺄 꺄 꺄 꺄 꺄 꺄 꺄 꺄 꺄 꺄
B0 꺄 꺄 꺄 꺄 꺄 꺄 꺄 꺄 꺄 꺄 꺄 꺄 꺄
C0 꺄 꺄 꺄 꺄 꺄 꺄 꺄 꺄 꺄 꺄 꺄 꺄 꺄
D0 꺄 꺄 꺄 꺄 꺄 꺄 꺄 꺄 꺄 꺄 꺄 꺄 꺄
E0
F0

C840 - C8FF

40
50
60
70
80
90
A0 꺆 꺆 꺆 꺆 꺆 꺆 꺆 꺆 꺆 꺆 꺆 꺆 꺆
B0 꺆 꺆 꺆 꺆 꺆 꺆 꺆 꺆 꺆 꺆 꺆 꺆 꺆
C0 꺆 꺆 꺆 꺆 꺆 꺆 꺆 꺆 꺆 꺆 꺆 꺆 꺆
D0 꺆 꺆 꺆 꺆 꺆 꺆 꺆 꺆 꺆 꺆 꺆 꺆 꺆
E0
F0

C940 - C9FF

40
50
60
70
80
90
A0 꺈 꺈 꺈 꺈 꺈 꺈 꺈 꺈 꺈 꺈 꺈 꺈 꺈
B0 꺈 꺈 꺈 꺈 꺈 꺈 꺈 꺈 꺈 꺈 꺈 꺈 꺈
C0 꺈 꺈 꺈 꺈 꺈 꺈 꺈 꺈 꺈 꺈 꺈 꺈 꺈
D0 꺈 꺈 꺈 꺈 꺈 꺈 꺈 꺈 꺈 꺈 꺈 꺈 꺈
E0
F0

Code Page 949 Korean (Cont.)

CA40 - CAFF

40
50
60
70
80
90
A0 伽佳假價加可呵哥嘉嫁家暇架枷柯
B0 歌珂痲稼苛茄街袈珂賈跏軻迦鷓刻却
C0 各恪殼殼珏脚覺角關侃刊藝奸森干幹
D0 懇揀杆乘桿澗瀾看礪稗竿簡肝良艱諫
E0 間芻囑曷湯碼竭葛禡鳩勸坎堪嵌感
F0 憾駭敢柑橄滅甘疳監敵紺邯繼鑿齏

CC40 - CCFF

40
50
60
70
80
90
A0 臉鈐鈐劫怯怯遠偈翹揭擊格橄激膈現
B0 隔堅牽犬甄綉繭脣兒髓遺鵬抉決潔結
C0 缺缺兼嫌箝謙鉗鑣京徑倥傾傲勁勅脚
D0 垠境庚徑慶憤擊敬景曠更梗涇炁烟環
E0 璣瓊瘰硬碧實競綉經耕耿脛莖誓輕運
F0 鏡頃頸驚鯨係啓堺契季屆悻戒桂械

CE40 - CEFF

40
50
60
70
80
90
A0 科菓誇課跨過綢穎廓榔藿郭串冠官
B0 寬憤棺款瀦瑄瑄管罐菅觀貫關館刮愨
C0 括适侑光匡壙廣曠洸吹狂珙篋胱續卦
D0 掛雲乖傀塊壤怪愧拐槐魁宏絃肱轟交
E0 僑咬喬嬌嶠巧攪教校橋狡皎矯絞翹膠
F0 番蛟較矯郊皎驕皎丘久九仇俱具勾

CB40 - CBFF

40
50
60
70
80
90
A0 匣岬甲胛鉀聞剛罔蕪岡崗康强彊慷
B0 江薑疆糠絳絳羌腔紅薑襁講綱降鱗介
C0 价個凱墮愷愷改概溉疥皆蓋箇芥蓋
D0 壹錯關嗜客坑更梗憂醜偈去居巨拒据
E0 據舉渠炬祛距踞車遽鉅鍋乾件健巾建
F0 愨礎礎虞蹇蹇齋乞傑杰桀儉劍劔檢

CD40 - CDFF

40
50
60
70
80
90
A0 磔溪界癸礪稽系繫繼計誠谿階鷄古
B0 叩告呱固姑孤尻廡拷攷攷鬻枯槁沽
C0 瘡蟲壽稿羔考股膏苦苾菰薰蠱禱誥賈
D0 辜鑄履履高鼓哭斛曲楷穀谷鷓困坤崑
E0 昆梱棍滾琨琨衰鯤汨滑骨供公共功孔工
F0 恐恭拱控攻玳空蚣賈鞏串寡戈果瓜

CF40 - CFFF

40
50
60
70
80
90
A0 區口句咎囑坵垢寇嶇廐懼拘救枸樞
B0 構歐歐毬求溝灸狗玖球瞿矩究綵書白
C0 窮舊苟衝謳購驅逯邱鈞錄駒驅鳩鷓龜
D0 國局菊鞠鞠趨君奢群裙軍郡堀屈掘窟
E0 宮弓窳窮芎窮倦券勸卷圍拳捲權眷
F0 厥厥厥驟關机櫃潰詭軌饋句曷歸貴

Code Page 949 Korean (Cont.)

D040 - D0FF

40
50
60
70
80
90
A0 鬼龜叫圭奎揆槻珪硯窺覈糾葵規赴
B0 遠闊勻均鈞筠園鈞龜橘克剋劇戟棘極
C0 隙僅肋勳勳斤根槿瑾筋芹董觀腫近謹
D0 契今姁摛吟檣琴禁寓芩衾衿襟金錦級
E0 及急扱扱級給亘競矜肯企伎其冀嗜器
F0 圻基琦藝奇妓寄岐崎己幾忌技旗旣

D140 - D1FF

40
50
60
70
80
90
A0 菁期杞棋棄機欺氣汽沂淇玳琦琪瑾
B0 璣琦畿碁磯邢祗祈祺冀紀綺羈耨機肌
C0 記讎壹起銻鎮飢饑騎騏驎獸緊信吉拮
D0 桔金喫儼喇奈娜懶擊拿獮羅羅螺裸
E0 邇那樂洛烙珞落諾酪駱亂卵暖欄爇爛
F0 蘭難鸞掙捺南嵐柎楠浦濫男藍襪拉

D240 - D2FF

40
50
60
70
80
90
A0 納臘蠟衲囊娘廊朗浪狼郎乃來內奈
B0 奈耐冷女年撚季念恬拈捻寧寧努勞奴
C0 聾怒搗摶爐璫盧老蘆虜路露鷲魯鷲碌
D0 祿綠莖錄鹿論壘弄濃籠聾膿農惱牢磊
E0 腦賂露尿壘厲樓淚漏累纒陋嫩納扭紐
F0 勒肋凜凌稜綾能菱陵尼泥匱濶多荼

D340 - D3FF

40
50
60
70
80
90
A0 丹璽但單團壇彖斷且檀段湍短端簞
B0 緞蛋袒鄆鍛撻漣瀾疽遠啖坩儻攢曇淡
C0 湛潭潛疲腩膽毒覃談譚鈇沓沓答踏選
D0 膚堂墻幢擘擗棠嘗糖螳黨代岱殆大對
E0 岱帶待戴擗玳臺袋貸隊黨宅德惠倒刀
F0 到圖墻塗導屠烏嶋度徒悼挑掉搗桃

D440 - D4FF

40
50
60
70
80
90
A0 棹櫂洩渡滔濤濼盜賭禱稻荀觀賭跳
B0 蹈逃途道都鍍陶韜壽瀆瀆擗獨督禿篤
C0 轟讀墩惇敦吨噉沌焯嫩豚碩芎突全冬
D0 凜動同懂東桐棟洞渣痊腫畫洞畫銅兜
E0 斗杜抖痘賣莖讀豆逗頭屯臀苞遍遜鈍
F0 得燈橙燈登等藤騰鄧騰喇懶擊癩羅

D540 - D5FF

40
50
60
70
80
90
A0 羅螺裸邇樂洛烙珞絡落諾酪駱丹亂
B0 卵欄樂瀾欄蘭鸞刺辣嵐掣攬攪濫籃纜
C0 藍襪覽拉臘蠟廊朗浪琅榔榔郎來啞
D0 徠萊冷掠略亮倆兩涼梁樑糧梁糧良諒
E0 輛量侶僂勵呂慮慮戾旅欄濾礪藜蠟閻
F0 驪驪麗黎力曆歷漚礫礫靈憐戀擊漣

Code Page 949 Korean (Cont.)

D640 - D6FF

40
50
60
70
80
90
A0 煉躑躅聯蓮盤連鍊冽列劣冽烈裂廉
B0 斂殮瀟蕭獵令伶囹罩岑嶺伶玲苓矜翎
C0 聆逞鈴零靈領齡例禮禮隸勞怒撈攆
D0 橋潞瀟爐盧老慮虞路絡露魯鶯鹵碌綠
E0 綠茶錄鹿麓論壘弄麗瀟瓊龍嬰偏瀨牢
F0 磊賂賣賴雷了僚寮廖料煉療瞭聊聊

D740 - D7FF

40
50
60
70
80
90
A0 遠闊龍壘囊屢樓淚漏瘰累縷蕪樓錄
B0 陋劉旒柳榴流溜瀏琉瑠留瘤硫膠類六
C0 戮陸侷倫倫壽滄繪輪律慄栗率隆勒肋凜
D0 凌楞稜綾菱陵俚利厘吏喇履俐李梨涅
E0 犁理瑤璵異痢離羅羸莉裏裡里釐離鯉
F0 吝溝熾璵閻蹶隣鱗鱗林淋淋躡躡

D840 - D8FF

40
50
60
70
80
90
A0 立笠粒摩瑪麻碼磨馬魔麻寔幕漠膜
B0 莫邁万巳媿巒巒慢挽晚曼滿漫濶瞞萬
C0 蔓蠻饒饒饒能抹末沫萊襪寐亡妄忘忙
D0 望網罔芒茫莽綯邛埋妹煤寐味枚梅每
E0 煤罵賈賈邁魅脈貊陌暮麥孟氓猛盲盟
F0 萌幕覓免冕勉棉沔眄眠綿緬面麵滅

D940 - D9FF

40
50
60
70
80
90
A0 蕙異名命明暎稔溟血暝茗萸螟酪銘
B0 鳴袂侮冒暮姆帽慕摸暮某模母毛牟
C0 牡瓠眸矛耗茅謀讓貌木沐牧目睦穆
D0 驚致沒夢朦蒙卯墓妙廟描鼎沓渺貓妙
E0 苗錯務巫撫懋戍拇撫无淋武母無玳敵
F0 緜舞茂蕪誣質霧鷓墨默們勿吻問文

DA40 - DAFF

40
50
60
70
80
90
A0 汶紊紋閻蚊門雲勿勿物味媚尾媚彌
B0 微未槐檣漢漚眉米美薇謎迷靡微岷閱
C0 愍憫敏曼旻民混玳珉縉閱密蜜醴劍博
D0 拍搏撲朴樸泊珀璞箔粕縛膊舶簿迫雹
E0 駁伴半反叛拌撥攀斑盤泮潘班畔癖盤
F0 盼譬礪礪絆般燿返頒飯勃拔撥渤潑

DB40 - DBFF

40
50
60
70
80
90
A0 發跋蹶鉢髮越傲傍坊妨尪幫彷彿放
B0 方旁昉枋榜滂磅紡肪膀舫芳蕩蚌訪謗
C0 邦防龐倍俳北培俳拜排杯湃焙盃背胚
D0 裴裴褸賠輩配陪伯佰卑柏栢白百魄魄
E0 樊煩燔番幡繁蕃藩翻伐筏罰闊凡帆梵
F0 汜汎泛犯範范法珙僻劈壁壁壁壁

Code Page 949 Korean (Cont.)

DC40 - DCFF

40
50
60
70
80
90
A0 碧藥關驛便卞弁變辨辯邊別營紫甍
B0 丙併兵屏井晒鬲柄棟炳瓶病秉竝駢餅
C0 駢保堡報賈普步狀深潛珣楠菩補襍譜
D0 輔伏僕匍卜宓復服福腹茯葡複覆輶輻
E0 龍顛本惠倭奉封峯峰捧捧烽燧璿璿蓮
F0 蟻遙錄鳳不付俯傅副副否咐埠夫婦

DD40 - DDFF

40
50
60
70
80
90
A0 孚夥富府復扶敷斧浮溥父符簿缶腐
B0 腑膚輝芙季訃責賦賻赴跣部釜卓附駙
C0 曷北分吩噴墳奔奮忿憤扮扮汾焚盆粉
D0 糞紛芬實霧不佛弗佛拂崩朋棚棚繡繡
E0 丕備匕匪卑妃婢庇悲德靡批斐批樞比
F0 彪毗毘沸泌琶痺砒砒砒秘批緋緋肥

DE40 - DEFF

40
50
60
70
80
90
A0 脾臂菲藍裨誹譬費鄙非飛鼻嘖嬪彬
B0 斌檣殞浜濱瀕牝玼貧實頻憑冰聘聘乍
C0 事些仕伺似使俟僂史司峻嗣四士奢娑
D0 寫寺射巳師徙思捨斜斯柶查梭死沙泗
E0 瀟瀟獅砂社祀祠私篩紗絲肆舍莎賽蛇
F0 裝詐詞謝賜赦辭邪飼駟駟削數朔藥

DF40 - DFFF

40
50
60
70
80
90
A0 傘刪山散汕珊產疝算蒜酸霰筵撒殺
B0 簾薩三參杉森滲苒蓼衫插澁鋸嫗上傷
C0 儻償商喪嘗嫻尙峯常床庠廂想桑橡湘
D0 爽牀狀相祥籍翔裝觴詳象賞霜塞靈賽
E0 齋塞種索色牲生甥省筌豎墻嶼序庶徐
F0 愬抒摯絞暑曙書栖棲犀瑞茲絮緒薯

E040 - E0FF

40
50
60
70
80
90
A0 胥舒薯西誓逝鋤黍鼠夕爽席惜昔皙
B0 析汐浙瀉石碩薦釋錫仙僂先善嬋宣屬
C0 敷旋渣燭珽瓊璇璿癩禪線繕揆腺膳船
D0 蘇蟬詵詵選詵鑄鑄鮮島胥楔泄洩滌舌
E0 薛裴設說霽醫剌暹穰穰蟾臙閃陝攝涉
F0 變葉城姓宥性懼成量晟猩城盛省晟

E140 - E1FF

40
50
60
70
80
90
A0 聖聲腥誠醒世勢歲洗稅筭細說賈召
B0 囁望宵小少巢所掃播昭梳沼消溯瀟炤
C0 燒甞疏疎瘡笑篠簫素紹蔬蕭蘇訴道遯
D0 邵銷韶騷俗屬東凍粟纈讓贖速孫巽損
E0 蕪遜凜率宋悚松淞訟誦送頌刷殺瀾碎
F0 鎖衷劍修受嗽囚垂壽嫂守岫宙帥愁

Code Page 949 Korean (Cont.)

E240 - E2FF

40
50
60
70
80
90
A0 戍手授搜收數樹殊水洙漱燧狩獸琇
B0 璩瘦睡秀穗整粹綬綬繡蓋脩茱萸蓓藪
C0 袖誰響輸達達酬銖綉隋隄隨雖需須首
D0 髓鬚叔塾夙孰宿淑瀟熟瑒璠肅菽巡徇
E0 循恂旬枸楸楸狗洵洵瑁盾瞬筍純膏舜
F0 荀寡寡詢醇醇錘順馴戍術述紬崇崧

E340 - E3FF

40
50
60
70
80
90
A0 嵩瑟膝疊濕拾習褶襲丞乘僧勝升承
B0 昇繩繩陸侍匙嘶始媿尸屎屍市弒恃施
C0 是時柙柴猜矢示翅蒔審視試詩謹豕豺
D0 壘塞式息拭植殖湫燧簋蝕譜賦食飾伸
E0 侏僂呻娠廣慎新晨燼申神紳腎臣莘薪
F0 臺暨訊身辛辰迅失室實悉審尋心沁

E440 - E4FF

40
50
60
70
80
90
A0 沈深潛甚苾謏什十拾雙氏亞俄兒啞
B0 娥峨我牙芽莪蛾衙訝阿雅餓鴉鵝靈岳
C0 嶽嶽惡愕握樂濯鄂鏗顛觸齧安岸按晏
D0 案眼雁鞍顏鮫幹謁軋閱噉岩巖庵暗癌
E0 奄閻壓押狎鴨仰央快昂殃殃黨厓裏埃
F0 崖爰暖漣磚艾陰羈厄扼掖液繼腋額

E540 - E5FF

40
50
60
70
80
90
A0 櫻嬰鶯鶯也御冶夜惹挪椰爺耶若野
B0 弱掠略約若葯蕩藥躍亮佯兩涼壤壤恙
C0 揚攘駁陽梁楊樣洋漾揚瘴瘍禳穰糧羊
D0 良襄諒諒闕陽量養團御於漁瘀樂語馭
E0 魚齟億憶抑憶臆偃堰彥焉言諳擊擊俺
F0 儼嚴奄掩淹業業円予余勵呂女如廬

E640 - E6FF

40
50
60
70
80
90
A0 旅歟汝瀟璵璵礪與餘茹與覺閻餘曠
B0 麗黎亦力域役易曆歷疫繹譚嶮逆驪嚙
C0 瓊妍媯婁年延憐戀搗挺撚椽沅沿涎涓
D0 淵瀆漣烟然燿煉燃蕪璉研硯季筵緣練
E0 續聯衍軟蠶蓮蓮鉛鍊薦列劣咽悅涅烈
F0 熱裂說閱厭廉念捻染殮炎焰琰鮑苒

E740 - E7FF

40
50
60
70
80
90
A0 簾間髻鬢擘擘燻燻葉令困瑩寧嶺嶺影
B0 伶映映楹樂永泳洪穎灑瀟灑煥燿燿玲
C0 瑛瑛瑛盈穎纓玲聆英詠迎鈴鏤零靈靈
D0 領又倪例刈叟曳汨瀦猊奢穰芮藝穰禮
E0 裔詣譽豫醜銳棘覽預五伍伍傲午香吳
F0 嗚塢塢奧娛瘡瘡悟惡悞悞教昨晤梧汚漢

Code Page 949 Korean (Cont.)

E840 - E8FF

40
50
60
70
80
90
A0 烏熬葵冀蜈誤蕪龔屋沃獄玉鈺溫璠
B0 邇穩緇繇兀壘擗叁薺癩翁蠱雍甕渦瓦
C0 窩窪臥蛙蝸訛婉宛宛椀惋浣玩琬琬碗
D0 緩馱腕腕莞腕阮頑曰往旺枉汪王倭娃
E0 歪矮外寬覲覬畏了儻儻凹堯夭妖姚寥
F0 聚尿峽拗搖撓擻料曜樂橈煉燿瑤療

E940 - E9FF

40
50
60
70
80
90
A0 窃窳絲繞耀腰孽蛻要謠遙遠邀執慾
B0 欲浴縛縛尋備備冗勇捅壙容膺憑榕涌
C0 湧溶熔瓊用甬聳葶蕈踊鎔鏞龍于佑偶
D0 優又友右宇寓尤愚憂吁牛玕瑤孟枯耦
E0 馮紆羽芋藕虞迂遇郵舒隅雨弩勳馮旭
F0 畏柁煨穢郁瑣云暈櫻殞潑煨耘芸嬰

EA40 - EAFF

40
50
60
70
80
90
A0 暹隅雲韻蔚鬱亏熊雄元原員圓園垣
B0 嬾嫻寬怨愿援沅洹浚源爰猿媛苑袁轅
C0 遠阮院願鷺月越鉞位偉僞危圍委威尉
D0 慰賄渭爲瑋緯胃萎葦蕪媯衛禮謂違韋
E0 魏乳侑備兪劉唯噲孺宥幼幽庾悠惟愈
F0 愉揄攸有杻柔柚柳楡檣油清流游溜

EB40 - EBFF

40
50
60
70
80
90
A0 漚猶飲琉瑜由留應硫紐維與奕裕誘
B0 誤輸踰踈遊逾遺酉釉鎗類六堵戮毓肉
C0 育陸倫允翊尹衛滄澗玢胤贊輸銃閻律
D0 慄栗率韋戎泐絨融隆垠恩殷殷閻銀隱
E0 乙吟淫蔭陰音飲揖泣邑凝應膺鷹依倚
F0 儀宜意懿擬椅毅疑矣蕪蠟薑蠟衣隄

EC40 - ECFE

40
50
60
70
80
90
A0 躡醫二以伊利吏夷姨履已弛彝怡易
B0 李梨泥爾珥理異痲痢移確而耳聾致冀
C0 裏裡貽貳還里離餉餉區瀾瀾益翊翌翼
D0 謔人仁刃印吝咽困姻實引忍澶熾璘網
E0 菌蘭蚓認隣鞞鞞鱗鱗一佚份壹曰溢逸
F0 鎡駟任壬妊姪恁林淋稔臨莅賃入什

ED40 - EDFF

40
50
60
70
80
90
A0 立笠粒仍剩孕苻仔刺咨姊姿子字孜
B0 恣恣滋炙煮茲瓷疵磁紫者自茨蔗藉諮
C0 資雌作勻嚼斫昨灼炸爵綽芍酌雀鷓戾
D0 棧殘滌盡岑暫潛箴簪蠶雜丈仗匠場墻
E0 壯獎將帳庄張掌擘杖樟檣穢漿牆狀獐
F0 璋章粧腸臙臙莊葬蔣蓄藏裝臟醬長

Code Page 949 Korean (Cont.)

EE40 - EEFF

40
50
60
70
80
90
A0 障再載在宰才材裁梓濊滓災緝裁財
B0 載齋齋爭爭諍錚佇低儲咀姐底抵杵楮
C0 樽沮渚狙猪疽箸紵苧著齏詛貯躡躡
D0 邸雖雖勳吊嫡寂摘敵滴狄炙的積笛籍
E0 績響荻藹賊赤跡蹟迫迹適鑄佃仝傳全
F0 典前剪填塲奠專展廛悛戰栓殿氈澗

EF40 - EFFF

40
50
60
70
80
90
A0 煎瑣田甸畑癩釜簞箭簞纏詮輟轉細
B0 銓錢鑄電順順錢切截折浙齏糶節絕占
C0 站店漸点粘霑黏點接搗蝶丁井亭停偵
D0 呈妊定幘庭廷征情挺政整旌晶叢枉槓
E0 禮正汀淀淨淨漬滯疋玎玘叮睛錠積程
F0 猝精緹緹訂諄貞鄭訂釘鉦鉷錠靈靖

F040 - F0FF

40
50
60
70
80
90
A0 靜頂鼎制劑啼堤帝弟悌提梯濟祭第
B0 臍齊製諸蹄醍除際霽題齊俎兆凋助嘲
C0 弔彫措操早晁曹朝條棗槽漕潮照燥
D0 爪瓖眺祖祚租穉窳粗糴組縲孽藻詔
E0 調趙躁造遭鈞阻雕烏族簇足繼存尊卒
F0 拙猝侏宗從棕慙棕涼琮種終綜縱腫

F140 - F1FF

40
50
60
70
80
90
A0 踪踵鍾鐘佐坐左座挫罪主住侏倣姝
B0 曹呪囫噉輿宙州廚畫朱柱株注洲湊澍
C0 炷珠囁籌紂紉綱舟蛛註誅走躡躡週耐
D0 酒鑄駐竹粥俊備准塢峻峻峻溲溲溲
E0 煨煨竣霽竣遠遠駕駿茁中仲衆重卽榔糧
F0 汁葦增僧曾拯蒸甑症縉蒸證贈之只

F240 - F2FF

40
50
60
70
80
90
A0 咫地址志持指擊支旨智枝枳止池址
B0 漬知砥祉祗紙肢脂至芝芷蚰詭讖贊趾
C0 遲直稹稹織職營嶼塵振摺晉晉板檣珍
D0 漣漣珍瓊瓊珍疹瘞眞眞素縉縉縉縉
E0 診贖診辰進鎮陣陳慶侄叱姪嫉佚桎瓊
F0 疾秩竇腫蛭質跌送斟朕什執濼縉縉

F340 - F3FF

40
50
60
70
80
90
A0 鑱集徽徽澄且佗借又嗟嶮差次此礎
B0 筍茶隧車遽捉擗擗窄錯盤巖撰潔燦燦
C0 瓊瓊菓菓縉縉贊贊贊贊饌刹察擦札棗
D0 僧參暨慘慙憾斬站讎讎倉偏創唱颯廠
E0 彰槍敵昌颯暢槍滄漲獨瘡怒脹膾薑蒼
F0 價塚窠窠彩採痞綵菜蔡采釵冊柵策

Code Page Traditional Chinese (Cont.)

F440 - F4FF

40
50
60
70
80
90
A0 賁湊妻懷處侷刺剔尺憾戚拓擲斥滌
B0 瘠脊蹠陟隻仟千喘天川擅泉淺玠穿舛
C0 鷹賤踐運釧聞阡韃凸哲詰徹撤澈綴綴
D0 轍鐵僉尖沾添話贖簽籤鷹詔堞妾帖捷
E0 牒疊腫謀貼輒廳晴清聽菁請青鯖切刺
F0 替涕滯締諦遠遞體初劑哨憺抄招梢

F540 - F5FF

40
50
60
70
80
90
A0 椒楚樵炒焦硝礁礎秒稍肖艸苔草蕉
B0 貂超酢醋醜促囁燭轟蜀觸寸忖村邨叢
C0 塚寵愚憶摠總聰蕙統撮催崔最墜抽推
D0 椎楸樞湫皺秋芻菽諷趨追鄒齒醜錐錘
E0 鎚難翳歟丑蓄祝竺筑築縮菁聲蹴軸逐
F0 春椿璿出朮黜充忠沖轟衝衷悴臍萃

F640 - F6FF

40
50
60
70
80
90
A0 贅取吹嘴娶就炊翠聚脆臭趣醉驟贅
B0 側仄厠惻測層侈值嗑峙幘恥樞治淄熾
C0 痔痲癢稚穉縉緞置致嶺輜雉馳齒則勅
D0 飭親七柒漆優寢枕沈浸琛砧針鍼蟄秤
E0 稱快他咤唾墮妥愜打拖朶檣舵陀馱駝
F0 俶卓喙垢度托拓擻暉柝濁濯琢璋託

F740 - F7FF

40
50
60
70
80
90
A0 鑼吞嘆坦彈憚歎灘炭綻誕奪脫探耽
B0 耽貪塔搭榻宕帑湯糖蕩兌台太怠態殆
C0 汰泰答胎苔胎郤駘宅擇澤撐摑兎吐土
D0 討慟桶洞痛簡統通堆槌腿榷退頹偷套
E0 妬投透闕慝特闕坡婆巴把播擺杷波派
F0 爬琶破罷芭跛頗判坂板版瓣販辦飯

F840 - F8FF

40
50
60
70
80
90
A0 阪八叭捌佩唄悖敗沛涓牌猥稗霸貝
B0 彭澎烹膨悞便偏扁片篇編翩遍鞭騙貶
C0 坪平枰萍評吠嬰幣廢弊斃肺蔽閉陞佈
D0 包匍匍咆哺圃布怖拋抱捕暴泡浦庖砲
E0 胞脯匍葡蒲袍褒遠鋪飽飽幅暴曝瀑爆
F0 輻倭剝彪標杓標漂飄票表豹驕驕驕

F940 - F9FF

40
50
60
70
80
90
A0 品稟楓飄豐風馮彼披疲皮被避陂匹
B0 弼必泌泌畢疋筆苾秘乏邇下何屢夏廈
C0 豐河瑕荷蝦賀避霞蝦壑學虐謔鶴寒恨
D0 憚畢汗漢潞瀚罕翰閑閑限轄割轄函含
E0 戚啣噉權涵緘艦銜陷鹹合哈盒蛤閤闔
F0 陝亢伉媼嫵巷恒抗杭桁沆港缸肛航

Code Page 949 Korean (Cont.)

FA40 - FAFF

40
50
60
70
80
90
A0 行降項亥偕咳垓奚孩害懶楷海澄蟹
B0 解該階選駭骸劾倖杏苻行享向嚮
C0 瑯鄉響銷響香噓墟虛許憲權獻軒歇險
D0 驗奕嶙赫革偃峴弦懸曉法炫玄玆現眩
E0 眼絃絢縣絃街見賢鉉顯子穴血貢嫌俠
F0 協夾峽挾浹挾脅莢缺頰亨兄刑型

FB40 - FBFF

40
50
60
70
80
90
A0 形洞熒濼濼炯熒珩螢荊螢衡迥邢螢
B0 龔兮馨憲慧曙憲蹊醴鞋乎互呼壤壘好
C0 咕弧戶履昊皓毫浩漢湖潏滌濼瀾瀾狐
D0 琬瑚瓠皓枯糊縞胡芦葫蒿虎號瑚護豪
E0 鎬護顛惑或酷婚昏混渾環魂忽惚笏哄
F0 弘永泓洪烘紅虹缸鴻化和燐樺火燾

FC40 - FCFF

40
50
60
70
80
90
A0 禍禾花華話譁貨靴廓擴撰確礪禮丸
B0 喚奐宦幻患換歡皖桓渙煥環紈還驪鯨
C0 活滑猾豁闊鳳幌徨恍惶恍晃晃晃晃况
D0 澆滉潢煇璜璜璜璜璜璜璜璜璜璜璜
E0 徊恢悔懷晦會檜淮淮淮淮淮淮淮淮淮
F0 賄劃獲弘橫橫橫橫橫橫橫橫橫橫橫橫

FD40 - FDFF

40
50
60
70
80
90
A0 爻肴醇驍侯侯厚后吼喉嗅喉後朽煦
B0 翊運勳勳墳壘蕪蕪蕪蕪蕪蕪蕪蕪蕪
C0 董卉噉毀彙徽揮暉輝輝輝輝輝輝輝
D0 虧恤驕驕兇凶匈洵胸黑昕欣忻痕吃屹
E0 紇訖欠欽欽吸怡洽禽興僊熙喜噫驪姬
F0 墟希憲懼戲晞囁熙熙熙熙熙熙熙熙熙

Code Page 949 Traditional Chinese (Cont.)

A840 - A8FF

40 杓杓步每求黍沙沁沈沉沉沛汪泱沐汰
 50 沌汨冲沒汽沃汲汾汴沈汶沔沔沂灶
 60 灼災灸牢牡牠狄狂玖甬南男旬皂叮矣
 70 私秀禿究系翠肖青肝肘肛肚育良芒
 80
 90
 A0 芋芍見角曹谷豆豕貝赤走足身車辛
 B0 辰迂迤迅迄巡邑邢邪邦那酉采里防阮
 C0 陴阪阮並乖乳事些亞享京佯依侍佳使
 D0 佬供例來侃倍併侈佩佻禽侑侏侑佻兔
 E0 兒兕兩具其典冽函刻券刷刺到刮制剝
 F0 効勁卒協卓卑卦卷卸卹取叔受味呵

A940 - A9FF

40 咖呷咕咀呻呷咄咒咆呼咐呱呶和咚呢
 50 周咋命咎固坵坳坪坳坳坳坳坳坳坳
 60 奈奄奔妾妻委妹妮姑姆姐孀始姓姊妯
 70 姝姝婢孟孤季宗定官宜宙宛侑屈屠
 80
 90
 A0 屨岷岡岸岩岫岱岳帘帶帖帕帛帛帛
 B0 庚店府底庖延弦弧鸞往征佛彼忝忠忽
 C0 念忿快怔怯怵怖怪怕怡性恹佛但或戕
 D0 虜戾所承拉拌拄振搥搥搥搥搥搥搥
 E0 拈揅抽揅揅揅揅揅揅揅揅揅揅揅揅揅
 F0 捨放斧於旺昔易昌昆昂明昡昏昕昊

AA40 - AAFF

40 昇服朋杭枋枕東果杏杷枇枝林柅杰板
 50 枉松析杵枚料杵杵杵杵杵杵杵杵杵
 60 注泳沓泌泥河沽沾滔波沫法泓沸泄油
 70 況沮泗泗泱治治泡泛泊沫浪泚泚泚
 80
 90
 A0 炕爇炒炊炙爬爭爸版牧物狀狎狙狗
 B0 狐玩玃玃玃玃玃玃玃玃玃玃玃玃玃
 C0 社祀祁稟稟稟稟稟稟稟稟稟稟稟稟
 D0 肱股肱肱肱肱肱肱肱肱肱肱肱肱肱
 E0 芹花芬芥苾芸茱茱茱茱茱茱茱茱茱
 F0 返返郅郅郅郅郅郅郅郅郅郅郅郅郅

AB40 - ABFF

40 陂佳雨膏非亟亭亮信優侯便俠備俏保
 50 促侶俣俣俣俣俣俣俣俣俣俣俣俣俣
 60 曹冠刺刺刺刺刺刺刺刺刺刺刺刺刺
 70 厚叛咬衰咨咬哉威噴咳哇晒咽咪品
 80
 90
 A0 哄哈咯罔罔罔罔罔罔罔罔罔罔罔罔
 B0 城垮埃突契奏奎奕姜姘姿妓媿娃媿娃
 C0 姚姦威姻孩宣宦室客宥封屎屏屍屍時
 D0 峒巷帝帥窳幽率度建奕弭彥很待徊律
 E0 徇後佻怒思怠急怎怨恍恰恨恢恆恃恬
 F0 恫恪恤扁拜挖挖按拊拭持拊搥指拱搥

AC40 - ACFF

40 拯括捨捨挑掛政故斫施既春昭映味是
 50 星昨昱昞曷柿柒柱柔某菓架枯柵柵柯
 60 柄柑枊柚查枸柏柞柳桺桺柢柢架歪殃
 70 殆段毒毗氤泉洋洲洪流津洌洌洌洌洌
 80
 90
 A0 活洽派洵洛泵洵洵洵洵洵洵洵洵洵
 B0 爲炳炬炯炭炸炮熠爇爇爇爇爇爇爇
 C0 珊瑚玲珍珀玳基甯畏界畎畎畎畎畎
 D0 洗癸皆皇飯盈盆盃盃盃盃盃盃盃盃
 E0 眇矜矜矜矜矜矜矜矜矜矜矜矜矜矜
 F0 突竿竿籽紉紅紀紉紉紉紉紉紉紉紉

AD40 - ADFF

40 耐耍崙耶胖胥胥胥胥胥胥胥胥胥胥
 50 致舛苧范茅苜苜苜苜苜苜苜苜苜苜
 60 苜苜苜苜苜苜苜苜苜苜苜苜苜苜苜
 70 計訂訃訃訃訃訃訃訃訃訃訃訃訃訃
 80
 90
 A0 迭迫迤迤郊郎郁郅郅郅郅郅郅郅
 B0 降面革羣非音頁風飛食首香乘毫借借
 C0 倣俯倦倣倣倣倣倣倣倣倣倣倣倣倣
 D0 倣倣倣倣倣倣倣倣倣倣倣倣倣倣倣
 E0 冢凍淮淮潤割割割割割割割割割割
 F0 唐嘈嘈嘈嘈嘈嘈嘈嘈嘈嘈嘈嘈嘈嘈

AE40 - AEFF

40 哦啣唇噀唏圍圍圍圍圍圍圍圍圍圍
 50 娑娘娜媚娛媿媿媿媿媿媿媿媿媿媿
 60 害家裏宮穹容震射層展展嶂峻峻峻嶽
 70 嶽嶽嶽嶽嶽嶽嶽嶽嶽嶽嶽嶽嶽嶽嶽
 80
 90
 A0 恣恥恐怨恭恩息情愜慍悻悻悻悻悻
 B0 扇拳擊拿揜揜揜揜揜揜揜揜揜揜揜
 C0 揜揜揜揜揜揜揜揜揜揜揜揜揜揜揜
 D0 晁晁晁晁晁晁晁晁晁晁晁晁晁晁晁
 E0 桌桑栽柴桐桀格桃株槐桎柎柎柎柎
 F0 氣氣氣氣氣氣氣氣氣氣氣氣氣氣氣

AF40 - AFFF

40 溼涉浮浚浴浩涌潏潏潏潏潏潏潏潏潏
 50 烈烏鬱特狹狹狹狹狹狹狹狹狹狹狹狹
 60 畔畝奮奮畱疾痲痲痲痲痲痲痲痲痲
 70 飽益盍盍盍盍盍盍盍盍盍盍盍盍盍
 80
 90
 A0 砥砥砥砥砥砥砥砥砥砥砥砥砥砥砥
 B0 秣秧租稟秧秘窄窳站笛笑粉紛紗紋紊
 C0 紊紊純紐紙紘級紙紘級紙紘級紙紘級
 D0 耘耕耙耗耽耽耽耽耽耽耽耽耽耽耽耽
 E0 能脊胛膊臬臬臬臬臬臬臬臬臬臬臬
 F0 荆葦葦草茵茵茵茵茵茵茵茵茵茵茵茵

Code Page 980 Traditional Chinese (Cont.)

B040 - B0FF

40 虞蚊蚪蛭蚤蚩蚌蚣蚜衰袁袞袞祇記
50 訐討訑訑訑訑訑訑訑訑訑訑訑訑訑訑訑
60 躬軒軋軋軋軋軋軋軋軋軋軋軋軋軋軋
70 郡郝郢酒配酌釘針劍釜針閃院陣陡
80
90
A0 陸陔除陟陟隻飢馬骨高門高鬼乾僂
B0 僞傳假僞僞僞僞僞僞僞僞僞僞僞僞僞
C0 佞個兜冕鳳剪副勒務勸勸勸勸勸勸勸
D0 匾參曼商啞啞啞啞啞啞啞啞啞啞啞啞
E0 啤唸售啜啜啜啜啞啞啞啞啞啞啞啞
F0 埠埠基堂培軌培夠耆娶婁媯媯媯媯

B140 - B1FF

40 媯媯媯媯媯媯媯媯媯媯媯媯媯媯媯
50 雁屏崇崴崴崴崴崴崴崴崴崴崴崴崴崴
60 常帶帳帷廉廉廉廉廉廉廉廉廉廉廉廉
70 從從從從從從從從從從從從從從從從
80
90
A0 情悻悻悻悻悻悻悻悻悻悻悻悻悻悻悻
B0 掠控捲掖探接捷捧掘措挂掩掉掃掛掛
C0 推掄授掄採掄採掄採掄採掄採掄採掄採掄
D0 教啟啟啟啟啟啟啟啟啟啟啟啟啟啟啟啟
E0 晤晨晦晦曹翳望梁梯梢梓梵樺樺樺樺
F0 榎槭槭槭槭槭槭槭槭槭槭槭槭槭槭槭

B240 - B2FF

40 毫毳氈涎涼淳涼液淡淌淤添淺清淇淋
50 涯淑澗澗澗澗澗澗澗澗澗澗澗澗澗澗澗
60 深淮淨滑溜滑溜滑溜滑溜滑溜滑溜滑溜
70 犁猜猛猛猛猛猛猛猛猛猛猛猛猛猛猛猛
80
90
A0 瓷甜產略哇畢異疏壽痕疵痊痼咬筮
B0 盒盛眷眾眼眶眸眺疏硃硃硃硃硃硃硃
C0 笠笠笠笠笠笠笠笠笠笠笠笠笠笠笠笠笠笠
D0 紹縟縟縟縟縟縟縟縟縟縟縟縟縟縟縟
E0 粗聊聆脯脰脰脰脰脰脰脰脰脰脰脰脰
F0 莞莘莘莢莖莖莖莖莖莖莖莖莖莖莖莖莖

B340 - B3FF

40 葡萹處彪蛇蛙蚌蛤蚧蚧蚧蚧蚧蚧蚧蚧
50 袈被袒袖袍袋覺規訪訝訣訥許設訟訛
60 訛駁駁駁駁駁駁駁駁駁駁駁駁駁駁駁
70 造逋逋逋逋逋逋逋逋逋逋逋逋逋逋逋
80
90
A0 部郭都酏野釵鈞鈞鈞鈞鈞鈞鈞鈞鈞鈞鈞
B0 陸陰陣陶陷陞霄雪零章竟頂頃魚鳥鹵
C0 鹿麥麻傢傍傳備傑僥僥僥僥僥僥僥僥
D0 創剩勞勝勳博厥菅喀噎噎噎噎噎噎噎
E0 喪哩喇喋喋喋喋喋喋喋喋喋喋喋喋喋喋
F0 喫噉園堯堪場堤堰報堡垆垆垆垆垆垆

B440 - B4FF

40 嫵媚嫵嫵嫵嫵嫵嫵嫵嫵嫵嫵嫵嫵嫵
50 嵐嵐嵒巖嶂嶂嶂嶂嶂嶂嶂嶂嶂嶂嶂嶂嶂
60 循徨惑惑惑惑惑惑惑惑惑惑惑惑惑惑
70 懷惶愉愉愉愉愉愉愉愉愉愉愉愉愉愉
80
90
A0 插揣提握握握握握握握握握握握握握握
B0 敦敦敦敦敦敦敦敦敦敦敦敦敦敦敦敦
C0 替期朝棺棕棠棘棗椅棟棟棟棟棟棟棟
D0 棟棋棍植椒棉棚檜棊款款款款款款款
E0 毯氤氤氤氤港游漸渡道湧湧渠渥渣減湛
F0 湘渤湖溼瀟瀟瀟瀟瀟瀟瀟瀟瀟瀟瀟瀟瀟

B540 - B5FF

40 漑澳酒潛漚漚漚漚漚漚漚漚漚漚漚漚
50 牌椅屜猶猴猴猩珙珙珙珙珙珙珙珙珙珙
60 琛琦瓊瓊瓊瓊瓊瓊瓊瓊瓊瓊瓊瓊瓊瓊
70 皖皓皴盜幽短碩硬硯稍稭稭稭稭稭
80
90
A0 窗窳童竣等策筆筍筒筍筍筍筍筍筍筍
B0 粥絞結絨紫紫紫紫紫紫紫紫紫紫紫紫
C0 蠶聒肅腕腔腋腋腎脹腴脾膾腴腴舒舜
D0 菩萃菸萃菠菅蕈青華蕈蕈蕈蕈蕈蕈蕈
E0 菽菲菊葵葵葵葵葵葵葵葵葵葵葵葵葵葵
F0 蛤蚶蛤街裁戮欸單視註詁評詞詁註詁

B640 - B6FF

40 詔詛詐詛詛詛詛詛詛詛詛詛詛詛詛詛
50 賀貴買貶賀賀越越越越越越越越越越越
60 貽軻軻軻軻軻軻軻軻軻軻軻軻軻軻軻軻
70 酥量鈔鈕鈳鈳鈳鈳鈳鈳鈳鈳鈳鈳鈳鈳鈳
80
90
A0 間聞閱隊階階階階階階階階階階階階階
B0 集履雲雲雲雲雲雲雲雲雲雲雲雲雲雲雲
C0 黃黍黑亂債債債債債債債債債債債債債
D0 劇劇劇劇劇劇劇劇劇劇劇劇劇劇劇劇劇
E0 網噉噉噉噉噉噉噉噉噉噉噉噉噉噉噉噉
F0 塔填塌塌塌塌塌塌塌塌塌塌塌塌塌塌塌

B740 - B7FF

40 媯媯媯媯媯媯媯媯媯媯媯媯媯媯媯媯
50 感想愛惹惹惹惹惹惹惹惹惹惹惹惹惹
60 歡歡撻撻撻撻撻撻撻撻撻撻撻撻撻撻撻
70 攜敬斟斟斟斟斟斟斟斟斟斟斟斟斟斟斟
80
90
A0 楚檣楠檣檣檣檣檣檣檣檣檣檣檣檣
B0 楫楫楫楫楫楫楫楫楫楫楫楫楫楫楫楫楫楫
C0 滅溥溥溥溥溥溥溥溥溥溥溥溥溥溥溥溥溥
D0 煩煤煉照煜煜煜煜煜煜煜煜煜煜煜煜煜
E0 獅猿獠鄧瑚瑟瑞璋璋璋璋璋璋璋璋璋
F0 痰瘁羶瘁瘁瘁瘁瘁瘁瘁瘁瘁瘁瘁瘁瘁

Code Page 950 Traditional Chinese (Cont.)

B840 - B8FF

40 瞎瞶睬睜睜睜睜矮碎碗碗碗碗碗碗
 50 確陞祺祿禁萬禽稜稚稠稔稔稔宿窠俠
 60 節筠筮筮梁稷粳粳經網網網綬係置罪
 70 署義義群聖聘肆肆肆肆腰腸脰腮腳腫
 80
 90
 A0 腹腺腦翼艇蒂葦落萱葵葦胡葉莖葛
 B0 粵萼葡薑葩葩保虞虞號號號號號號
 C0 蛻蜂蛋蜆蚶蜆衞裝裔裙補裝裝裡農裕袞
 D0 規解耗該詳試詩詰誇詠詠詠詠詠詠詠
 E0 詮詬管詬管管管管管管管管管管管
 F0 駭跡跟跨路跳跳跳跳跳跳跳跳跳跳跳

B940 - B9FF

40 辟農運遊道途途途途途途途途途途途
 50 道鄒鄒鄒鄒鄒鄒鄒鄒鄒鄒鄒鄒鄒鄒鄒
 60 鉞鉞鉞鉞鉞鉞鉞鉞鉞鉞鉞鉞鉞鉞鉞鉞
 70 雷電雷電電電電電電電電電電電電
 80
 90
 A0 飽飾馳駢駢駢駢駢駢駢駢駢駢駢駢
 B0 管飲儀儀儀儀儀儀儀儀儀儀儀儀儀
 C0 嘛普嗽嘔嘔嘔嘔嘔嘔嘔嘔嘔嘔嘔嘔嘔
 D0 應墊境基墊墊墊墊墊墊墊墊墊墊墊墊
 E0 嫩嫵嫵嫵嫵嫵嫵嫵嫵嫵嫵嫵嫵嫵
 F0 慶軒嘔嘔嘔嘔嘔嘔嘔嘔嘔嘔嘔嘔嘔嘔

BA40 - BAFF

40 愚態慷慢憤慚慚慚慚慚慚慚慚慚慚
 50 摺摺摺摺摺摺摺摺摺摺摺摺摺摺摺摺
 60 橘榮檣檣檣檣檣檣檣檣檣檣檣檣檣
 70 歎歌氣潭演滾滾滾滾滾滾滾滾滾滾滾
 80
 90
 A0 滿滯漆漱漸漲漣漣漣漣漣漣漣漣漣
 B0 滌滌滌滌滌滌滌滌滌滌滌滌滌滌滌滌
 C0 瑰瑰瑰瑰瑰瑰瑰瑰瑰瑰瑰瑰瑰瑰瑰瑰
 D0 碟碧碳碩碩碩碩碩碩碩碩碩碩碩碩
 E0 菱筵算箝箝箝箝箝箝箝箝箝箝箝箝
 F0 綾綠緊綴網網網網網網網網網網網網

BB40 - BBFF

40 罰翠翳翳聞聚聚腐腐腐腐腐腐腐腐腐
 50 與孫舞盞盞盞盞盞盞盞盞盞盞盞盞盞
 60 菟蒼養養養養養養養養養養養養養
 70 裴裴裴裴裴裴裴裴裴裴裴裴裴裴裴裴
 80
 90
 A0 說誥誥誥誥誥誥誥誥誥誥誥誥誥誥
 B0 趕隔輔輒輒輒輒輒輒輒輒輒輒輒輒輒輒
 C0 鄺鄺鄺鄺鄺鄺鄺鄺鄺鄺鄺鄺鄺鄺鄺鄺
 D0 鉗鉗鉗鉗鉗鉗鉗鉗鉗鉗鉗鉗鉗鉗鉗鉗
 E0 韶頰頰頰頰頰頰頰頰頰頰頰頰頰頰
 F0 驚鳳麼鼻齊儀儀儀儀儀儀儀儀儀儀儀

BC40 - BCFF

40 劇劈劉劍劍劍劍劍劍劍劍劍劍劍劍
 50 嘆噴嘖嘖嘖嘖嘖嘖嘖嘖嘖嘖嘖嘖嘖嘖
 60 嬋嫵嫵嫵嫵嫵嫵嫵嫵嫵嫵嫵嫵嫵
 70 廚廟廟廟廟廟廟廟廟廟廟廟廟廟廟
 80
 90
 A0 感慰愆愆愆愆愆愆愆愆愆愆愆愆愆愆
 B0 擊摹撞撲撲撲撲撲撲撲撲撲撲撲撲撲
 C0 攝攝攝攝攝攝攝攝攝攝攝攝攝攝攝攝
 D0 標標標標標標標標標標標標標標標標
 E0 渣渣渣渣渣渣渣渣渣渣渣渣渣渣渣渣
 F0 膝膝膝膝膝膝膝膝膝膝膝膝膝膝膝膝

BD40 - BDFF

40 瑾瑾瑾瑾瑾瑾瑾瑾瑾瑾瑾瑾瑾瑾瑾瑾
 50 瞑瞑瞑瞑瞑瞑瞑瞑瞑瞑瞑瞑瞑瞑瞑瞑
 60 窠窠窠窠窠窠窠窠窠窠窠窠窠窠窠窠
 70 絨絨絨絨絨絨絨絨絨絨絨絨絨絨絨絨
 80
 90
 A0 翩翩翩翩翩翩翩翩翩翩翩翩翩翩翩翩
 B0 蔑蔣葵菊蓬蔥蔥蔥蔥蔥蔥蔥蔥蔥蔥蔥
 C0 蝗蟀蝻蝻蝻蝻蝻蝻蝻蝻蝻蝻蝻蝻蝻蝻
 D0 請請請請請請請請請請請請請請請請
 E0 賞賦賤賤賤賤賤賤賤賤賤賤賤賤賤賤
 F0 陽踏踩脚脚脚脚脚脚脚脚脚脚脚脚脚

BE40 - BEFF

40 輓適適適適適適適適適適適適適適適
 50 銷銷銷銷銷銷銷銷銷銷銷銷銷銷銷銷
 60 羸羸羸羸羸羸羸羸羸羸羸羸羸羸羸羸
 70 駛駕駕駕駕駕駕駕駕駕駕駕駕駕駕駕
 80
 90
 A0 缺缺缺缺缺缺缺缺缺缺缺缺缺缺缺缺
 B0 刺刺刺刺刺刺刺刺刺刺刺刺刺刺刺刺
 C0 壁壁壁壁壁壁壁壁壁壁壁壁壁壁壁壁
 D0 憶憶憶憶憶憶憶憶憶憶憶憶憶憶憶憶
 E0 擒擒擒擒擒擒擒擒擒擒擒擒擒擒擒擒
 F0 樹樹樹樹樹樹樹樹樹樹樹樹樹樹樹樹

BF40 - BFFF

40 濃濃濃濃濃濃濃濃濃濃濃濃濃濃濃
 50 燕燕燕燕燕燕燕燕燕燕燕燕燕燕燕
 60 瘴瘴瘴瘴瘴瘴瘴瘴瘴瘴瘴瘴瘴瘴瘴
 70 穆穆穆穆穆穆穆穆穆穆穆穆穆穆穆
 80
 90
 A0 縑縑縑縑縑縑縑縑縑縑縑縑縑縑縑縑
 B0 膩膩膩膩膩膩膩膩膩膩膩膩膩膩膩膩
 C0 螃螃螃螃螃螃螃螃螃螃螃螃螃螃螃螃
 D0 諱諱諱諱諱諱諱諱諱諱諱諱諱諱諱諱
 E0 賴賴賴賴賴賴賴賴賴賴賴賴賴賴賴賴
 F0 遲遲遲遲遲遲遲遲遲遲遲遲遲遲遲遲

Code Page 949 Traditional Chinese (Cont.)

C040 - C0FF

40 錐錦錡銀錙錙閻隨隨險離憂藉霖霍寬
 50 霏靛靜靛靛頰頰頰頰頰頰頰頰頰
 60 鎔鎔駭駭駭駭駭駭駭駭駭駭駭駭
 70 寫默齡齡齡優優優優優優優優優優
 80
 90
 A0 噓噓壓壓壓壓壓壓壓壓壓壓壓壓壓壓
 B0 幫彌微應應應應應應應應應應應應
 C0 擬擺擺擺擺擺擺擺擺擺擺擺擺擺擺
 D0 樂槍樂槍樂槍樂槍樂槍樂槍樂槍樂槍
 E0 濬濬濬濬濬濬濬濬濬濬濬濬濬濬濬
 F0 瀟瀟瀟瀟瀟瀟瀟瀟瀟瀟瀟瀟瀟瀟瀟

C140 - C1FF

40 賤賤矯矯矯矯矯矯矯矯矯矯矯矯矯矯
 50 軟條煉煉煉煉煉煉煉煉煉煉煉煉煉煉
 60 總總總總總總總總總總總總總總總總
 70 聯聯聯聯聯聯聯聯聯聯聯聯聯聯聯聯
 80
 90
 A0 薄薄薄薄薄薄薄薄薄薄薄薄薄薄薄薄
 B0 蟻蟻蟻蟻蟻蟻蟻蟻蟻蟻蟻蟻蟻蟻蟻
 C0 誦誦誦誦誦誦誦誦誦誦誦誦誦誦誦誦
 D0 蹈蹈蹈蹈蹈蹈蹈蹈蹈蹈蹈蹈蹈蹈蹈蹈
 E0 醜醜醜醜醜醜醜醜醜醜醜醜醜醜醜醜
 F0 關關關關關關關關關關關關關關關關

C240 - C2FF

40 駿鮮絞絞絞絞絞絞絞絞絞絞絞絞絞絞
 50 噲噲墳墳墳墳墳墳墳墳墳墳墳墳墳墳
 60 囉囉囉囉囉囉囉囉囉囉囉囉囉囉囉囉
 70 瀆瀆瀆瀆瀆瀆瀆瀆瀆瀆瀆瀆瀆瀆瀆瀆
 80
 90
 A0 恣恣恣恣恣恣恣恣恣恣恣恣恣恣恣恣
 B0 篋篋篋篋篋篋篋篋篋篋篋篋篋篋篋篋
 C0 臍臍臍臍臍臍臍臍臍臍臍臍臍臍臍臍
 D0 覆覆覆覆覆覆覆覆覆覆覆覆覆覆覆覆
 E0 轉轉選選選選選選選選選選選選選選
 F0 鑄鑄鑄鑄鑄鑄鑄鑄鑄鑄鑄鑄鑄鑄鑄鑄

C340 - C3FF

40 鞭鞭鞭鞭鞭鞭鞭鞭鞭鞭鞭鞭鞭鞭鞭鞭
 50 鬆魏魏魏魏魏魏魏魏魏魏魏魏魏魏魏
 60 嚙嚙嚙嚙嚙嚙嚙嚙嚙嚙嚙嚙嚙嚙嚙嚙
 70 積積積積積積積積積積積積積積積積
 80
 90
 A0 獼靈靈靈靈靈靈靈靈靈靈靈靈靈靈靈
 B0 窺窺窺窺窺窺窺窺窺窺窺窺窺窺窺窺
 C0 藝藝藝藝藝藝藝藝藝藝藝藝藝藝藝藝
 D0 諧諧諧諧諧諧諧諧諧諧諧諧諧諧諧諧
 E0 駝駝駝駝駝駝駝駝駝駝駝駝駝駝駝
 F0 鏢鏢鏢鏢鏢鏢鏢鏢鏢鏢鏢鏢鏢鏢鏢

C440 - C4FF

40 願願願願願願願願願願願願願願願願
 50 鵬鵬鵬鵬鵬鵬鵬鵬鵬鵬鵬鵬鵬鵬鵬
 60 嶼嶼嶼嶼嶼嶼嶼嶼嶼嶼嶼嶼嶼嶼嶼嶼
 70 廠廠廠廠廠廠廠廠廠廠廠廠廠廠廠廠
 80
 90
 A0 裏裏裏裏裏裏裏裏裏裏裏裏裏裏裏裏
 B0 搖覺覺覺覺覺覺覺覺覺覺覺覺覺覺覺覺
 C0 釋釋釋釋釋釋釋釋釋釋釋釋釋釋釋釋
 D0 鹹鹹鹹鹹鹹鹹鹹鹹鹹鹹鹹鹹鹹鹹鹹鹹
 E0 區區區區區區區區區區區區區區區區
 F0 簾簾簾簾簾簾簾簾簾簾簾簾簾簾簾簾簾

C540 - C5FF

40 護護護護護護護護護護護護護護護護
 50 關關關關關關關關關關關關關關關關
 60 綵綵綵綵綵綵綵綵綵綵綵綵綵綵綵綵
 70 學學學學學學學學學學學學學學學學
 80
 90
 A0 襖襖襖襖襖襖襖襖襖襖襖襖襖襖襖襖
 B0 鄧鄧鄧鄧鄧鄧鄧鄧鄧鄧鄧鄧鄧鄧鄧鄧
 C0 練練練練練練練練練練練練練練練練
 D0 瑣瑣瑣瑣瑣瑣瑣瑣瑣瑣瑣瑣瑣瑣瑣瑣
 E0 鍊鍊鍊鍊鍊鍊鍊鍊鍊鍊鍊鍊鍊鍊鍊鍊
 F0 徹徹徹徹徹徹徹徹徹徹徹徹徹徹徹徹

C640 - C6FF

40 讖讖讖讖讖讖讖讖讖讖讖讖讖讖讖讖
 50 敵敵敵敵敵敵敵敵敵敵敵敵敵敵敵敵
 60 顧顧顧顧顧顧顧顧顧顧顧顧顧顧顧顧
 70 鑽鑽鑽鑽鑽鑽鑽鑽鑽鑽鑽鑽鑽鑽鑽鑽
 80
 90
 A0
 B0
 C0
 D0
 E0
 F0

C740 - C7FF

40
 50
 60
 70
 80
 90
 A0
 B0
 C0
 D0
 E0
 F0

Code Page 980 Traditional Chinese (Cont.)

C840 - C8FF

40
50
60
70
80
90
A0
B0
C0
D0
E0
F0

C940 - C9FF

40 义乂口口厂万开毛予口兀巾彳丐有与
50 乳元仿仇仇尤勾印去扎劫夫心市无爻
60 母气片非井任仁仕佗全企判區卅疋至
70 苑秀宁充尔夙男奋疋疋庆切成劫气
80
90
A0 承汎汎边发玃王内臆防伎优佻件伉
B0 伶伶价价佻佻佻佻佻佻佻佻佻佻佻佻
C0 翳園園卍屮屮屮屮屮屮屮屮屮屮屮屮
D0 妯奸媯孖孖孖孖孖孖孖孖孖孖孖孖
E0 伙伙伙伙伙伙伙伙伙伙伙伙伙伙伙伙
F0 机机机机机机机机机机机机机机机机

CA40 - CAFF

40 洲切勃狂玃玃玃玃玃玃玃玃玃玃玃玃
50 西邨邨邨邨邨邨邨邨邨邨邨邨邨邨邨
60 佻佻佻佻佻佻佻佻佻佻佻佻佻佻佻佻
70 劬劬直直直直直直直直直直直直直直
80
90
A0 吡吡吡吡吡吡吡吡吡吡吡吡吡吡吡
B0 龘龘龘龘龘龘龘龘龘龘龘龘龘龘龘龘
C0 峴峴峴峴峴峴峴峴峴峴峴峴峴峴峴峴
D0 序序序序序序序序序序序序序序序序
E0 伙伙伙伙伙伙伙伙伙伙伙伙伙伙伙伙
F0 扰扰扰扰扰扰扰扰扰扰扰扰扰扰扰扰

CB40 - CBFF

40 杙杖机杈柀柀柀柀柀柀柀柀柀柀柀柀
50 沏沏沏沏沏沏沏沏沏沏沏沏沏沏沏沏
60 勃勃勃勃勃勃勃勃勃勃勃勃勃勃勃勃
70 疔疔疔疔疔疔疔疔疔疔疔疔疔疔疔
80
90
A0 芊芊芊芊芊芊芊芊芊芊芊芊芊芊芊芊
B0 阮阮阮阮阮阮阮阮阮阮阮阮阮阮阮阮
C0 佻佻佻佻佻佻佻佻佻佻佻佻佻佻佻佻
D0 刳刳刳刳刳刳刳刳刳刳刳刳刳刳刳
E0 嘴嘴嘴嘴嘴嘴嘴嘴嘴嘴嘴嘴嘴嘴嘴嘴
F0 囡囡囡囡囡囡囡囡囡囡囡囡囡囡囡

CC40 - CCFF

40 坳坳坳坳坳坳坳坳坳坳坳坳坳坳坳坳
50 婢妹婢婢婢婢婢婢婢婢婢婢婢婢婢婢
60 岨岨岨岨岨岨岨岨岨岨岨岨岨岨岨岨岨
70 韶韶韶韶韶韶韶韶韶韶韶韶韶韶韶韶
80
90
A0 愠愠愠愠愠愠愠愠愠愠愠愠愠愠愠
B0 伶伶伶伶伶伶伶伶伶伶伶伶伶伶伶伶
C0 狡狡狡狡狡狡狡狡狡狡狡狡狡狡狡狡
D0 盼盼盼盼盼盼盼盼盼盼盼盼盼盼盼盼
E0 枵枵枵枵枵枵枵枵枵枵枵枵枵枵枵枵枵
F0 泣泣泣泣泣泣泣泣泣泣泣泣泣泣泣泣

CD40 - CDFF

40 涓涓涓涓涓涓涓涓涓涓涓涓涓涓涓涓涓
50 焮焮焮焮焮焮焮焮焮焮焮焮焮焮焮焮
60 狷狷狷狷狷狷狷狷狷狷狷狷狷狷狷狷
70 眈眈眈眈眈眈眈眈眈眈眈眈眈眈眈眈眈
80
90
A0 矧矧矧矧矧矧矧矧矧矧矧矧矧矧矧
B0 轔轔轔轔轔轔轔轔轔轔轔轔轔轔轔轔
C0 芡芡芡芡芡芡芡芡芡芡芡芡芡芡芡芡
D0 迭迭迭迭迭迭迭迭迭迭迭迭迭迭迭迭
E0 僂僂僂僂僂僂僂僂僂僂僂僂僂僂僂僂
F0 剉剉剉剉剉剉剉剉剉剉剉剉剉剉剉

CE40 - CEFF

40 啮啮啮啮啮啮啮啮啮啮啮啮啮啮啮啮
50 垝垝垝垝垝垝垝垝垝垝垝垝垝垝垝垝
60 复复复复复复复复复复复复复复复复
70 姘姘姘姘姘姘姘姘姘姘姘姘姘姘姘姘
80
90
A0 嶷嶷嶷嶷嶷嶷嶷嶷嶷嶷嶷嶷嶷嶷嶷嶷
B0 嶷嶷嶷嶷嶷嶷嶷嶷嶷嶷嶷嶷嶷嶷嶷嶷
C0 德德德德德德德德德德德德德德德德
D0 恹恹恹恹恹恹恹恹恹恹恹恹恹恹恹恹
E0 振振振振振振振振振振振振振振振振
F0 弄弄弄弄弄弄弄弄弄弄弄弄弄弄弄弄

CF40 - CFFF

40 柜柜柜柜柜柜柜柜柜柜柜柜柜柜柜柜
50 桡桡桡桡桡桡桡桡桡桡桡桡桡桡桡桡
60 柀柀柀柀柀柀柀柀柀柀柀柀柀柀柀柀
70 澳澳澳澳澳澳澳澳澳澳澳澳澳澳澳澳
80
90
A0 涪涪涪涪涪涪涪涪涪涪涪涪涪涪涪涪
B0 焮焮焮焮焮焮焮焮焮焮焮焮焮焮焮焮
C0 猊猊猊猊猊猊猊猊猊猊猊猊猊猊猊
D0 珺珺珺珺珺珺珺珺珺珺珺珺珺珺珺珺珺
E0 耽耽耽耽耽耽耽耽耽耽耽耽耽耽耽耽
F0 斫斫斫斫斫斫斫斫斫斫斫斫斫斫斫斫

Code Page 950 Traditional Chinese (Cont.)

D840 - D8FF

40 鈣鈦鈦鈦鈦閨閨閨閨閨閨閨閨閨閨閨閨閨
 50 墟容催儻傴傴傴傴傴傴傴傴傴傴傴傴
 60 舛滄芻芻芻芻芻芻芻芻芻芻芻芻芻芻
 70 嗚嗎煦嚙嚙嚙嚙嚙嚙嚙嚙嚙嚙嚙嚙
 80
 90
 A0 壘堞堞堞堞堞堞堞堞堞堞堞堞堞堞堞
 B0 瓠瓠瓠瓠瓠瓠瓠瓠瓠瓠瓠瓠瓠瓠瓠瓠瓠瓠
 C0 媵媵媵媵媵媵媵媵媵媵媵媵媵媵媵媵
 D0 竊竊竊竊竊竊竊竊竊竊竊竊竊竊竊竊竊竊
 E0 嶠嶠嶠嶠嶠嶠嶠嶠嶠嶠嶠嶠嶠嶠嶠嶠嶠嶠
 F0 岽岽岽岽岽岽岽岽岽岽岽岽岽岽岽岽岽岽

D940 - D9FF

40 儻儻儻儻儻儻儻儻儻儻儻儻儻儻儻儻儻儻
 50 悛悛悛悛悛悛悛悛悛悛悛悛悛悛悛悛悛悛
 60 揶揄揶揄揶揄揶揄揶揄揶揄揶揄揶揄
 70 揶揄揶揄揶揄揶揄揶揄揶揄揶揄揶揄
 80
 90
 A0 晚晚晚晚晚晚晚晚晚晚晚晚晚晚晚晚晚晚
 B0 椏椏椏椏椏椏椏椏椏椏椏椏椏椏椏椏椏椏
 C0 椏椏椏椏椏椏椏椏椏椏椏椏椏椏椏椏椏椏
 D0 椏椏椏椏椏椏椏椏椏椏椏椏椏椏椏椏椏椏
 E0 涓涓涓涓涓涓涓涓涓涓涓涓涓涓涓涓涓涓涓涓涓
 F0 涓涓涓涓涓涓涓涓涓涓涓涓涓涓涓涓涓涓涓涓涓

DA40 - DAFF

40 溟溟溟溟溟溟溟溟溟溟溟溟溟溟溟溟溟溟
 50 溟溟溟溟溟溟溟溟溟溟溟溟溟溟溟溟溟溟
 60 焮焮焮焮焮焮焮焮焮焮焮焮焮焮焮焮焮焮
 70 焮焮焮焮焮焮焮焮焮焮焮焮焮焮焮焮焮焮
 80
 90
 A0 瑠瑠瑠瑠瑠瑠瑠瑠瑠瑠瑠瑠瑠瑠瑠瑠瑠瑠
 B0 瘳瘳瘳瘳瘳瘳瘳瘳瘳瘳瘳瘳瘳瘳瘳瘳瘳瘳
 C0 睇睇睇睇睇睇睇睇睇睇睇睇睇睇睇睇睇睇睇睇睇
 D0 碛碛碛碛碛碛碛碛碛碛碛碛碛碛碛碛碛碛
 E0 筓筓筓筓筓筓筓筓筓筓筓筓筓筓筓筓筓筓
 F0 網網網網網網網網網網網網網網網網網網

DB40 - DBFF

40 翠蕪蕪蕪蕪蕪蕪蕪蕪蕪蕪蕪蕪蕪蕪蕪蕪蕪蕪
 50 臄臄臄臄臄臄臄臄臄臄臄臄臄臄臄臄臄臄
 60 菴菴菴菴菴菴菴菴菴菴菴菴菴菴菴菴菴菴
 70 松藟藟藟藟藟藟藟藟藟藟藟藟藟藟藟藟藟
 80
 90
 A0 菴菴菴菴菴菴菴菴菴菴菴菴菴菴菴菴菴菴
 B0 恭蚌蚌蚌蚌蚌蚌蚌蚌蚌蚌蚌蚌蚌蚌蚌蚌蚌蚌
 C0 岫岫岫岫岫岫岫岫岫岫岫岫岫岫岫岫岫岫
 D0 覬覬覬覬覬覬覬覬覬覬覬覬覬覬覬覬覬覬
 E0 誓誓誓誓誓誓誓誓誓誓誓誓誓誓誓誓誓誓
 F0 跖跖跖跖跖跖跖跖跖跖跖跖跖跖跖跖跖跖

DC40 - DCFF

40 軹軹軹軹軹軹軹軹軹軹軹軹軹軹軹軹軹軹
 50 鄴鄴鄴鄴鄴鄴鄴鄴鄴鄴鄴鄴鄴鄴鄴鄴鄴鄴
 60 酢酢酢酢酢酢酢酢酢酢酢酢酢酢酢酢酢酢
 70 鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇
 80
 90
 A0 隄隄隄隄隄隄隄隄隄隄隄隄隄隄隄隄隄隄
 B0 甯甯甯甯甯甯甯甯甯甯甯甯甯甯甯甯甯甯
 C0 從從從從從從從從從從從從從從從從從從
 D0 囑囑囑囑囑囑囑囑囑囑囑囑囑囑囑囑囑囑
 E0 喀喀喀喀喀喀喀喀喀喀喀喀喀喀喀喀喀喀
 F0 塗塗塗塗塗塗塗塗塗塗塗塗塗塗塗塗塗塗

DD40 - DDFF

40 嫫嫫嫫嫫嫫嫫嫫嫫嫫嫫嫫嫫嫫嫫嫫嫫嫫嫫
 50 嶠嶠嶠嶠嶠嶠嶠嶠嶠嶠嶠嶠嶠嶠嶠嶠嶠嶠
 60 廋廋廋廋廋廋廋廋廋廋廋廋廋廋廋廋廋廋
 70 慎慎慎慎慎慎慎慎慎慎慎慎慎慎慎慎慎慎
 80
 90
 A0 揶揄揶揄揶揄揶揄揶揄揶揄揶揄揶揄
 B0 揶揄揶揄揶揄揶揄揶揄揶揄揶揄揶揄
 C0 睇睇睇睇睇睇睇睇睇睇睇睇睇睇睇睇睇睇睇睇睇
 D0 椏椏椏椏椏椏椏椏椏椏椏椏椏椏椏椏椏椏
 E0 椏椏椏椏椏椏椏椏椏椏椏椏椏椏椏椏椏椏
 F0 椏椏椏椏椏椏椏椏椏椏椏椏椏椏椏椏椏椏

DE40 - DEFF

40 氾氾氾氾氾氾氾氾氾氾氾氾氾氾氾氾氾氾
 50 溟溟溟溟溟溟溟溟溟溟溟溟溟溟溟溟溟溟
 60 淮淮淮淮淮淮淮淮淮淮淮淮淮淮淮淮淮淮
 70 熯熯熯熯熯熯熯熯熯熯熯熯熯熯熯熯熯熯
 80
 90
 A0 燿燿燿燿燿燿燿燿燿燿燿燿燿燿燿燿燿燿
 B0 猿猿猿猿猿猿猿猿猿猿猿猿猿猿猿猿猿猿
 C0 甌甌甌甌甌甌甌甌甌甌甌甌甌甌甌甌甌甌
 D0 瘳瘳瘳瘳瘳瘳瘳瘳瘳瘳瘳瘳瘳瘳瘳瘳瘳瘳
 E0 睇睇睇睇睇睇睇睇睇睇睇睇睇睇睇睇睇睇睇睇睇
 F0 碛碛碛碛碛碛碛碛碛碛碛碛碛碛碛碛碛碛

DF40 - DFFF

40 籥籥籥籥籥籥籥籥籥籥籥籥籥籥籥籥籥籥
 50 箒箒箒箒箒箒箒箒箒箒箒箒箒箒箒箒箒箒
 60 絳絳絳絳絳絳絳絳絳絳絳絳絳絳絳絳絳絳
 70 葵葵葵葵葵葵葵葵葵葵葵葵葵葵葵葵葵葵
 80
 90
 A0 腫腫腫腫腫腫腫腫腫腫腫腫腫腫腫腫腫腫
 B0 蕲蕲蕲蕲蕲蕲蕲蕲蕲蕲蕲蕲蕲蕲蕲蕲蕲蕲蕲
 C0 薈薈薈薈薈薈薈薈薈薈薈薈薈薈薈薈薈薈
 D0 蘘蘘蘘蘘蘘蘘蘘蘘蘘蘘蘘蘘蘘蘘蘘蘘蘘蘘
 E0 菴菴菴菴菴菴菴菴菴菴菴菴菴菴菴菴菴菴
 F0 覬覬覬覬覬覬覬覬覬覬覬覬覬覬覬覬覬覬

Code Page 950 Traditional Chinese (Cont.)

E840 - E8FF

40 踔踔踔踔踔踔踔踔踔踔踔踔踔踔踔踔
 50 遼遼遼遼遼遼遼遼遼遼遼遼遼遼遼
 60 陶陶陶陶陶陶陶陶陶陶陶陶陶陶陶
 70 銛銛銛銛銛銛銛銛銛銛銛銛銛銛銛銛
 80
 90
 A0 錫鎰鎰鎰鎰鎰鎰鎰鎰鎰鎰鎰鎰鎰鎰
 B0 靦靦靦靦靦靦靦靦靦靦靦靦靦靦靦
 C0 銜銜銜銜銜銜銜銜銜銜銜銜銜銜銜
 D0 鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇鈇
 E0 鮫鮫鮫鮫鮫鮫鮫鮫鮫鮫鮫鮫鮫鮫鮫鮫
 F0 廙廙廙廙廙廙廙廙廙廙廙廙廙廙廙廙

E940 - E9FF

40 嘖嘖嘖嘖嘖嘖嘖嘖嘖嘖嘖嘖嘖嘖嘖嘖
 50 學媼媼媼媼媼媼媼媼媼媼媼媼媼媼
 60 嶢嶢嶢嶢嶢嶢嶢嶢嶢嶢嶢嶢嶢嶢嶢嶢
 70 瘡瘡瘡瘡瘡瘡瘡瘡瘡瘡瘡瘡瘡瘡瘡
 80
 90
 A0 傲儉儉儉儉儉儉儉儉儉儉儉儉儉儉儉
 B0 敵敵敵敵敵敵敵敵敵敵敵敵敵敵敵敵
 C0 檣檣檣檣檣檣檣檣檣檣檣檣檣檣檣
 D0 檣檣檣檣檣檣檣檣檣檣檣檣檣檣檣
 E0 敵敵敵敵敵敵敵敵敵敵敵敵敵敵敵敵
 F0 潞潞潞潞潞潞潞潞潞潞潞潞潞潞潞潞

EA40 - EAFF

40 瀟瀟瀟瀟瀟瀟瀟瀟瀟瀟瀟瀟瀟瀟瀟瀟
 50 桑燭燭燭燭燭燭燭燭燭燭燭燭燭燭燭
 60 獮獮獮獮獮獮獮獮獮獮獮獮獮獮獮
 70 瘰瘰瘰瘰瘰瘰瘰瘰瘰瘰瘰瘰瘰瘰瘰
 80
 90
 A0 曉曉曉曉曉曉曉曉曉曉曉曉曉曉曉曉
 B0 糜糜糜糜糜糜糜糜糜糜糜糜糜糜糜糜
 C0 質質質質質質質質質質質質質質質質
 D0 綳綳綳綳綳綳綳綳綳綳綳綳綳綳綳綳綳
 E0 蔚蔚蔚蔚蔚蔚蔚蔚蔚蔚蔚蔚蔚蔚蔚蔚
 F0 臘臘臘臘臘臘臘臘臘臘臘臘臘臘臘臘

EB40 - EBFF

40 棘棘棘棘棘棘棘棘棘棘棘棘棘棘棘棘
 50 覆覆覆覆覆覆覆覆覆覆覆覆覆覆覆覆
 60 蜈蜈蜈蜈蜈蜈蜈蜈蜈蜈蜈蜈蜈蜈蜈蜈
 70 樞樞樞樞樞樞樞樞樞樞樞樞樞樞樞樞
 80
 90
 A0 譚譚譚譚譚譚譚譚譚譚譚譚譚譚譚譚
 B0 謹謹謹謹謹謹謹謹謹謹謹謹謹謹謹謹
 C0 蹀蹀蹀蹀蹀蹀蹀蹀蹀蹀蹀蹀蹀蹀蹀蹀蹀蹀
 D0 遶遶遶遶遶遶遶遶遶遶遶遶遶遶遶遶
 E0 鈹鈹鈹鈹鈹鈹鈹鈹鈹鈹鈹鈹鈹鈹鈹鈹鈹鈹
 F0 鈹鈹鈹鈹鈹鈹鈹鈹鈹鈹鈹鈹鈹鈹鈹鈹鈹鈹

EC40 - ECFF

40 錕錕錕錕錕錕錕錕錕錕錕錕錕錕錕錕
 50 錕錕錕錕錕錕錕錕錕錕錕錕錕錕錕錕
 60 錕錕錕錕錕錕錕錕錕錕錕錕錕錕錕錕
 70 錕錕錕錕錕錕錕錕錕錕錕錕錕錕錕錕
 80
 90
 A0 鮎鮎鮎鮎鮎鮎鮎鮎鮎鮎鮎鮎鮎鮎鮎鮎
 B0 慶慶慶慶慶慶慶慶慶慶慶慶慶慶慶慶
 C0 噤噤噤噤噤噤噤噤噤噤噤噤噤噤噤噤
 D0 翺翺翺翺翺翺翺翺翺翺翺翺翺翺翺翺
 E0 慈慈慈慈慈慈慈慈慈慈慈慈慈慈慈慈
 F0 厲厲厲厲厲厲厲厲厲厲厲厲厲厲厲厲

ED40 - EDFF

40 緊緊緊緊緊緊緊緊緊緊緊緊緊緊緊緊
 50 滌滌滌滌滌滌滌滌滌滌滌滌滌滌滌滌
 60 煗煗煗煗煗煗煗煗煗煗煗煗煗煗煗煗
 70 甌甌甌甌甌甌甌甌甌甌甌甌甌甌甌甌
 80
 90
 A0 臨臨臨臨臨臨臨臨臨臨臨臨臨臨臨臨
 B0 襪襪襪襪襪襪襪襪襪襪襪襪襪襪襪襪襪
 C0 拵拵拵拵拵拵拵拵拵拵拵拵拵拵拵拵拵
 D0 綉綉綉綉綉綉綉綉綉綉綉綉綉綉綉綉
 E0 綉綉綉綉綉綉綉綉綉綉綉綉綉綉綉綉
 F0 襪襪襪襪襪襪襪襪襪襪襪襪襪襪襪襪襪

EE40 - EEFF

40 預預預預預預預預預預預預預預預預
 50 香蕘蕘蕘蕘蕘蕘蕘蕘蕘蕘蕘蕘蕘蕘蕘
 60 蠶蠶蠶蠶蠶蠶蠶蠶蠶蠶蠶蠶蠶蠶蠶蠶
 70 蝻蝻蝻蝻蝻蝻蝻蝻蝻蝻蝻蝻蝻蝻蝻蝻
 80
 90
 A0 諱諱諱諱諱諱諱諱諱諱諱諱諱諱諱諱
 B0 諛諛諛諛諛諛諛諛諛諛諛諛諛諛諛諛諛
 C0 驛驛驛驛驛驛驛驛驛驛驛驛驛驛驛驛
 D0 鑄鑄鑄鑄鑄鑄鑄鑄鑄鑄鑄鑄鑄鑄鑄鑄鑄
 E0 鑄鑄鑄鑄鑄鑄鑄鑄鑄鑄鑄鑄鑄鑄鑄鑄鑄
 F0 闌闌闌闌闌闌闌闌闌闌闌闌闌闌闌闌闌闌闌闌闌

EF40 - EFFF

40 韓韓韓韓韓韓韓韓韓韓韓韓韓韓韓韓
 50 鶴鶴鶴鶴鶴鶴鶴鶴鶴鶴鶴鶴鶴鶴鶴鶴
 60 翮翮翮翮翮翮翮翮翮翮翮翮翮翮翮
 70 絡絡絡絡絡絡絡絡絡絡絡絡絡絡絡絡
 80
 90
 A0 鷓鷓鷓鷓鷓鷓鷓鷓鷓鷓鷓鷓鷓鷓鷓鷓
 B0 散散散散散散散散散散散散散散散散
 C0 嬰嬰嬰嬰嬰嬰嬰嬰嬰嬰嬰嬰嬰嬰嬰嬰
 D0 儀儀儀儀儀儀儀儀儀儀儀儀儀儀儀儀
 E0 檣檣檣檣檣檣檣檣檣檣檣檣檣檣檣
 F0 激激激激激激激激激激激激激激激激

Appendix C: How to make printing pattern from single side to double side (Double side mode with single side command)

The print condition is as below.

The distance between cutter and 1st platen	17.5mm
The distance between 1st platen and 2nd platen	23.5mm

(1) Firmware algorithm to separate the printing from single side to double side

The following method is to separate the print buffer into two parts – one part is for front side and the other part is for back side.

a) Store printing data until paper cut

Firmware stores print data until paper cut command.

The print data is stored bit-pattern and information of position for each line.

b) Search last print line

Firmware search last print line then line spacing after last print line should be consider as space to adjust the distance between printing position and cutter.

If there is any printing within 17.5mm (distance between 1st platen and cutter) like logo, firmware prints on front side.

c) Calculate printing separate position

Firmware accumulate the print space from beginning to the end (searched by step b)) then calculate the separate position by following formula.

Separate Position (SP) =

$$\{ \text{Total print space (TP)} + 23.5\text{mm}(\text{distance between 1st and 2nd platen}) \} / 2$$


d) Adjust the separate position not to separate the middle of print line

Firmware adjusts separate position not to separate the printing in the middle of print line (includes character attributes such as double height), barcode, and logo.

(2) Example of printing pattern

a) Text printing only

The distance between cutter and 1st platen 17.5 mm
 The distance between 1st platen and 2nd platen 35.0 mm



Top Margin
17.5 mm



Print commands
 Line 1
 Line 2
 ...
 ...
 Line 100
 LF
 ... (6 LF)
 LF
 Paper Cut

Printing area
337.7 mm

Note
 Top margin is due to the line feed after last line before cut.
 Line pitch is 7.52 LPI

Separate position
 $(337.7 + 35) / 2 / 25.4 * 7.52 = 55.17$ Line
 Front side
 $= 56 \text{ line} / 7.52 * 25.4 = 189.1 \text{ mm}$
 Back side
 $= 337.7 - 189 = 148.6 \text{ mm}$

TotalLength
358.0 mm




Top Margin
17.5 mm

Printing area
189.1 mm

Bottom Margin
2.8 mm

TotalLength
209.4 mm





Top Margin
52.5 mm


Printing area
148.6 mm

Bottom Margin
8.4 mm

b) Text & logo printing (Logo is printed after paper cut)




c) Text & logo printing (Logo is printed before paper cut.)



(3) Limitation

a) Grouped lines


If several lines are grouped as below, for Double Side Mode with Single Side Command, firmware may separate these lines and print them on two sides.



FW may separate into two pages at here.

b) Rotated Mode


Firmware may separate these words and print them on two sides.



FW may separate into two pages at here.

c) Bitimage printing

Firmware may separate the graphic print used by bitimage command (ESC * and ESC Y) onto two pages.



FW may separate into two pages at here.

Index

- 7 -

7156 printer
 printer specifications, 233
 7198 printer
 clearance, 11
 dimensions, 11, 235
 environmental conditions, 234
 features, 2
 location, 11
 ordering supplies, 4
 power requirements, 234
 power supply, ordering, 6
 reliability, 235
 sending in for repair, 11
 turning on, 39

- A -

Accessories. *See* Supplies
 Asian character
 commands, 194
 Asian character commands, 194
 Asian mode
 setting, 59, 60

- B -

Bar code commands, 172
 Bar codes
 commands, 172
 BASIC
 sending commands, 79

- C -

Cabinet
 cleaning, 7
Cables
cash drawer, 9
communication, 9
 connecting, 15
 Carriage return usage

setting, 59
 Cash drawer
 ordering, 6
 Cash drawer cables
 connecting, 15
 Changing paper, 40
 Character set
 code page 437, 242
 code page 850, 243
 code page 852, 245
 code page 863, 247
 code page 865, 244, 246, 247, 248, 249
 Character sets, 240
 Characters, receipt station
 dot patterns, 237
 Cleaning the printer, 7
 Clearance around printer, 11
 Code page 437
 character set, 240
 Code Page 437, 242
 Code page 850
 character set, 240
 Code Page 850, 243
 Code Page 852, 245
 Code Page 863, 247
 Code Page 865, 244, 246, 247, 248, 249
 Color paper
 setting, 54, 55, 57, 60, 63, 65, 68, 69
 Commands
 Asian character, 194
 bar code, 172
 flash download, 197
 graphics, 139
 horizontal positioning, 114
 listing, 87
 macro, 185
 page mode, 178
 print, 108
 print characteristics, 121
 printer function, 102
 printer status, 150
 real time, 161
 real time, rules for using, 161

- realtime, moving data through the buffer, 162
- sending, 78
- user data storage, 187
- vertical positioning, 108
- Commands, printer function
 - set horizontal and vertical minimum motion units, 113
- Commands, real time
 - alternate implementation, 161
 - first implementation, 161
 - real time request to printer, GS sequence, 166
 - recognizing data from the printer, 159
- Commands, sending
 - using BASIC, 79
 - using DOS, 78
- Communication, 78
- Communication cables, 9
 - connecting, 15
 - ordering, 6
- Communication interface. *See* RS-232C interface
- Communication interface modes, 53
- Configuring the printer, 50
- Connecting cables
 - cash drawer, 15
 - communication, 15
 - power, 15
- Connector
 - cash drawer, 83
 - RS-232C communication, 81
- Consumables. *See* Paper
- Contacting a service representative, 47

- D -

- Data
 - moving through buffer, 162
- Datascope modes
 - setting, 56
- Default code page**, 64
- Default lines per inch
 - setting, 59
- Density, of print, 235
- Diagnostic modes, 56
- Diagnostics, 48
 - knife failure, 45
 - level 0, 48
 - level 1, 49
 - level 2, 76
 - level 3, 77
 - paper jam, 45
 - paper out, 45
 - printhead over/under temperature, 46
 - startup, 48

- Vendor adjustment, 70
- Dimensions, of printer, 11, 235
- DIP switches. *See* Switch settings
- Documentation
 - ordering, 6
- DOS
 - sending commands, 78
- DOS Flash Utility, 221
- Dot patterns, of characters, 237
- DTR/DSR protocol, 80
- Duty cycle**
 - limitations**, 235

- E -

- EEPROM to default settings, 69
- Emulation/software options, 57
- Environmental conditions, 234
- Errors. *See* Problems

- F -

- Features, 2
- Flash download
 - commands, 197
- Flash download commands, 197

- G -

- Graphics
 - commands, 139
- Graphics commands, 139

- H -

- Hardware options, 61
- Horizontal positioning commands, 114

- I -

- Installation
 - choosing location, 11
 - connecting cables, 15
 - loading paper, 40
 - setting switches, 14
 - turning on the printer, 39
- Interface. *See* RS-232C interface

- K -

- Knife
 - failure of, 45

- L-

- LED (green) blinking (fast)
 - what to do, 45
- LED (green) blinking (slow)
 - what to do, 45
- LED (green) does not come on
 - what to do, 45
- Level 0 diagnostics, 48
- Level 1 diagnostics, 49
 - asian mode, 59, 60
 - carriage return usage, 59
 - color paper option, 54, 55, 57, 60, 63, 65, 68, 69
 - communication interface modes, 53
 - configuring the printer, 50
 - datascope modes, 56
 - default code page**, 64
 - default lines per inch, 59
 - diagnostic modes, 56
 - EEPROM to default settings, 69
 - emulation/software options, 57
 - hardware options, 61
 - maximum power option, 61
 - paper low sensor, 62
 - paper width, 62
 - print density, 61
 - printer configuration, 49
 - printer emulations, 57
 - receipt test modes, 57
 - RS 232 interface, 53
 - set extra RS-232C options, 86
- Level 2 diagnostics, 76
- Level 3 diagnostics, 77
- Location
 - choosing, 11
 - clearance, 11

- M-

- Macro
 - commands, 185
- Macro commands, 185
- Maintenance
 - cleaning the printer, 7
- Maximum power
 - setting, 61
- Modes
 - datascope, 56
 - receipt test, 57

- O-

- Operator panel, 76
- Options

- asian mode, 59, 60
- carriage return usage, 59
- color paper, 54, 55, 57, 60, 63, 65, 68, 69
- default lines per inch, 59
- maximum power, 61
- paper low sensor, 62
- paper width, 62
- print density, 61
- printer emulations, 57
- Ordering
 - cash drawer, 6
 - communication cables, 6
 - documentation, 6
 - paper, 4
 - power supply, 6
 - supplies, 4

- P-

- Packing material
 - repacking printer, 11
- Page mode
 - commands, 178
- Page mode commands, 178
- Paper
 - advancing, 43
 - changing, 40
 - low, 40, 45
 - ordering, 4
 - out, 40
 - putting in the paper roll, 41
 - removing, 40
 - requirements, 4
 - suppliers, 4
- Paper jam, 45
- Paper low sensor
 - setting, 62
- Paper out, 45
- Paper width
 - setting, 62
- Power
 - turning on the printer, 39
- Power cables
 - connecting, 15
- Power requirements, 234
- Power supply
 - ordering, 6
- Print characteristics commands, 121
- Print characteristics
 - commands, 121
- Print commands, 108
- Print density
 - receipt, 235

- setting, 61
- Print problems, 46
- Print speed, 79
- Print timing, 79
- Print zones
 - receipt station, 238
- Printer
 - configuration, 49
- Printer configuration
 - setting, 49
- Printer emulations
 - setting, 57
- Printer function commands, 102
- Printer status
 - commands, 150
- Printer status commands, 150
- Printhead
 - thermal, 3
- Printhead, thermal
 - cleaning, 8
 - over/under temperature, 46
- Printing, continuous**
 - limitations of**, 235
- Problems, 44
 - contacting a service representative, 47
 - knife failure, 45
 - paper jam, 45
 - paper out, 45
 - print is light or spotty, 46
 - printhead over/under temperature, 46
- Protocol, RS-232C
 - DTR/DSR, 80
 - XON/XOFF, 80

- R -

- Real time
 - commands, 161
- Real time commands, 161
 - alternate implementation, 161
 - preferred implementation, 161
 - using, 161
- Receipt station
 - character dot patterns, 237
 - print zones, 238
- Receipt test modes
 - setting, 57
- Reliability, 235
- Repacking printer, 11
- Reset, 14
- Rotated printing
 - summary, 138
- RS 232 interface

- setting, 53
- RS 232 interface settings, 53
- RS-232C interface, 79
 - cash drawer connector, 83
 - communication connector, 81
 - DTR/DSR protocol, 80
 - parameters, 85
 - setting extra options, 86
 - technical specifications, 81
 - XON/XOFF protocol, 80

- S -

- Setting switches, 14
 - RS-232C parameters, 85
- Setup mode. *See* Level 1 diagnostics
- Specifications, 233
 - RS-232C interface, 81
- Speed, 79
- Supplies
 - cash drawer, 6
 - communication cables, 6
 - paper, 4
 - power cord, 6
 - power supply, 6
 - shipped separately**, 9
- Switch settings, 14
- Switch Settings
 - RS-232C parameters, 85

- T -

- Technical specifications
 - RS-232C interface, 81
- Testing the printer, 70
- Thermal paper
 - ordering, 4
 - requirements, 4
 - suppliers, 4
- Thermal printhead. *See* Printhead
 - cleaning, 8
 - print density, 235
- Timing, 79
- Troubleshooting. *See* Problems
- Turning on the printer, 39

- U -

- User data storage
 - commands, 187
- User data storage commands, 187
- Using real time commands, 161

- V-

Vendor Adjustment, 70
Vertical Positioning Commands, 108

- W-

Weight, of printer, 235

- X-

XON/XOFF protocol, 80



User Feedback Form

Title: NCR 7198 Thermal Receipt Owners Guide

Number: B005-0000-1736

Issue: Issue B

Date: August 2006

NCR welcomes your feedback on this publication. Your comments can be of great value in helping us improve our information products.

Circle the numbers below that best represent your opinion of this publication.

Ease of use	5	4	3	2	1	0	5 = Excellent
Accuracy	5	4	3	2	1	0	4 = Good
Clarity	5	4	3	2	1	0	3 = Adequate
Completeness	5	4	3	2	1	0	2 = Fair
Organization	5	4	3	2	1	0	1 = Poor
Appearance	5	4	3	2	1	0	0 = Not applicable
Examples	5	4	3	2	1	0	
Illustrations	5	4	3	2	1	0	
Job performance	5	4	3	2	1	0	
Question resolution	5	4	3	2	1	0	
Overall satisfaction	5	4	3	2	1	0	

Indicate the ways you feel we could improve this publication.

- | | |
|--|---|
| <input type="checkbox"/> Improve the table of contents | <input type="checkbox"/> Add more/better quick reference aids |
| <input type="checkbox"/> Improve the overview/introduction | <input type="checkbox"/> Add more examples |
| <input type="checkbox"/> Improve the organization | <input type="checkbox"/> Add more illustrations |
| <input type="checkbox"/> Improve the index | <input type="checkbox"/> Add more step-by-step procedures |
| <input type="checkbox"/> Make it less technical | <input type="checkbox"/> Add more troubleshooting information |
| <input type="checkbox"/> Make it more concise/brief | <input type="checkbox"/> Add more detail |

Write any additional comments you may have below and on additional sheets, if necessary. Include page numbers where applicable.

If we may contact you concerning your comments, please fill in the information below.

Name: _____

Organization: _____

Company: _____

Address: _____


Phone: _____ Fax: _____



NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

BUSINESS REPLY MAIL
FIRST CLASS PERMIT NO. 3 DAYTON, OHIO

POSTAGE WILL BE PAID BY ADDRESSEE



Thank you for your evaluation of this publication. Fold the form where indicated, tape (please do not staple), and drop in the mail.

Cut

Fold

Fold

NCR CORPORATION
RETAIL SYSTEMS GROUP
INFORMATION PRODUCTS DEPT
2651 SATELLITE BLVD.
DULUTH, GA 30096-6810

B005-000-1736

Issue B

1102

NCR is the name and mark of NCR Corporation
© 2006 NCR Corporation
Printed in U.S.A