

7409-K101/K102/K104/K106/K108/K113/K135

# 17" Cosmetic Bezel

Kit Instructions



Issue A

---

## Revision Record

Issue	Date	Remarks
A	Feb 2011	First issue

## Introduction

Use these instructions to install the Cosmetic Bezel on a 7409 terminal. There are 6 colors available. The installation procedures are identical.

- 7409-K101 (Red)
- 7409-K101 (Blue, NHS)
- 7409-K104 (Blue, Pick N Pay)
- 7409-K105 (Charcoal, Standard 7409)
- 7409-K106 (Yellow)
- 7409-K108 (White, RAL 9003)
- 7409-K113 (Green, Pantone PMS 361)
- 7409-K135 (Green, Pantone 382)

Each kit includes the bezel and four screws to install it.

## Installation Procedures

The Cosmetic Bezel is held on by screws and plastic tabs on the bezel.

1. Install the Cosmetic Bezel, making sure all 12 tabs snap into place.
2. Secure the bezel with screws (4).

