

KIT INSTRUCTIONS

External Biometrics Reader without Biokey



9700-0006-7761 / 9700-9006-7761

Issue A



The product described in this document is a licensed product of NCR Corporation.

NCR is a registered trademark of NCR Corporation. Product names mentioned in this publication may be trademarks or registered trademarks of their respective companies and are hereby acknowledged.

The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.

Where creation of derivative works, modifications or copies of this NCR copyrighted documentation is permitted under the terms and conditions of an agreement you have with NCR, NCR's copyright notice must be included.

It is the policy of NCR Corporation (NCR) to improve products as new technology, components, software, and firmware become available. NCR, therefore, reserves the right to change specifications without prior notice.

All features, functions, and operations described herein may not be marketed by NCR in all parts of the world. In some instances, photographs are of equipment prototypes. Therefore, before using this document, consult with your NCR representative or NCR office for information that is applicable and current.

To maintain the quality of our publications, we need your comments on the accuracy, clarity, organization, and value of this book. Please use the link below to send your comments.

Email: FD230036@ncr.com

Copyright © 2017
By NCR Corporation
Duluth, GA U.S.A.
All Rights Reserved


Revision Record

Issue	Date	Remarks
A	May 2017	First Issue

External Biometrics Reader without Biokey


Introduction

This kit provides the components to add an External Biometrics Reader without Biokey.



Installation Procedure

1. Connect the Biometrics Reader USB Cable to any available USB port on the POS.



2. Position the Biometrics Reader for use.



Note: A mounting kit (7761-K100) is available to mount the Biometrics Reader on the wall or countertop.



Note: You may need to download the latest U.are.U 4500 family of Fingerprint Modules and Readers driver. Please visit www.crossmatch.com to do so.

