

Kit Instructions

Mobile Shopper MC18/PS20 Soft Holster

2394-K012
Issue A



The product described in this document is a licensed product of NCR Corporation.

NCR is a registered trademark of NCR Corporation. Product names mentioned in this publication may be trademarks or registered trademarks of their respective companies and are hereby acknowledged.

Where creation of derivative works, modifications or copies of this NCR copyrighted documentation is permitted under the terms and conditions of an agreement you have with NCR, NCR's copyright notice must be included.

It is the policy of NCR Corporation (NCR) to improve products as new technology, components, software, and firmware become available. NCR, therefore, reserves the right to change specifications without prior notice.

All features, functions, and operations described herein may not be marketed by NCR in all parts of the world. In some instances, photographs are of equipment prototypes. Therefore, before using this document, consult with your NCR representative or NCR office for information that is applicable and current.

To maintain the quality of our publications, we need your comments on the accuracy, clarity, organization, and value of this book. Please use the link below to send your comments.

Email: FD230036@ncr.com

Copyright © 2019
By NCR Corporation
864 Spring St NW
Atlanta, GA 30308
U.S.A.
All Rights Reserved

Revision Record

Issue	Date	Remarks
A	May 2019	First Issue


Mobile Shopper MC18/PS20 Soft Holster

Introduction

This kit contains a soft holster that serves as a holder for the Personal Shopping Device. Users can wear the holster in the following ways:

- On the hip by using a detachable belt clip
- Across the body using a shoulder strap

Kit Components



CCP-75925

PID	Description
2394-K012	FL Mobile Shopper MC18/PS20 Soft Holster, hip (includes belt clip) or crossbody wearable with an additional shoulder strap

Installation Procedures

The holster can be worn in the following ways:

- On the hip by using a belt clip. For more details, refer to [Using a Belt Clip](#) below.
- Across the body using a shoulder strap. For more details, refer to [Using a Shoulder Strap](#) on the facing page.




Note: To insert the Personal Shopping Device into the holster, refer to [Inserting the Mobile Shopper into the Holster](#) on page 4.

Using a Belt Clip


To wear the holster on the hip using a detachable belt clip, follow these steps:

1. Attach the belt clip to the holster.



CCP-75926

2. Pinch the clip release and attach the holster to a belt or waist band.




CCP-75927



Note: To insert the Personal Shopping Device into the holster, refer to [Inserting the Mobile Shopper into the Holster](#) on page 4.

Removing the Belt Clip


To remove the detachable belt clip from the holster, press the release button on the belt clip, and then remove the belt clip from the holster.



CCP-75929

Using a Shoulder Strap

To wear the holster across the body using shoulder strap, attach the shoulder strap to the loops located on both sides of the holster.



CCP-75928




Note: To insert the Personal Shopping Device into the holster, refer to [Inserting the Mobile Shopper into the Holster](#) on the next page.

Inserting the Mobile Shopper into the Holster


To insert the mobile shopper into the holster, follow these steps:

1. Slide the mobile shopper into the holster, with the screen facing the user.



CCP-75931

2. Place the restraining strap over the mobile shopper and the hook to secure it in place.



CCP-75930