

Installing and Removing the 58 mm Paper Guide

Installing and removing the 58mm paper guide for the 58 mm wide paper.

For printers: 7167-1xxx, 7167-2xxx, 7167-7xxx, 7167-9xxx
7197-1xxx, 7197-2xxx, 7197-7xxx, 7197-9xxx

Installing the 58mm Paper Guide

1. Open the top cover.
2. Align the 58 mm paper guide to the 4 slots in the paper tray and push it into position.



Removing the 58mm Paper Guide

1. Open the top cover.
2. Release the 58mm paper guide by depressing on the portion of the paper guide by using finger (as shown in the picture) and then pull on to remove.

