


For 7168-1XXX, 7198-2XXX, and 7198-9XXX Printers

Slot in/ Insert the paper guide into A and B locations and press it downwards by finger as shown in the picture.




For 7197-5XXX, 7197-6XXX and 7167-5XXX, 7167-6XXX printers

Installation

Break the tab using a pair of pliers



Slot in/ Insert the paper guide into A and B locations and press it downwards by finger as shown in the picture.



Removal

Push the paper guide away from the printer cover wall as shown in the picture.

