

Kit Instructions

Rear Cable Cover

7199-K200
Issue A



The product described in this document is a licensed product of NCR Corporation.

NCR is a registered trademark of NCR Corporation. NCR RealPOS is a trademark of NCR Corporation in the United States and/or other countries. Other product names mentioned in this publication may be trademarks or registered trademarks of their respective companies and are hereby acknowledged.

The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.

Where creation of derivative works, modifications or copies of this NCR copyrighted documentation is permitted under the terms and conditions of an agreement you have with NCR, NCR's copyright notice must be included.

It is the policy of NCR Corporation (NCR) to improve products as new technology, components, software, and firmware become available. NCR, therefore, reserves the right to change specifications without prior notice.

All features, functions, and operations described herein may not be marketed by NCR in all parts of the world. In some instances, photographs are of equipment prototypes. Therefore, before using this document, consult with your NCR representative or NCR office for information that is applicable and current.

To maintain the quality of our publications, we need your comments on the accuracy, clarity, organization, and value of this book. Please use the link below to send your comments.

Email: FD230036@ncr.com

Copyright © 2018
By NCR Corporation
Atlanta, GA U.S.A.
All Rights Reserved

Revision Record

Issue	Date	Remarks
A	Jul 2017	First Issue

REAR CABLE COVER KIT INSTRUCTION

Introduction


This kit serves as a cover for the rear cables connected at the bottom of the printer.

Installation Procedure


- 1) Flip the printer to view the back cover.




- 2) When attaching the cables, make sure to fasten it to the cable restraints. See blue arrows for direction. Below is an Option I/F routing:



- 3) Attach the rear cable cover to the printer. Insert the top latches to the top slots.



- 4) Lock the rear cable cover by inserting the bottom latches to the bottom slots or by pushing the cover to the printer.



Removal Procedure

- 1) Flip the printer to view the back cover.



- 2) Hold the printer with one hand and the other to push the rear cable cover.

