KIT INSTRUCTIONS

Serial Expansion VESA Bracket

NCR

7702-K323

Issue A

Revision Record

Issue	Date	Remarks
A	Jun 2015	First Issue

3-Port Serial Expansion

This kit provides an adapter plate for installing an NCR RealPOS XR7 on a 3rd party VESA mount when the XR7 is configured with the Serial Port Expansion feature. there are two versions of the Serial Port Expansion feature:

- 3-Port Serial Expansion (7702-K161) for standard NCR peripherals

- HSR RJ12 Expansion (7702-K160) for HSR peripherals

The installation procedures are the same for both versions.

Components

Serial Expansion VESA Bracket
497-0508370

Screw, SEMS, M4 x 12, Pan Head, Ph
006-8622686

33882

Installation Procedures

**Note:** Since the mounting scheme could be on a wall, table stand, or kiosk only the the VESA mounting plate is shown.

1. Install the Serial Expansion VESA Bracket on the 3rd party mount (4 screws).

Serial Expansion VESA Bracket

3rd Party VESA Mounting Plate (Typical)

33877

Caution: The M4 x 12 mm length works for 3rd party VESA plates with a thickness range of 2 – 6 mm. Anything outside of this range requires different length screws and selection is the end users discretion.

2. Install the Serial Expansion Module on the mounting plate(3 screws).

Serial Expansion

33878

3. Secure the mount to the terminal (2 captive screws).

    a. Insert the Mounting Plate Studs (2) into the openings in the Rear Cover and rotate the Table Top Stand downward.


33880

    b. Secure the mount to the terminal (2 captive screws).

Captive Screws

33881

4. Connect the Serial Expansion Power/USB Cable to the terminal I/O Panel.

Serial Expansion Power/USB Cable

33879