NCR VOYIX

Tamper Resistant Cover, Remote I/O

Kit Instructions

7772-K200

Issue A

Copyright

The product described in this document is a licensed product of NCR Voyix Corporation.

NCR CX7 All-in-One POS (7772) is a trademark of NCR Voyix Corporation in the United States and/or other countries. Other product names mentioned in this publication may be trademarks or registered trademarks of their respective companies and are hereby acknowledged.

Where creation of derivative works, modifications or copies of this NCR Voyix copyrighted documentation is permitted under the terms and conditions of an agreement you have with NCR Voyix, NCR Voyix's copyright notice must be included.

It is the policy of NCR Voyix Corporation to improve products as new technology, components, software, and firmware become available. NCR Voyix, therefore, reserves the right to change specifications without prior notice.

All features, functions, and operations described herein may not be marketed by NCR Voyix in all parts of the world. In some instances, photographs are of equipment prototypes. Therefore, before using this document, consult with your NCR Voyix representative or NCR Voyix office for information that is applicable and current.

Table of Contents

Revision Record

| Issue	Date	Remarks
A	Aug 2020	First Issue

Tamper Resistant Cover, Remote I/O

This kit provides a Tamper Resistant Cover for the Remote I/O Chassis of the NCR CX7 All-in-One POS (7772) or NCR CX5 All-in-One POS (7773).

Kit Contents

M3x8mm Machine,
Phillips, Flat
006-8617798

Bracket, Hinged I/O Cover, CX7
497-0526997

CCP-77893

Installation Procedure

1. Install the Tamper Resistant Cover on the Remote I/O Chassis using two (2) screws.

Security Cover

Remote I/O Chassis

CCP-77894

2. Loosen the captive screws of the Tamper Resistant Cover and lift the Top Cover to open.

Captive Screws

Top Cover

CCP-78201

3. Connect the cables to the I/O.

USB Centric (Retail) Remote I/O Chassis

CCP-77891

Callout	Port Name
1	RJ50 Serial (Enhanced UART)
2	Dual USB 3.0
3	DisplayPort
4	DB9 Serial (Standard UART)
5	LAN In Connect to Ethernet Network
6	LAN Out Connect to the CX Head

Callout	Port Name
7	USB-C
8	LED
9	24V Power In
10	USB 12V
11	USB 24V
12	Cash Drawer

Serial Centric (Hospitality) Remote I/O Chassis

CCP-77892

| Callout	Port Name
1	RJ12 Serial • COM1 (Enhanced UART) • COM2 (Standard UART) • COM3 (Enhanced UART) • COM4 (Standard UART)
2	Cash Drawer A
3	Cash Drawer B
4	DisplayPort
5	LAN In Connect to Ethernet Network
6	LAN Out Connect to the CX Head
7	USB-C
8	LED
9	24V Power In
10	USB 24V
11	USB 12V
12	Dual USB 3.0

Callout	Port Name
13	RJ45 Serial • COM5 (Enhanced UART) • COM6 (Standard UART)

4. Close the Top Cover and tighten the captive screws.

Captive Screws

CCP-78202